xdobo XDOBO X8 IV

xdobo X8 IV Portable Bluetooth Speaker User Manual

1. Product Overview



The xdobo X8 IV is a portable Bluetooth speaker designed for high-quality audio playback in various environments. Featuring IPX7 waterproofing, it is suitable for outdoor use and can withstand immersion in water up to 1 meter for 30 minutes. The speaker also includes integrated RGB lighting for an enhanced audio-visual experience. Its compact design and wireless connectivity make it ideal for home, outdoor activities, and parties.

2. What's in the Box

The retail package for the xdobo X8 IV Portable Bluetooth Speaker includes the following items:

- xdobo X8 IV Portable Bluetooth Speaker
- Charging Cable
- User Manual

3. Controls and Indicators

The xdobo X8 IV speaker features intuitive controls for easy operation. Specific button functions are detailed below:

- **Power Button:** Press and hold to power on or off.
- **Play/Pause Button:** Press to play or pause audio.
- **Volume Up Button:** Press to increase volume. Press and hold to skip to the next track.
- **Volume Down Button:** Press to decrease volume. Press and hold to go to the previous track.
- **Mode Button:** Press to cycle through different playback modes or RGB lighting effects.
- **Charging Port:** For connecting the charging cable.

4. Setup

4.1. Charging the Speaker

1. Connect the charging cable to the speaker's charging port.
2. Connect the other end of the cable to a compatible USB power adapter (5V input).
3. The charging indicator light will illuminate.
4. Once fully charged, the indicator light will change or turn off.

4.2. Powering On/Off

1. To power on, press and hold the Power button until you hear an audible prompt and the indicator lights activate.
2. To power off, press and hold the Power button again until you hear an audible prompt and the indicator lights turn off.

4.3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "XDOBO X8 IV" from the list of found devices.
4. Once connected, the speaker will provide an audible confirmation, and the LED indicator will become solid.

5. Operating Instructions

5.1. Audio Playback

- **Play/Pause:** Press the Play/Pause button once to start or stop audio playback.
- **Volume Adjustment:** Press the Volume Up button to increase the volume. Press the Volume Down button to decrease the volume.
- **Track Navigation:** Press and hold the Volume Up button to skip to the next track. Press and hold the Volume Down button to go to the previous track.

5.2. RGB Lighting Modes

The xdobo X8 IV features dynamic RGB lighting. Press the Mode button to cycle through various lighting effects or to turn the lights off.

5.3. Waterproof Usage

The xdobo X8 IV speaker is rated IPX7 waterproof, meaning it can be immersed in water up to 1 meter (3 feet) for up to 30 minutes. Ensure all port covers are securely closed before exposing the speaker to water. Do not expose the speaker to saltwater or other chemicals. After exposure to water, dry the speaker thoroughly before charging.

6. Maintenance

- **Cleaning:** Use a soft, damp cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, fully charge the speaker before long periods of storage and recharge it every few months.

7. Troubleshooting

Issue	Possible Cause	Solution
Speaker does not power on	Low battery	Charge the speaker fully.
	Power button not pressed correctly	Press and hold the Power button for 3-5 seconds.
No sound	Volume too low	Increase the volume on both the speaker and your connected device.
	Not paired correctly	Re-pair the speaker with your device.
	Device not playing audio	Ensure your connected device is playing audio.
Bluetooth pairing fails	Speaker not in pairing mode	Ensure the speaker's LED is flashing, indicating pairing mode.
	Device Bluetooth off	Enable Bluetooth on your device.

Issue	Possible Cause	Solution
	Too far from device	Move the speaker closer to your device (within 10 meters/33 feet).
	Interference	Move away from other wireless devices.
Sound distortion	Volume too high	Reduce the volume on both the speaker and your connected device.
	Low battery	Charge the speaker.

8. Specifications

Feature	Detail
Model Name	XDOBO X8 IV
Speaker Type	Portable
Water Resistance Level	IPX7 Waterproof
Connectivity Technology	Bluetooth
Input Voltage	5 Volts
Recommended Uses	Indoor, Outdoor, Music
Compatible Devices	Smartphone
Surround Sound	360-degree Surround Sound
Product Dimensions	3.7"D x 8.87"W x 3"H
Item Weight	1 Kilogram (2.2 pounds)
Impedance	4 Ohms
Speaker Size	2.05 Inches
Power Source	Battery Powered
Woofer Diameter	3 Inches
Max Output Power	60 Watts
Frequency Response	32 Hz
Audio Output Mode	Stereo
Audio Driver Size	52 Millimeters
Batteries	1 Nonstandard Battery (included)

9. Warranty and Support

The xdobo X8 IV Portable Bluetooth Speaker comes with a standard manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please contact xdobo customer support through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.