Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Akko Dash Max

Akko Dash Max Wireless Gaming Mouse Instruction Manual

Model: Dash Max

1. Product Overview

The Akko Dash Max is an ultra-lightweight wireless gaming mouse designed for high-performance gaming. It features an 8K polling rate, a PAW3395 sensor with up to 26000 DPI, and durable Akko Custom Optical Switches. The mouse offers versatile connectivity options including Bluetooth, 2.4G wireless, and wired USB-C, making it suitable for various setups and preferences.



Image 1.1: The Akko Dash Max mouse, demonstrating its ultra-light 41g weight.

2. Setup Instructions

2.1 Package Contents

- Akko Dash Max Wireless Gaming Mouse
- USB-C to USB-A Cable
- 2.4G USB Receiver
- User Manual

2.2 Charging the Mouse

Connect the mouse to your computer using the provided USB-C cable. The mouse will charge automatically. A full charge

typically takes approximately 2-3 hours. The LED indicator on the mouse will show charging status.

2.3 Connectivity Modes

The Akko Dash Max supports three connectivity modes: 2.4G Wireless, Bluetooth, and Wired. Use the switch on the bottom of the mouse to select your desired mode.



Image 2.1: Connectivity options for the Akko Dash Max mouse.

2.3.1 2.4G Wireless Mode

1. Locate the 2.4G USB receiver. It may be stored in a compartment on the underside of the mouse.
2. Plug the 2.4G USB receiver into an available USB port on your computer.
3. Switch the mode selector on the bottom of the mouse to "2.4G".
4. The mouse should connect automatically.

2.3.2 Bluetooth Mode

1. Switch the mode selector on the bottom of the mouse to "BT".
2. On your computer, open Bluetooth settings and search for new devices.
3. Select "Akko Dash Max" from the list of available devices to pair.

2.3.3 Wired Mode

1. Connect the USB-C end of the cable to the mouse and the USB-A end to your computer.
2. The mouse will automatically switch to wired mode and begin charging.

3. Operating Instructions

3.1 DPI Adjustment

The Akko Dash Max features 8 adjustable DPI levels, allowing you to customize sensitivity for different tasks or games. The default DPI settings are 400, 800, 1200, 1600, 3200, 6400, 10000, and 26000. You can cycle through these settings using the dedicated DPI button, usually located behind the scroll wheel.



Image 3.1: Visual representation of adjustable DPI levels and polling rate.

3.2 Button Functions

The mouse is equipped with 7 programmable buttons:

- **Left Click:** Standard primary action.
- **Right Click:** Standard secondary action.
- **Scroll Wheel:** Scrolls up/down, and acts as a middle click button.
- **DPI Button:** Cycles through preset DPI levels.
- **Side Buttons (2):** Typically for forward/backward navigation in browsers or custom functions in games.

3.3 Software Customization

For advanced customization, including remapping buttons, creating macros, and fine-tuning DPI settings, download the Akko Gaming Hub software. This software is compatible with Windows operating systems. A web driver is also available for both Windows and Mac (Chrome browser only).

Your browser does not support the video tag.

Video 3.1: Official Akko video demonstrating the Akko Dash Wireless Mouse features and customization options.

4. Key Features

- **41g Ultra Lightweight:** Engineered for effortless control and faster movement, the lightweight build reduces fatigue and enhances precision, empowering users with greater speed and agility.
- **Akko Custom Optical Micro-switches:** Precisely tuned with a 150-million click lifespan for long-lasting durability and firm click. These switches offer exceptional precision stability combined with fast response times.
- **8 Adjustable DPI Levels:** Fine-tune sensitivity for different games and playstyles. Switch seamlessly between 400, 800, 1200, 1600, 3200, 6400, 10000, and 26000 DPI.
- **Optimized for Small to Medium Hands:** Ergonomically designed with a symmetrical shape for fingertip grip, palm grip, and claw grip. Compact dimensions (117.56 × 60.91 × 37.01mm) ensure a natural grip, balanced force distribution, smooth control, and long-lasting comfort.
- **Compatible with Driver:** Akko Gaming Hub supports Windows OS and offers extensive customization options, including DPI Setting, Parameter Setting, and Macro Setting. A web driver is available for Win & Mac (Chrome only).



Image 4.1: Ergonomic design supporting various grip styles.



Image 4.2: Detailed view of the PAW3395 sensor.



Image 4.3: Akko Custom Optical Switches for durability and response.

5. Maintenance

5.1 Cleaning

To maintain optimal performance and hygiene, regularly clean your mouse. Use a soft, dry, lint-free cloth to wipe the surface. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials.

5.2 Storage

When not in use, store the mouse in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the mouse is fully charged to preserve battery health.

5.3 Battery Care

To prolong the lifespan of the mouse's internal battery, avoid fully discharging it frequently. Charge the mouse when the battery indicator is low. If the mouse will not be used for a long time, charge it to about 50% before storage.

6. Troubleshooting

6.1 Mouse Not Responding

- **Check Battery:** Ensure the mouse is charged. Connect it via USB-C cable to charge.
- **Check Connectivity:** Verify the mode switch on the bottom of the mouse is set correctly (2.4G, BT, or Wired).
- **2.4G Wireless:** Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port.
- **Bluetooth:** Re-pair the mouse in your computer's Bluetooth settings. Ensure Bluetooth is enabled on your computer.
- **Wired:** Ensure the USB-C cable is securely connected to both the mouse and the computer. Try a different USB port or cable.

6.2 Erratic Tracking or Cursor Movement

- **Clean Sensor:** Dust or debris on the optical sensor can cause tracking issues. Clean the sensor area on the bottom of the mouse with a soft cloth.
- **Surface:** Ensure you are using the mouse on a suitable, non-reflective surface. A mouse pad is recommended.
- **DPI Setting:** Adjust the DPI setting to a level that feels comfortable and stable for your use.

6.3 Buttons Not Working

- **Software Conflict:** If you have custom software installed, try resetting button assignments to default within the Akko Gaming Hub.
- **Physical Obstruction:** Check for any physical obstructions preventing the button from clicking properly.

7. Specifications

Feature	Specification
Brand	Akko
Model	Dash Max
Color	Max White-Akko Custom Optical
Connectivity Technology	2.4G, Bluetooth, Wired
Movement Detection Technology	Optical (PAW3395 Sensor)
Button Quantity	7
Hand Orientation	Right
Compatible Devices	PCs

Power Source	Battery Powered
Mouse Maximum Sensitivity	26000 Dots per Inch (DPI)
Polling Rate	Up to 8000Hz
Weight	41g
Dimensions	117.56 × 60.91 × 37.01mm

8. Warranty and Support

8.1 Warranty Information

Akko products are covered by a limited warranty against manufacturing defects. Please refer to the warranty card included with your product or visit the official Akko website for detailed warranty terms and conditions specific to your region.

8.2 Customer Support

For technical assistance, troubleshooting, or any product-related inquiries, please visit the official Akko support website or contact their customer service team. Contact information can typically be found on the Akko website or in your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GHRJ5PQ5

More documents and user manuals: **https://manuals.plus/**