Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced VR763

RemotesReplaced Remote Control for Philips VR763

Model: VR763

Introduction

This manual provides instructions for the RemotesReplaced compatible remote control, designed for use with Philips VR763 devices. This replacement remote is electronically identical to the original and offers the same functionality. It does not require any setup codes; simply insert batteries to begin operation.

Product Overview

The RemotesReplaced VR763 remote control features a standard layout for easy navigation and control of your Philips VR763 device. Below are images illustrating the remote's design and key features.



Image 1: Front view of the RemotesReplaced VR763 remote control, showing all buttons and their labels. The remote is black with white and colored buttons.



Image 2: Left side profile of the remote control, illustrating its ergonomic curve.



Image 3: Right side profile of the remote control, showing the gradual slope of the design.



Image 4: Rear view of the remote control, displaying the battery compartment cover and regulatory markings.



Image 5: Top-front view of the remote control, highlighting the infrared emitter at the front.



Image 6: Bottom view of the remote control, showing the base and the battery compartment latch.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two new AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Initial Use

This RemotesReplaced remote control is pre-programmed for the Philips VR763 and does not require any additional setup codes. Once batteries are installed, point the remote control towards your Philips VR763 device and begin operation.

Operating Instructions

The remote control provides full functionality for your Philips VR763 device. Refer to the button layout for specific functions:

- **POWER:** Turns the device on or off.
- **MUTE:** Mutes or unmutes the audio.
- **TV** / **SAT** / **DVD** / **AUX:** Selects the input source.
- **MENU:** Accesses the main menu.
- **EXIT:** Exits the current menu or function.
- **SHIFT:** Used for accessing secondary functions of certain buttons (if applicable).
- **Number Buttons (0-9):** For direct channel selection or data entry.
- **SOURCE:** Cycles through available input sources.
- **-/--:** Toggles between single and double-digit channel entry.
- **GUIDE:** Displays the electronic program guide.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the channel up or down.
- **OK:** Confirms selections in menus.
- **Directional Arrows (Up, Down, Left, Right):** Navigates through menus and options.
- **BACK:** Returns to the previous screen or menu.
- **SLEEP:** Sets a sleep timer.
- **TV/DTV:** Switches between analog and digital television modes.
- **INFO:** Displays information about the current program or input.
- **EPG:** Electronic Program Guide.
- **FAV:** Accesses favorite channels.
- **NET TV** / **SMART:** Accesses smart TV features or internet applications.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.
- **Colored Buttons (Red, Green, Yellow, Blue):** Functions vary depending on the context or application.

Maintenance

Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using abrasive cleaners or solvents, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases. Always replace both batteries at the same time with new ones of the same type (AAA). Dispose of used batteries according to local regulations.

Troubleshooting

- **Remote not responding:**
  - Ensure the remote is pointed directly at the device's infrared receiver.
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote and the device.
- **Buttons are unresponsive:**
  - Clean the remote control, especially around the buttons, to remove any dirt or debris that might be causing sticking.
  - If only specific buttons are not working, it might indicate a fault with the remote.
- **Device not turning on/off:**
  - Verify that the device itself is powered and not in a standby mode that prevents remote activation.
  - Test the remote with another function to confirm it is generally working.

Specifications

Brand	RemotesReplaced
Model	VR763
Manufacturer	Linkwebb
Compatibility	Philips VR763
Batteries Required	2 x AAA (not included)
Setup	No setup code required
ASIN	B0GHS9XZCH

Warranty and Support

For any questions, issues, or support regarding your RemotesReplaced remote control, please contact RemotesReplaced directly. Information regarding specific warranty terms may be available through your point of purchase or on the RemotesReplaced official website.

RemotesReplaced has specialized in remote controls for over 20 years, ensuring a broad database of compatible remotes and dedicated customer assistance.

© 2026 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GHS9XZCH

More documents and user manuals: **https://manuals.plus/**