Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

deli PL5-BL

deli Electric Pencil Sharpener

Model: PL5-BL

Introduction

This manual provides instructions for the safe and efficient use of your deli Electric Pencil Sharpener. Please read this manual thoroughly before operation and retain it for future reference.

Safety Information

- Keep out of reach of small children.
- Do not insert fingers or foreign objects into the sharpening hole.
- Ensure the transparent container is properly closed before operation to prevent mess and ensure safe sharpening.
- Use only the specified battery type (2 AA batteries).
- Do not mix old and new batteries, or different types of batteries.
- Dispose of used batteries responsibly.

Package Contents

- 1 x deli Electric Pencil Sharpener (Model PL5-BL)
- *Note: 2 AA batteries are not included.*

Setup

1. **Battery Installation:**

   Locate the battery compartment on the bottom of the sharpener. Open the cover and insert 2 AA batteries, ensuring correct polarity (+/-). Close the battery compartment cover securely.



Figure 1: Battery installation in the deli Electric Pencil Sharpener.

2. **Placement:**

   Place the sharpener on a stable, flat surface. The anti-skid mats on the bottom will help keep it in place during use.



Figure 2: Anti-slip mats on the base of the sharpener.

Operating Instructions

1. **Insert Pencil:**

   Gently insert the pencil into the sharpening hole. The sharpener is designed for pencils with diameters between 6.5mm and 8.0mm, including standard No.2 pencils, colored pencils, and pencils with round, triangular, or hexagonal barrels.



Figure 3: Pencil compatibility and insertion point.

2. **Sharpening:**

   Press down lightly on the pencil. The sharpener will automatically begin sharpening. Maintain a light, consistent pressure. The sharpening process typically takes 3-5 seconds.



Figure 4: Sharpening a pencil with the electric sharpener.

3. **Remove Pencil:**

   Once the pencil is sharpened to a fine point, the motor will stop automatically, or you can remove the pencil when desired. Avoid over-sharpening to prevent excessive pencil waste.



Figure 5: Efficient sharpening to reduce waste.

Official Product Video

Your browser does not support the video tag.

Video 1: Demonstration of the deli Electric Pencil Sharpener's features and operation.

Maintenance

- **Emptying Shavings:**

  Regularly empty the transparent shaving container to prevent blockages and ensure optimal performance. To empty, gently pull the container away from the main body of the sharpener, dispose of shavings, and reattach securely.

- **Blade Durability:**

  The sharpener features a high-quality tungsten steel blade designed for long-lasting performance, capable of over 3000 sharpening cycles.



Figure 6: Tungsten steel blade for extended use.

- **Cleaning:**

  Wipe the exterior of the sharpener with a soft, dry cloth. Do not use abrasive cleaners or immerse the unit in water.

Troubleshooting

Problem	Possible Cause	Solution
Sharpener does not operate.	Batteries are dead or incorrectly installed. Shaving container is not properly closed.	Replace batteries or ensure correct polarity. Ensure the shaving container is securely attached.

Problem	Possible Cause	Solution
Pencil is not sharpening effectively.	Shaving container is full. Pencil diameter is outside the supported range (6.5mm-8.0mm). Blade is worn (unlikely due to tungsten steel, but possible after extensive use).	Empty the shaving container. Use pencils within the specified diameter range. Contact customer support if the blade appears dull after normal use.
Pencil lead breaks frequently.	Excessive pressure applied during sharpening. Pencil lead is of poor quality.	Apply lighter pressure. The sharpener requires minimal force. Try a different pencil to see if the issue persists.

Specifications

- **Brand:** deli
- **Model:** PL5-BL
- **Power Source:** 2 x AA Batteries (not included)
- **Pencil Diameter Compatibility:** 6.5mm - 8.0mm
- **Blade Material:** Tungsten Steel
- **Special Features:** Compact, Portable, One-press operation, Anti-skid mats, Transparent shaving container
- **Dimensions:** Approximately 3.0 inches (height) x 2.8 inches (width) x 1.8 inches (depth)



Figure 7: Compact size for portability.

Warranty and Support

For warranty information or technical support, please contact deli customer service through the retailer where the product was purchased or visit the official deli website.

Manufacturer: deli

Manufacturer Part Number: PL5-BL

ASIN: B0GJ92K5CG

© 2026 deli. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GJ92K5CG

More documents and user manuals: **https://manuals.plus/**