Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Benass B-JL-3x4-1

Benass Large Metal Chicken Coop

Model: B-JL-3x4-1

Instruction Manual

Introduction

Thank you for choosing the Benass Large Metal Chicken Coop. This manual provides essential information for the safe assembly, operation, and maintenance of your new poultry enclosure. Designed for durability and functionality, this coop offers a secure and spacious environment for your chickens and other small animals.

Please read these instructions thoroughly before beginning assembly to ensure proper setup and to maximize the lifespan of your product. Keep this manual for future reference.

Safety Information

- **Adult Assembly Required:** Assembly of this chicken coop requires at least two adults.
- **Wear Protective Gear:** Always wear gloves and eye protection during assembly to prevent injury from sharp edges or tools.
- **Secure Placement:** Choose a level, stable outdoor surface for installation. Ensure the coop is securely anchored to the ground to prevent tipping in strong winds.
- **Inspect Components:** Before assembly, check all parts for damage. Do not proceed with assembly if any critical components are bent or broken. Contact customer service for replacements.
- **Child Safety:** Keep children away from the assembly area. Do not allow children to play inside or around the coop unsupervised.
- **Animal Safety:** Regularly inspect the coop for any potential hazards to your animals, such as sharp wire edges or loose components.

Package Contents

Verify that all components listed below are present and undamaged before starting assembly. If any parts are missing or damaged, please contact Benass customer support.

- Galvanized Steel Frame Components (1" diameter)
- PVC Coated Chicken Wire (39.3" x 118' roll)
- 2 x PE&UV Double-Sided Coated Covers (120gms)
- 1 x Roosting Ladder
- 30 x Bungee Balls
- 400 x Detachable Zip Ties
- Reinforcement Bars for corners
- Assembly Hardware (bolts, nuts, connectors)



Figure 1: All accessories included with the Benass chicken coop, such as bungee balls, wire fencing mesh, detachable zip ties, PE&UV coated cover, and chicken roosting ladder.

Setup and Assembly

Assembly typically requires two people and can take several hours. Follow the steps below carefully.

1. **Frame Assembly:** Connect the galvanized steel pipes according to the provided diagrams to form the main structure of the coop. Ensure all connections are secure.
2. **Door Installation:** Attach the split door frame to the main structure. Ensure the hinges allow for smooth operation.
3. **Wire Mesh Installation:** Unroll the PVC coated chicken wire. Securely attach the wire mesh to the frame using the provided detachable zip ties. Ensure the mesh is taut and covers all open sides of the coop to prevent escape and deter predators. You may need to cut notches in the wire for door latches.

4. **Roosting Ladder Placement:** Install the roosting ladder inside the coop at a suitable height for your poultry.
5. **Cover Attachment:** Drape the PE&UV coated covers over the roof frame. Secure them using the bungee balls, ensuring they are taut to prevent water pooling and provide maximum UV protection.
6. **Final Inspection:** Double-check all connections, wire mesh, and cover attachments for security and stability.



Figure 2: Product dimensions including overall size (157"L x 117.6"W x 78.72"H), door size (23.6"W x 63"H), wire mesh size (39.3" x 118ft), and cover area (129 sq ft).



Figure 3: An assembled Benass chicken coop providing a spacious outdoor run for poultry.

Operating Instructions

- **Split Door Access:** The coop features a split door design with 3 U-shaped locks. You can open the entire door or just the upper or lower section independently for feeding, watering, or accessing your poultry.
- **Cover Adjustment:** The two included covers can be used together for maximum protection or individually depending on weather conditions. Secure them firmly with bungee balls to prevent wind damage.



Figure 4: The unique two-door design allows for easier feeding and access to the coop.



Figure 5: The PE&UV double-sided coating cover provides protection from rain and sun, keeping poultry comfortable.

Maintenance

- **Regular Cleaning:** Clean the coop regularly to maintain a hygienic environment for your poultry. The galvanized frame and PVC coated wire can be wiped down with water.
- **Cover Care:** The PE&UV coated covers can be cleaned with mild soap and water. Ensure they are dry before storing if removed for extended periods.
- **Structural Inspection:** Periodically check all frame connections, zip ties, and bungee balls for tightness and wear. Replace any worn or damaged components promptly to maintain structural integrity and security.
- **Ground Anchoring:** Re-check ground anchors periodically, especially after heavy winds or rain, to ensure the coop remains stable.

Troubleshooting

- **Bent Bars/Missing Parts:** If you receive bent bars or discover missing parts during assembly, contact Benass customer service immediately for replacements. Do not attempt to force bent parts into place.

- **Difficulty with Wire Mesh:** Installing the chicken wire can be a two-person job. Ensure you measure and cut carefully, leaving enough material to secure it tightly to the frame. Detachable zip ties allow for adjustments.
- **Door Security:** If the door latches feel insecure, ensure the chicken wire is cut appropriately around the latch mechanism and that the U-shaped locks are fully engaged.
- **Cover Sagging:** If covers sag, re-tighten the bungee balls. Ensure the covers are evenly distributed and taut across the roof frame.

Specifications

Feature	Detail
Model Number	B-JL-3x4-1
Overall Dimensions (L x W x H)	157.48" x 118.1" x 78.74" (approx. 13.1' x 9.8' x 6.56')
Door Dimensions (H x W)	63" x 23.6" (approx. 5.25' x 2')
Frame Material	1" Galvanized Steel
Wire Mesh Material	1mm PVC Coated Steel Wire
Cover Material	120gms PE&UV Double-Sided Coated Polyester
Capacity	Accommodates 10-20 chickens
Special Features	Split Doors with U-shaped locks, Roosting Perch, Waterproof & UV-resistant Cover, Reinforced Corners

Warranty and Support

Benass provides customer support for product inquiries, missing parts, or warranty claims. For assistance, please contact Benass-US directly through your purchase platform or their official website. Please have your model number (B-JL-3x4-1) and purchase information ready when contacting support.

© 2026 Benass. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GKD4D4W7

More documents and user manuals: **https://manuals.plus/**