Nordivale H21430-70BRBK-1

Nordivale 70-inch Fireplace TV Stand

Model: H21430-70BRBK-1

Walnut & Black Finish

Safety | Overview | Assembly | Operation | Maintenance & Support | Troubleshooting | Specifications | Warranty

1. Important Safety Information

Please read and understand all instructions before assembling and using this product. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

- Keep all packaging materials away from children.
- Do not operate the fireplace if the cord is damaged or if the unit malfunctions.
- Ensure the power outlet meets the electrical requirements of the fireplace.
- Do not overload electrical circuits.
- Keep combustible materials at least 3 feet (0.9 meters) away from the front of the fireplace.
- Always unplug the fireplace before cleaning or performing maintenance.
- This product is intended for indoor use only.

2. Product Overview

The Nordivale 70-inch Fireplace TV Stand is a versatile entertainment center designed to accommodate TVs up to 80 inches. It features an integrated 36-inch electric fireplace with adjustable flame colors and heating capabilities, along with ample storage space.



Image: Fully assembled Nordivale 70-inch Fireplace TV Stand with a television on top, showcasing its design and integrated fireplace.

Key Features:

- **Electric Fireplace:** 36-inch unit with realistic crystal stones, 12 flame colors, and 5 levels of brightness.
- **Heating Function:** Adjustable temperature from 60°F to 99°F and a timer from 0 to 9 hours.
- **Storage:** Features both open and closed cabinets, including two glass-door cabinets with LED light strips.
- **Cable Management:** Integrated cable holes for organized wiring.
- **Design:** Farmhouse style with a walnut and black finish, suitable for various living room decors.



Image: Detailed view of the TV stand's features, including an elegant handle, large cable holes for wire management, and open storage compartments.

3. Assembly Instructions

This TV stand requires assembly. It is recommended to have two adults for assembly. Please ensure all parts are present before beginning. The product typically ships in two separate boxes, which may arrive on different days.

General Steps:

1. Unpack all components and hardware. Verify against the parts list in the included assembly manual.
2. Follow the step-by-step diagrams and instructions provided in the separate assembly manual.
3. Assemble the main frame of the TV stand.
4. Install the electric fireplace insert into the designated opening.
5. Attach the cabinet doors and shelves.

6. Connect the LED light strips in the glass-door cabinets.

For detailed assembly instructions, please refer to the dedicated assembly manual included with your product.



Image: Illustration depicting the product being delivered in two separate boxes, which may arrive on different days.

4. Operating Instructions

The electric fireplace and LED lights can be controlled using the included remote control or the control panel on the fireplace unit.

4.1 Electric Fireplace

- **Power On/Off:** Press the power button on the remote or control panel to turn the fireplace on or off.
- **Flame Colors:** Cycle through 12 different flame colors by pressing the flame color button.
- **Flame Brightness:** Adjust the flame brightness through 5 levels using the brightness control.



Image: Visual representation of the 36-inch electric fireplace, highlighting the 12 available flame colors and 5 levels of brightness.

4.2 Heater Function

- **Temperature Control:** Adjust the temperature from 60°F to 99°F using the temperature buttons on the remote or control panel.
- **Timer Setting:** Set the operating time from 0 to 9 hours. The fireplace will automatically turn off after the set time.
- **Overheat Protection:** The fireplace is equipped with overheat protection for safety. If the unit overheats, it will automatically shut off.



Image: Diagram illustrating the heater control features, including temperature adjustment, timer settings, and flame brightness control, accessible via the remote and unit buttons.

4.3 LED Light Strips

- The glass-door cabinets feature integrated LED light strips. These lights can be adjusted to 12 different colors to create various ambiances.
- Refer to the remote control instructions for changing the LED light colors.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your TV stand and electric fireplace.

- **Cleaning the Wood Surface:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.

- **Cleaning the Fireplace:** Ensure the fireplace is unplugged and cool before cleaning. Use a soft, dry cloth to wipe the glass and exterior. Do not use abrasive cleaners on the glass.
- **Dusting:** Regularly dust all surfaces, including the interior of the cabinets and the fireplace vents, to prevent dust buildup.
- **Cord Care:** Periodically inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.

6. Troubleshooting

If you encounter any issues with your Nordivale Fireplace TV Stand, please refer to the following common solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord not fully plugged in, circuit breaker tripped.	Check power connection, ensure outlet is functional, reset circuit breaker.
Heater not producing heat.	Temperature setting too low, timer activated, overheat protection engaged.	Increase temperature setting, check timer, allow unit to cool down if overheated.
Remote control not working.	Dead batteries, obstruction between remote and fireplace.	Replace batteries, ensure clear line of sight to the fireplace sensor.
LED cabinet lights not working.	Loose connection, power issue.	Check all connections for the LED strips, ensure the main unit has power.

7. Specifications

- **Brand:** Nordivale
- **Model Number:** H21430-70BRBK-1
- **Color:** Walnut & Black
- **Size:** 70 IN
- **Item Dimensions (L x W x H):** 70 x 14.2 x 33.5 inches
- **Item Weight:** 113 Pounds
- **Material Type:** Wood
- **Style:** Farmhouse
- **TV Stand Weight Capacity (Tabletop):** 150 LBS
- **Shelf Weight Capacity:** 33 LBS
- **Middle Wood Weight Capacity:** 44 LBS
- **Fireplace Size:** 36 inches
- **Additional Features:** Adjustable Flame, Multicolor Flame, Overheat Protection, TV Stand
- **Required Assembly:** Yes

Product Size

TV Stand: 70"L×14.2"W× 33.5"H

Fireplace: 36"L×23.2"W× 18.3"H

Tabletop Weight Capacity: 150 LBS

Shelf Weight Capacity: 33 LBS

Middle Wood Weight Capacity: 44 LBS



Image: Detailed diagram showing the dimensions of the TV stand and fireplace, along with the weight capacities for the tabletop, shelves, and middle wood section.



Image: The TV stand displayed with various TV sizes (50, 60, 70, 80 inches) to illustrate its compatibility with televisions up to 80 inches.

8. Warranty and Support

For warranty information, technical support, or replacement parts, please contact Nordivale customer service. Refer to your purchase documentation for specific contact details.

Please retain your proof of purchase for warranty claims.

© 2026 Nordivale. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question