Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CYBPOK PT6-8-P1

CYBPOK 2-Gallon Battery Powered Garden Sprayer PT6-8-P1 Instruction Manual

Model: PT6-8-P1

1. Introduction

Thank you for choosing the CYBPOK 2-Gallon Battery Powered Garden Sprayer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new sprayer. Please read this manual thoroughly before initial use and retain it for future reference.

1.1 Safety Information

> **WARNING:** Always wear appropriate protective clothing and eye/hand protection when using this product. Keep the product away from heat sources and do not store it in direct sunlight. Do not use this product with chemicals that are not intended for use with plastic containers. Always follow the manufacturer's instructions for the specific chemical being used. After use, clean the product thoroughly and dispose of it responsibly according to local regulations.

2. Product Components

Familiarize yourself with the parts of your CYBPOK 2-Gallon Battery Powered Garden Sprayer:

- **Sprayer Tank:** 2-gallon capacity for liquid solutions.
- **USB Rechargeable Handle:** Contains the battery and power button.
- **Retractable Wand:** Extends for reaching various areas.
- **Nozzles (4 Mist Nozzles):** Interchangeable nozzles for different spray patterns.
- **Adjustable Shoulder Strap:** For comfortable carrying.
- **USB Charging Cable:** For recharging the handle's battery.



Figure 2.1: Overview of the CYBPOK 2-Gallon Battery Powered Garden Sprayer, showing the main tank, handle, wand, and strap.

3. Setup

3.1 Charging the Battery

1. Locate the USB charging port on the sprayer handle.
2. Connect the provided USB charging cable to the handle and to a compatible USB power adapter (not included).
3. The indicator light on the handle will illuminate during charging and change color or turn off when fully charged.
4. Allow approximately 2-3 hours for a full charge before first use.



Figure 3.1: The sprayer handle with the USB charging port highlighted for battery charging.

3.2 Assembling the Sprayer

1. Attach the retractable wand to the sprayer handle by screwing it securely into place.
2. Select the desired nozzle from the four mist nozzles provided and attach it to the end of the wand. Ensure it is finger-tight.
3. Attach the adjustable shoulder strap to the designated attachment points on the sprayer tank. Adjust the strap length for comfortable carrying.



Figure 3.2: Illustration of attaching the wand and nozzle to the sprayer handle.

4. Operation

4.1 Filling the Tank

1. Unscrew the top cap of the sprayer tank.
2. Carefully pour your desired liquid solution into the tank, ensuring not to exceed the 2-gallon maximum fill line.
3. Securely screw the top cap back onto the tank to prevent leaks.



Figure 4.1: Demonstrating the proper method for filling the sprayer tank with liquid.

4.2 Spraying

1. Press and hold the power button on the handle to activate the pump. The sprayer will begin to dispense liquid.
2. Release the power button to stop spraying.
3. Adjust the retractable wand to the desired length for optimal reach.
4. Rotate the attached nozzle to change the spray pattern (if applicable to the selected nozzle).



Figure 4.2: A user demonstrating the operation of the sprayer, showing the extended wand and spray action.

4.3 Nozzle Selection

The sprayer comes with 4 mist nozzles, each designed for different applications:

- **Fine Mist Nozzle:** Ideal for delicate plants, herbicides, or insecticides requiring broad, even coverage.
- **Coarse Mist Nozzle:** Suitable for general watering or applying fertilizers.
- **Stream Nozzle:** For targeted application or reaching higher areas.
- **Fan Nozzle:** Provides a wide, flat spray pattern for efficient coverage of larger surfaces.

5. Maintenance

5.1 Cleaning After Use

1. Empty any remaining liquid from the tank.
2. Fill the tank with clean water and spray until the tank is empty to flush out the pump and wand. Repeat this process

2-3 times.

3. Rinse the exterior of the sprayer with clean water and wipe dry with a soft cloth.
4. Clean nozzles regularly to prevent clogging. Detach them and rinse under running water. Use a small brush if necessary.



Figure 5.1: Illustrating the process of flushing the sprayer with clean water for post-use cleaning.

5.2 Storage

- Store the sprayer in a cool, dry place, away from direct sunlight and extreme temperatures.
- Ensure the tank is empty and clean before storage.
- Store with the cap slightly loosened to allow air circulation and prevent pressure buildup.
- Charge the battery periodically (every 3-6 months) if storing for extended periods to maintain battery health.

6. Troubleshooting

Problem	Possible Cause	Solution
Sprayer not turning on.	Battery is discharged.	Charge the battery using the provided USB cable.
No spray or weak spray.	Tank is empty. Nozzle is clogged. Wand connection is loose. Battery is low.	Refill the tank. Clean the nozzle. Tighten the wand connection. Charge the battery.
Leaking from connections.	Loose connections or damaged O-rings.	Ensure all connections are tight. Check O-rings for damage and replace if necessary.

7. Specifications

Feature	Detail
Brand	CYBPOK
Model Name	PT6-8-P1
Tank Volume	2 Gallons
Power Source	Battery Powered (USB Rechargeable)
Material	Plastic
Included Components	Nozzle, Shoulder Strap
Item Dimensions (W x H)	12"W x 6.3"H
UPC	708451441426

8. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official CYBPOK website. Keep your proof of purchase for warranty claims.

© 2023 CYBPOK. All rights reserved. This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GLPCLH5Y

More documents and user manuals: **https://manuals.plus/**