GIANTEX GX11068US-BL-PF

Giantex Portable Washing Machine 18LBS Twin Tub - Instruction Manual

Model: GX11068US-BL-PF

1. Introduction and Overview

This manual provides essential information for the safe and efficient operation of your Giantex 18LBS Twin Tub Portable Washing Machine. This compact appliance features a powerful washer and spin dryer, designed for convenience in small living spaces such as apartments, dorms, and RVs.

The machine includes an 11 lbs wash tub and a 7 lbs spin tub, allowing for simultaneous washing and spinning. Key features include a built-in drain pump, a spray function in the spin tub for residue removal, and user-friendly controls for customizable wash cycles.



Image 1.1: The Giantex 18LBS Twin Tub Portable Washing Machine in Blue+White.



Image 1.2: Illustration of the wash tub (11 lbs capacity) and spin tub (7 lbs capacity).

2. Safety Information

- Read all instructions before using the appliance.
- Ensure the power supply matches the voltage specified on the machine's rating label.
- Do not immerse the electrical cord, plug, or the appliance in water or other liquids.
- Keep children away from the appliance during operation.
- Unplug the machine from the power outlet when not in use or before cleaning.
- Do not operate the machine with a damaged cord or plug.
- Place the machine on a stable, level surface to prevent vibration and noise.
- Do not wash waterproof materials or items that float easily, as this may cause imbalance.
- Avoid placing the machine in a bathtub or directly under a shower to prevent moisture damage to the motor.

3. Product Components

The package includes the following items:

- 1 x Portable Washing Machine

- 1 x Inlet Hose Kit
- 1 x Spin Tub Safety Cover
- 1 x User Manual (this document)

The machine features a see-through acrylic lid, hidden control knobs, a detachable lint filter, convenient side handles, and a cable management system.



Image 3.1: Detailed view of the machine's user-friendly components.

4. Setup

4.1 Placement

Choose a stable, level surface for the washing machine. Ensure there is enough space around the unit for proper ventilation and access. The compact design makes it suitable for various locations.



Image 4.1: Examples of suitable placement locations for the portable washing machine.

4.2 Water Inlet Connection

Connect the inlet hose to a water faucet. The inlet hose kit includes an adjustable metal clip to adapt to various faucet types. Insert the other end of the hose into the water inlet port located on the top of the washing machine.

4.3 Drain Hose Positioning

Position the drain hose into a sink, bathtub, or other suitable drainage area. The built-in drain pump can handle drainage up to 39 inches in height. Ensure the drain hose is securely placed to prevent water spillage.

5. Operating Instructions

The machine features three simple control knobs located under the lid for easy operation.



Image 5.1: The hidden control knobs for customizing wash cycles.

5.1 Washing Clothes

1. **Load Clothes:** Open the wash tub lid and place clothes loosely into the wash tub. Do not overload the machine beyond its 11 lbs capacity.
2. **Add Water and Detergent:** Fill the wash tub with water to the desired level. Add an appropriate amount of detergent.
3. **Set Wash Timer:** Turn the 'Wash Timer' knob to select the desired wash duration (0-15 minutes).
4. **Select Wash Mode:** Turn the 'Mode Selector' knob to choose between 'Gentle', 'Normal', or 'Drain'.
5. **Start Washing:** The machine will begin washing automatically once the timer is set.
6. **Drain Water:** After the wash cycle, set the 'Mode Selector' to 'Drain' to empty the water from the wash tub.

5.2 Rinsing Clothes

1. **Refill Water:** After draining, refill the wash tub with clean water.
2. **Rinse Cycle:** Set the 'Wash Timer' for 3-5 minutes for rinsing. You may add fabric softener if desired.
3. **Drain Water:** After rinsing, set the 'Mode Selector' to 'Drain' again.

5.3 Spinning Clothes

1. **Transfer Clothes:** Carefully transfer the washed and rinsed clothes from the wash tub to the spin tub.

Ensure the clothes are evenly distributed. Do not exceed the 7 lbs spin capacity.

2. **Place Safety Cover:** Put the spin tub safety cover over the clothes in the spin tub.
3. **Set Spin Timer:** Turn the 'Spin Timer' knob to select the desired spin duration (0-5 minutes).
4. **Start Spinning:** The spin cycle will begin. The spin tub features a spray function to help remove foam residue.
5. **Remove Clothes:** Once the spin cycle is complete, remove the clothes. They will be damp but not dripping wet.

6. Maintenance

6.1 Cleaning the Lint Filter

The machine is equipped with a detachable lint filter. Regularly remove and clean the lint filter to ensure efficient operation and prevent lint buildup on clothes. Rinse it under running water to remove collected lint.

6.2 Cleaning the Machine

Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents. For the interior, periodically run a wash cycle with just water and a small amount of white vinegar to clean and deodorize the tubs.

6.3 Storage

When not in use, ensure the machine is unplugged and completely dry. Store it in a cool, dry place. Utilize the cable management system to keep the power cord tidy.

7. Troubleshooting

Problem	Possible Cause	Solution
Machine does not start	Not plugged in; Power outage; Timer not set.	Check power connection; Verify power supply; Set wash/spin timer.
Water does not drain	Drain hose is kinked or blocked; Drain mode not selected.	Straighten drain hose; Clear any blockages; Set 'Mode Selector' to 'Drain'.
Excessive vibration or noise	Machine is not on a level surface; Clothes are unevenly distributed in spin tub.	Adjust machine to a level surface; Redistribute clothes evenly in the spin tub.
Spin tub not spinning effectively	Overloaded spin tub; Safety cover not properly placed.	Reduce load in spin tub; Ensure safety cover is securely in place.

8. Specifications

Feature	Detail
Model Number	GX11068US-BL-PF
Overall Dimensions (L x W x H)	22.5" x 14" x 25.5"

Feature	Detail
Wash Capacity	11 lbs
Spin Capacity	7 lbs
Wash Motor Power	240W
Spin Motor Power	140W
Net Weight	25 lbs
Material	PP, Acrylic, PE, EVA, Metal
Drain Hose Length	3.3 ft
Inlet Hose Length	4 ft
Max Pump Drain Height	39 inches
Operation Mode	Semi-Automatic
Number of Standard Cycles	3 (Gentle, Normal, Drain)



Image 8.1: Detailed dimensions of the portable washing machine.

9. Warranty and Support

This product comes with a**3-month warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For technical support, warranty claims, or any questions regarding the operation or maintenance of your Giantex Portable Washing Machine, please refer to the contact information provided with your purchase documentation or visit the official Giantex website.