Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cosori CAF-TF901

Cosori TWINFRY 9 QT Double Air Fryer Instruction Manual

Model: CAF-TF901-KUS

Important Safety Information

Please read all instructions carefully before using your Cosori TWINFRY 9 QT Double Air Fryer. Failure to follow these instructions may result in damage to the product, property damage, or personal injury.

- Always place the air fryer on a stable, heat-resistant surface, away from walls and other appliances to ensure proper ventilation.
- Do not immerse the air fryer's main unit, cord, or plug in water or other liquids.
- Keep children and pets away from the air fryer during operation.
- Do not block any ventilation openings.
- Unplug the air fryer when not in use and before cleaning. Allow it to cool completely before handling.
- Do not operate the air fryer if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Avoid using metal utensils inside the basket to prevent damage to the nonstick coating.
- Exercise extreme caution when removing the basket or divider, as hot steam may escape.

Package Contents

Upon unpacking, ensure all items listed below are present and in good condition:

- 1 x Cosori TWINFRY 9.0-Quart Air Fryer
- 1 x Basket Divider
- 2 x Crisper Plates
- 1 x Quick Start Guide
- 1 x Recipe Book
- 1 x User Manual (this document)

Product Overview

The Cosori TWINFRY 9 QT Double Air Fryer offers versatile cooking options with its innovative design. It features a removable divider, allowing you to switch between two independent 4.5-quart baskets or a single, spacious 9-quart basket. This flexibility enables simultaneous cooking of different foods or preparation of large family meals. The baskets and crisper plates are coated with a durable, PFAS-free ceramic nonstick material for easy cleaning and high-heat resistance.



Image: The Cosori TWINFRY 9 QT Double Air Fryer demonstrating its dual basket configuration on the left, cooking salmon and asparagus, and its single large basket configuration on the right, cooking a whole chicken. Below, the removable basket divider is shown being inserted and removed.

Components

Familiarize yourself with the main components of your air fryer:

- **Main Unit:** Houses the heating element, fan, and control panel.
- **Cooking Basket:** The primary cooking chamber, designed to hold food.
- **Basket Divider:** Divides the main cooking basket into two separate zones.
- **Crisper Plates:** Inserted into the basket to allow air circulation around food for crisping.
- **Control Panel:** Digital display and touch controls for settings.



Image: A close-up view of the air fryer's basket, two crisper plates, and the basket divider, emphasizing their PFAS-free and ceramic-coated surfaces for easy cleaning and durability.

Setup and First Use

Before First Use

1. Remove all packaging materials, including any temporary stickers or labels.
2. Wipe down the exterior of the air fryer with a damp cloth.
3. Wash the cooking basket, crisper plates, and basket divider with warm, soapy water. Rinse thoroughly and dry completely.
4. Place the air fryer on a flat, stable, heat-resistant surface, ensuring at least 5 inches (13 cm) of space behind and above the unit for proper air circulation.

Initial Operation (Burn-in)

To eliminate any manufacturing odors, it is recommended to run the air fryer empty once:

1. Insert the crisper plates into the basket. You may use the divider or not.
2. Plug in the air fryer.
3. Set the temperature to 350°F (175°C) and the time to 15 minutes.
4. Press Start.
5. Once complete, allow the air fryer to cool down completely before using it for cooking.

Operating Instructions

Control Panel Overview

The digital control panel allows you to select cooking functions, adjust time and temperature, and utilize special features like Sync and Match.

Using the Basket Divider

The removable divider offers flexibility for different meal sizes:

- **Dual 4.5 Qt Baskets:** Insert the divider into the main basket to create two separate cooking zones. This is ideal for cooking a main dish and a side simultaneously.
- **Full 9 Qt Basket:** Remove the divider to utilize the entire 9-quart capacity. Perfect for larger items like a whole chicken or multiple servings of a single dish.



Image: The Cosori TWINFRY air fryer with the basket divider inserted, showing brussels sprouts in one compartment and shrimp with lemon in the other, demonstrating simultaneous cooking of two different foods.



Image: A user removing the basket divider from the Cosori TWINFRY air fryer to create a single large 9-quart cooking space, which is then shown accommodating a large casserole dish, suitable for family-sized meals.

Cooking Functions and Settings

The air fryer offers 6 preset cooking functions:

- **Air Fry:** For crispy results with minimal oil.
- **Roast:** Ideal for meats and vegetables.
- **Bake:** For cakes, pastries, and other baked goods.
- **Broil:** For quick browning and searing.
- **Reheat:** To warm up leftovers.
- **Dry:** For dehydrating fruits or making jerky.

The temperature range is from 95°F to 465°F (35°C to 240°C), allowing for precise cooking control.



Image: The control panel of the Cosori TWINFRY air fryer showing temperature settings for different functions: Dry at 95°F, Air Fry at 385°F, and Broil at 465°F, with corresponding food examples like dried fruit, fries, and steak.

Sync and Match Functions

- **Sync:** Allows you to cook two different foods in separate baskets with different settings, ensuring they finish cooking at the same time.



Image: The Cosori TWINFRY air fryer's control panel and baskets illustrating the 'Sync' function. One basket is set to 'Roast 8 Mins' and the other to 'Air Fry 15 Mins', both programmed to finish simultaneously, with chicken and brussels sprouts cooking.

- **Match:** Mirrors the cooking settings (time and temperature) from one basket to the other, ideal for cooking larger quantities of the same food.



Image: The Cosori TWINFRY air fryer's control panel and baskets illustrating the 'Match' function. Both baskets are set to 'Roast 22 Mins', with chicken wings in both, indicating mirrored settings for cooking the same food in larger quantities.

Cleaning and Maintenance

Proper cleaning and maintenance ensure the longevity and optimal performance of your air fryer.

Cleaning the Basket and Crisper Plates

- Always unplug the air fryer and allow it to cool completely before cleaning.
- The cooking basket, crisper plates, and basket divider are **dishwasher-safe** for convenient cleaning.
- For hand washing, use warm, soapy water and a non-abrasive sponge. Avoid metal scouring pads or harsh detergents that can damage the PFAS-free ceramic nonstick coating.
- For stubborn food residue, soak the basket and plates in warm, soapy water for 15–20 minutes before cleaning.



Image: The top part of the image shows the Cosori TWINFRY air fryer basket and crisper plate inside a dishwasher rack, indicating they are dishwasher-safe. The bottom part shows a hand washing a crisper plate under running water in a sink.

Cleaning the Main Unit

- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners.
- Clean the interior of the air fryer with a damp cloth and mild soap if necessary. Avoid getting water into the electrical components.

Troubleshooting

If you encounter any issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; unit not properly assembled.	Ensure the power cord is securely plugged into a working outlet. Check if the basket is fully inserted.
Food is not cooked evenly.	Overcrowding the basket; insufficient shaking/flipping.	Do not overcrowd the basket. Shake or flip food halfway through cooking for even results.
White smoke coming from the air fryer.	Grease residue from previous use; high-fat food cooking.	Clean the basket and crisper plates thoroughly after each use. For high-fat foods, drain excess oil.
Air fryer smells like plastic.	New unit odor.	This is normal for first few uses. Run the air fryer empty as described in 'Initial Operation' section.

Specifications

Specification	Detail
Model Name	CAF-TF901
Model Number	CAF-TF901-KUS
Capacity	9 Quarts (Dual 4.5 Qt or Single 9 Qt)
Product Dimensions (D x W x H)	19" x 11.1" x 11.9"
Item Weight	17.2 pounds
Power Supply	120V, 60Hz
Rated Power	1750W
Temperature Range	95°F – 465°F (35°C – 240°C)
Control Method	Push Button
Material	Ceramic (PFAS-Free Coating)
Special Features	Automatic Shut-Off, Dual Zone Features, Sync & Match Functions, Temperature Control



Image: The Cosori TWINFRY air fryer positioned on a kitchen countertop, with labels indicating its dimensions: 19 inches (L), 11.9 inches (W), and 11.1 inches (H), demonstrating its compact footprint.

Warranty and Support

Warranty Information

This Cosori TWINFRY 9 QT Double Air Fryer is covered by a**2-year warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
The warranty does not cover:

- Damage due to accident, misuse, abuse, or improper operation.
- Damage caused by unauthorized repairs or modifications.
- Normal wear and tear.

Customer Support

For any questions, concerns, or issues regarding your product, please contact Cosori Customer Support. Have your order number and model number (CAF-TF901-KUS) ready when contacting support.
You can find contact information on the official Cosori website or through your purchase platform.

© 2026 Cosori. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GLX9TGJV

More documents and user manuals: **https://manuals.plus/**