Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PMXEA7ABK825VG83RBDA

Generic Ultrasonic Skin Scrubber

MODEL: PMXEA7ABK825VG83RBDA

1. Introduction

The Generic Ultrasonic Skin Scrubber is a versatile facial care tool designed to enhance your skincare routine. Utilizing ultrasonic technology, this rechargeable device offers four distinct modes to address various skin concerns, from deep cleansing to promoting nutrient absorption. Its compact and portable design makes it suitable for both home use and travel.

This manual provides essential information on how to safely and effectively use, maintain, and troubleshoot your ultrasonic skin scrubber.

2. Safety Precautions

- Do not use the device on damaged, irritated, or broken skin.
- Avoid using the device on areas with skin conditions such as severe acne, eczema, or psoriasis without consulting a dermatologist.
- Keep the device away from children.
- Do not immerse the entire device in water, despite its waterproof features. The charging port should remain dry.
- Discontinue use if you experience any discomfort or adverse reactions.
- Ensure the device is fully charged before first use.

3. Product Overview

The Ultrasonic Skin Scrubber features an ergonomic design with a stainless steel spatula head and intuitive controls.

Key Features:

- **4 Operating Modes:** Sonic, EMS, Ion-, Ion+ for comprehensive skincare.
- **Ultrasonic Vibration:** Gently cleanses and exfoliates the skin.
- **Rechargeable:** Cordless operation with extended battery life.
- **Waterproof Design:** Allows for convenient use in various settings.
- **Compact and Portable:** Ideal for home use and travel.



A user demonstrating the application of the ultrasonic skin scrubber on the cheek area, highlighting its ergonomic design and ease of use for facial care.

4. Getting Started (Setup)

4.1 Charging the Device

1. Before first use, fully charge the device.
2. Connect the charging cable to the device's charging port and a suitable USB power adapter.
3. The charging indicator light will illuminate during charging and typically turn off or change color when fully charged.
4. A full charge provides approximately two weeks of battery life, depending on usage.

4.2 Initial Preparation

- Cleanse your face thoroughly before using the device.
- Ensure your skin is damp or wet. The device works best on moist skin, often with water, toner, or a mild facial

cleanser.

5. Operating Instructions

The device features four distinct modes to cater to different skincare needs. Press the power button to turn on the device and cycle through the modes.



An infographic explaining the four distinct operating modes of the ultrasonic skin scrubber: Sonic for deep cleaning, EMS for collagen stimulation, Ion- for pore cleansing, and Ion+ for enhanced essence absorption.

5.1 Mode Descriptions

1. **Sonic Mode (Deep Cleaning):** This mode uses high-frequency ultrasonic vibrations to deeply cleanse the skin, helping to remove dirt, oil, and blackheads from pores.
2. **EMS Mode (Lifting & Firming):** Electrical Muscle Stimulation (EMS) gently stimulates facial muscles, promoting collagen production and helping to lift and firm the skin.

3. **Ion- Mode (Pore Cleansing):** This mode utilizes negative ions to draw out impurities and deeply cleanse pores, reducing blockages.
4. **Ion+ Mode (Nutrient Absorption):** This mode uses positive ions to help skincare products penetrate deeper into the skin, enhancing the absorption of essences and serums.

5.2 Usage Guide

- **For Cleansing (Sonic/Ion- Modes):** Hold the device with the spatula head angled downwards, gently gliding it across your damp face. Move from the center of your face outwards, focusing on areas with blackheads or clogged pores.
- **For Absorption (Ion+ Mode):** Apply your preferred serum or essence. Hold the device with the spatula head angled upwards, gently gliding it over your face to help the product absorb.
- **For Lifting (EMS Mode):** Apply a conductive gel or serum. Hold the device with the spatula head flat against the skin, gently moving it upwards and outwards to lift and tone.
- Use each mode for approximately 3-5 minutes per session, 2-3 times a week, or as recommended by a skincare professional.



The ultrasonic skin scrubber applied to the nose, demonstrating its capability to address specific concerns like blackheads and clogged pores.

6. Care and Maintenance

6.1 Cleaning the Device

- After each use, wipe the spatula head with a soft, damp cloth or an alcohol wipe.
- Do not use abrasive cleaners or brushes that could scratch the spatula.
- Ensure the device is completely dry before storing or recharging.

6.2 Storage

- Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- Keep it in its original packaging or a protective pouch to prevent damage.

7. Troubleshooting

- **Device not turning on:** Ensure the device is fully charged. If the issue persists, try a different charging cable or adapter.
- **No vibration:** Check if the device is in the correct mode. Ensure the spatula head is making proper contact with damp skin.
- **Poor cleansing results:** Ensure your skin is adequately moist. Use the device slowly and gently, allowing the ultrasonic vibrations to work.
- **Skin irritation:** Reduce the frequency or duration of use. Ensure you are not pressing too hard. If irritation continues, discontinue use and consult a dermatologist.

8. Specifications

Product Name	Ultrasonic Skin Scrubber
Model Number	PMXEA7ABK825VG83RBDA
Dimensions	Approx. 17 x 4 x 3 cm (6.69 x 1.57 x 1.18 inches)
Weight	110 g
Power Source	Rechargeable (USB)
Applicable Skin Types	Oily, Dry (General)
Applicable Parts	Body, Face


SONIC
EMS
ION-
ION+
17cm/6.69in
4cm/1.57in
3cm/1.18in

A diagram illustrating the physical dimensions of the ultrasonic skin scrubber, including its length, width, and thickness for reference.

9. Customer Support

For any questions, concerns, or technical assistance regarding your Generic Ultrasonic Skin Scrubber, please contact the seller or retailer from whom you purchased the product. Please have your model number (PMXEA7ABK825VG83RBDA) and purchase details ready when contacting support.

© 2026 Generic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GMW6FSWZ

More documents and user manuals: **https://manuals.plus/**