Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JAMFLY B0GQGZVDZP

JAMFLY 6-Piece Outdoor Patio Furniture Set with 43-inch Propane Gas Fire Pit Table Instruction Manual

Model: B0GQGZVDZP

1. Introduction

Thank you for choosing the JAMFLY 6-Piece Outdoor Patio Furniture Set with a 43-inch Propane Gas Fire Pit Table. This manual provides essential information for the safe assembly, operation, maintenance, and care of your new outdoor furniture set. Please read all instructions carefully before assembly and use to ensure proper function and longevity of your product.
This set is designed to provide a comfortable and functional outdoor living space, featuring durable PE wicker construction and a versatile propane fire pit table.

2. Important Safety Information

WARNING: Failure to follow these instructions could result in fire, explosion, or carbon monoxide poisoning, which could cause property damage, personal injury, or death.

- **Outdoor Use Only:** This furniture set and fire pit table are designed for outdoor use only. Do not use indoors or in enclosed areas.
- **Propane Gas Safety:**
  - Use only propane gas. Do not use natural gas or other fuels.
  - Ensure the propane tank is securely connected and free of leaks. Perform a leak test with soapy water before each use.
  - Keep the propane tank upright and in a well-ventilated area.
  - Never store a spare propane tank under or near the fire pit table.
  - Keep all combustible materials (e.g., paper, clothing, dry leaves) at least 3 feet (1 meter) away from the fire pit.
- **Supervision:** Never leave the fire pit unattended when in use. Keep children and pets at a safe distance.
- **Clearance:** Maintain adequate clearance from walls, ceilings, and other structures.
- **Hot Surfaces:** The fire pit table and surrounding areas will become hot during operation. Allow to cool completely before touching or moving.
- **Assembly:** Ensure all components are correctly assembled and tightened before use.

- **Maintenance:** Regularly inspect the fire pit and furniture for damage or wear. Do not operate if damaged.

3. Package Contents

Your JAMFLY 6-Piece Outdoor Patio Furniture Set includes the following components. Please verify all parts are present and undamaged before beginning assembly.

- 1 x 43-inch Propane Gas Fire Pit Table
- 2 x Corner Sofa Sections
- 2 x Armless Sofa Sections
- 1 x Coffee Table (or Ottoman)
- Seat and Back Cushions (Aegean Blue)
- Assembly Hardware and Tools (e.g., Allen wrench)



Figure 3.1: Overview of furniture components and their dimensions.



Figure 3.2: Detailed dimensions of the fire pit table.

4. Assembly Instructions

Assembly is required for this furniture set. It is recommended to have two people for assembly. Ensure you have ample space and all parts are accounted for before starting.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface to prevent scratches. Refer to the parts list and diagrams (Figures 3.1 and 3.2) to identify each piece and all hardware.
2. **Assemble Sofa Sections:**
    a. Attach the backrests and armrests to the seat frames using the provided bolts and washers. Do not fully tighten bolts until all components are loosely connected.
    b. Once all parts are aligned, gradually tighten all bolts using the Allen wrench. For efficiency, a cordless drill with an appropriately sized Allen bit is recommended.
    c. Repeat for all corner and armless sofa sections.
3. **Assemble Coffee Table:** Connect the legs to the tabletop frame using the provided hardware. Ensure stability before tightening.
4. **Assemble Fire Pit Table:** Follow the specific instructions provided with the fire pit table for assembling its base and burner components. This typically involves attaching side panels and securing the burner unit.
5. **Place Cushions:** Once all furniture frames are assembled and stable, place the seat and back cushions onto the respective sofa sections. Ensure the non-slip side of the seat cushions faces down.
6. **Final Check:** Verify all connections are secure and the furniture is stable before use.

5. Operating Instructions (Propane Gas Fire Pit Table)

This section details the safe operation of the 43-inch propane gas fire pit table.

Figure 5.1: Fire Pit Table in Coffee Table and Fire Pit Modes.

5.1 Connecting the Propane Tank

1. Ensure the fire pit control knob is in the 'OFF' position.
2. Open the access door on the fire pit table to access the propane tank compartment.
3. Place a standard 20 lb propane tank (not included) into the compartment.
4. Connect the regulator hose from the fire pit to the propane tank valve. Turn the coupling nut clockwise until hand-tight. Do not use tools to tighten.
5. Perform a leak test: Apply a soapy water solution to all connections. Open the propane tank valve slowly. If bubbles appear, there is a leak. Close the tank valve, tighten connections, and re-test. Do not operate if a leak is detected.

5.2 Lighting the Fire Pit

1. Ensure the propane tank valve is fully open.
2. Push and hold the ignition button while slowly turning the control knob to the 'LOW' position.
3. Continue to hold the ignition button for 15-20 seconds after the flame ignites to allow the thermocouple to heat up.
4. If the flame does not ignite, release the ignition button, turn the control knob to 'OFF', wait 5 minutes, and repeat the lighting procedure.
5. Once lit, release the ignition button and adjust the flame height using the control knob.

5.3 Turning Off the Fire Pit

1. Turn the control knob to the 'OFF' position.
2. Close the valve on the propane tank.
3. Allow the fire pit to cool completely before covering or moving.

6. Maintenance and Care

Proper maintenance will extend the life and appearance of your JAMFLY patio furniture set.

6.1 Wicker Frame Care

- Clean the PE wicker frames with a mild soap and water solution. Rinse thoroughly with clean water and allow to air dry.
- Avoid using harsh chemicals, abrasive cleaners, or stiff brushes, as these can damage the wicker.
- For prolonged outdoor exposure, consider using a furniture cover to protect the wicker from UV rays and harsh weather conditions.

6.2 Cushion Care

- The cushion covers are removable and washable. Follow the care instructions on the label, typically machine wash cold on a gentle cycle and air dry.
- Spot clean minor spills with a mild soap and water solution.
- Store cushions indoors or in a waterproof storage box during inclement weather or extended periods of non-use to prevent mildew and fading.
- Ensure cushions are completely dry before storing to prevent mold and mildew growth.

Figure 6.1: Non-slip cushion detail and heightened sofa feet.

6.3 Fire Pit Table Care

- Clean the fire pit table surfaces with a soft cloth and mild detergent.
- Ensure the burner area is free of debris before each use.
- Always use the provided cover or a weather-resistant cover when the fire pit is not in use to protect it from moisture and debris.
- Periodically check gas connections and hoses for signs of wear or damage. Replace if necessary.

7. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Fire pit does not ignite.	Propane tank valve closed, low propane, clogged burner, faulty igniter.	Ensure tank valve is open. Check propane level. Clean burner ports. Check igniter battery (if applicable) or connection.
Low flame or inconsistent flame.	Low propane, regulator issue, partially closed tank valve.	Check propane level. Ensure tank valve is fully open. Reset regulator by closing tank valve, disconnecting, waiting 30 seconds, and reconnecting.
Gas odor detected.	Gas leak.	Immediately turn off propane tank. Perform a leak test with soapy water. Do not operate if a leak persists. Contact customer support.
Furniture feels wobbly after assembly.	Bolts not fully tightened.	Re-tighten all bolts on the affected section. Ensure furniture is on a level surface.
Cushions are damp or show mildew.	Exposure to moisture, improper storage.	Remove covers and wash according to instructions. Ensure cushions are completely dry before re-covering or storing. Store in a dry place.

8. Product Specifications

Feature	Detail
Brand	JAMFLY
Model Number	B0GQGZVDZP
Color	Aegean Blue (Cushions)
Material Type	PE Wicker
Item Weight	163 Pounds

Feature	Detail
Item Dimensions (Overall)	76.8 x 50.2 x 25 inches
Fire Pit Table Size	43 inches (length)
Style	Modern Resort Style
Required Assembly	Yes

9. Warranty and Customer Support

JAMFLY products are manufactured to high-quality standards. For any questions regarding assembly, missing parts, or product performance, please contact JAMFLY customer support. Refer to your purchase documentation for specific warranty details and contact information.
Additional protection plans may be available for purchase to extend coverage beyond the standard warranty period. Please consult your retailer for details on available protection plans.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GQGZVDZP

More documents and user manuals: **https://manuals.plus/**