Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CYBPOK PT6-8-P1

CYBPOK 2 Gallon Battery Powered Garden Sprayer Instruction Manual

Model: PT6-8-P1

1. Introduction

Thank you for choosing the CYBPOK 2 Gallon Battery Powered Garden Sprayer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new sprayer. Please read it thoroughly before first use and retain it for future reference.



Image: The CYBPOK 2 Gallon Electric Sprayer in use, demonstrating effortless spraying with consistent performance.

This battery-powered sprayer is designed for various tasks including weed control, watering plants, fertilizing, and cleaning. Its cordless design and adjustable features offer convenience and efficiency for your lawn and garden care needs.



Image: Multiple applications of the sprayer, including weed control, plant watering, fertilizing, and cleaning.

2. Safety Information

Always follow basic safety precautions when using this product to reduce the risk of injury or damage.

- **Read All Instructions:** Familiarize yourself with the sprayer's operation and safety guidelines before use.
- **Wear Protective Gear:** Always wear appropriate personal protective equipment (PPE) such as safety glasses, gloves, and protective clothing, especially when handling chemicals.
- **Chemical Compatibility:** Use only liquids compatible with the sprayer's materials. Do not use flammable, corrosive, or highly viscous liquids. Consult chemical labels for proper application and safety.
- **Ventilation:** Use in well-ventilated areas to avoid inhaling fumes from sprayed materials.
- **Keep Away from Children and Pets:** Store the sprayer and chemicals out of reach of children and animals.
- **Avoid Overfilling:** Do not exceed the maximum fill line of the tank.
- **Charging Safety:** Use only the provided charging cable. Do not charge near water or in damp conditions. Avoid fast charging unless specified.
- **Inspect Before Use:** Check for any damage, loose connections, or leaks before each use. Do not operate a damaged sprayer.
- **Proper Disposal:** Dispose of unused chemicals and the sprayer components according to local regulations.

3. Package Contents

Please ensure all items are present in the package:

- 2 Gallon (8L) Sprayer Tank
- Electric Handle with Built-in Battery
- Telescopic Wand (Extendable up to 23.6 inches)
- Hose
- 5 Interchangeable Spray Nozzles (Point Jet, Adjustable Cone, F Type Dual, Fan, 6 Hole Pattern)
- Adjustable Shoulder Strap
- USB Charging Cable (Type-C)
- Spare O-rings
- Instruction Manual

4. Product Features

- **Powerful 7.4V Spraying System:** Equipped with a 7.4V 4000mAh rechargeable battery for strong, consistent pressure.
- **Long Runtime:** Provides up to 2-3 hours of continuous spraying per charge.
- **Smart Handle with 3 Spray Levels:** Waterproof electric handle features a clear battery indicator and three adjustable pressure settings (Low, Medium, High) for varied spraying needs.
- **5 Spray Nozzles:** Includes a variety of nozzles for mist, fan, and direct stream spraying, suitable for different tasks.
- **Telescopic Wand:** Extends up to 23.6 inches (60 cm) for reaching higher plants and hard-to-access areas.
- **2 Gallon Capacity:** Reduces the need for frequent refills.
- **Comfortable Carrying:** Adjustable shoulder strap and lightweight design for extended use.
- **Durable & Leak-Proof Design:** Constructed with high-quality, impact-resistant materials and reinforced sealing with rubber O-rings to prevent leaks.
- **USB-C Charging:** Convenient and widely compatible charging port.



Image: Features of the waterproof smart control handle, including battery, charging, runtime, and display.



Image: Design elements for convenience and durability, such as the spray rod holder, wide fill opening, and battery indicator.

5. Setup Instructions

Assembly is quick and requires no tools. Follow these steps for initial setup:

1. **Install the Suction Pipe:** Insert the suction pipe into the tank and tighten the nut securely.
2. **Connect the Electric Handle:** Unscrew the nut at the end of the electric handle, connect the hose, then tighten the nut to secure it.
3. **Attach the Telescopic Wand:** Connect the wand to the electric handle and secure it tightly.
4. **Adjust the Telescopic Wand:** Loosen the nut on the telescopic wand, adjust it to your desired length, then tighten the nut to secure. The wand extends up to 23.6 inches.
5. **Attach Nozzle & Secure Lid:** Select your desired nozzle and screw it onto the end of the telescopic wand. Ensure the tank lid is securely fastened.
6. **Attach the Shoulder Strap:** Fasten the metal clips of the adjustable shoulder strap to the hooks on both sides of the sprayer tank. Adjust the strap for a comfortable fit.



Image: Visual guide for the six-step quick setup process of the sprayer.

6. Operating Instructions

6.1. Charging the Battery

- Ensure the battery is fully charged before first use.
- Connect the USB charging cable to the Type-C port on the side of the electric handle.
- Plug the other end into a compatible USB power source (e.g., wall adapter, power bank).
- The battery indicator light on the handle will show charging status. A full charge typically takes about 4 hours.
- Avoid leaving the unit charging overnight.

6.2. Filling the Tank

- Unscrew the tank lid.
- Pour the desired liquid (water, fertilizer, weed killer, etc.) into the 2-gallon tank.
- Do not exceed the maximum fill line indicated on the tank.
- Securely tighten the tank lid to prevent leaks.

6.3. Selecting and Adjusting Spray Modes

The electric handle features a single button to control power and spray pressure.

- **Power On/Off:** Press and hold the power button on the handle for a few seconds to turn the sprayer on or off.
- **Adjust Pressure:** Once powered on, press the button briefly to cycle through the three pressure modes: Low (Soft Mist), Medium (Balanced Spray), and High (Powerful Jet). The battery indicator lights will change to reflect the selected mode.



Image: Three adjustable spray modes for various applications.

6.4. Using Interchangeable Nozzles

The sprayer comes with 5 different nozzles to suit various spraying needs.

- To change a nozzle, simply unscrew the current nozzle from the end of the telescopic wand and screw on the desired one.
- **Point Jet Nozzle:** For strong, targeted streams, ideal for deep watering or reaching specific areas.
- **Adjustable Cone Nozzle:** Provides an adjustable spray pattern from a fine mist to a stream.
- **F Type Dual Nozzle:** Offers dual spray output for faster coverage.
- **Fan Nozzle:** Creates a wide fan spray, suitable for covering larger areas evenly.
- **6 Hole Pattern Nozzle:** Delivers a fine mist spray for gentle watering.



Image: The five interchangeable nozzles and their respective spray patterns.



Image: Demonstration of a single nozzle adjusting between fine mist and focused jet spray.

6.5. Carrying the Sprayer

The sprayer can be carried in two ways:

- **Handheld:** Use the integrated handle on the tank for short distances or when precise control is needed.
- **Shoulder Strap:** For longer tasks or when the tank is full, use the adjustable shoulder strap to distribute weight and keep your hands free.



Image: Two convenient methods for carrying the sprayer: handheld and with the shoulder strap.

7. Maintenance

Proper maintenance ensures the longevity and optimal performance of your sprayer.

- **Rinse After Use:** After each use, especially when spraying chemicals, empty any remaining liquid and rinse the tank, hose, and nozzles thoroughly with clean water. Operate the sprayer with clean water for a few minutes to flush the internal components.
- **Drain Thoroughly:** Ensure all water is drained from the tank, hose, and wand before storage to prevent residue buildup or freezing in cold weather.
- **Clean Nozzles:** If nozzles become clogged, remove them and clean with water. A small brush or pin can help clear blockages.

- **Check O-Rings:** Periodically inspect the rubber O-rings for wear or damage. Replace them if necessary using the provided spare parts to maintain a leak-proof seal.
- **Storage:** Store the sprayer in a dry, cool place, away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (not fully depleted or fully charged) for long-term storage.



Image: Important tips for battery, assembly, sealing, cleaning, and maintenance.

8. Troubleshooting

If you encounter issues with your sprayer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Sprayer does not turn on.	Battery is depleted.	Charge the battery fully.
No spray or weak spray.	Nozzle is clogged.	Remove and clean the nozzle.
	Low liquid level in tank.	Refill the tank.
	Hose or suction pipe is kinked or blocked.	Check and clear any obstructions.
	Sprayer needs re-priming.	Disconnect the hose from the pump. Briefly run the inlet under a stream of water while the pump is on to re-prime. Reconnect the hose.
Liquid leaks from connections.	Loose connections or worn O-rings.	Tighten all connections. Inspect and replace O-rings if damaged.
Battery indicator not working.	Battery issue or electrical fault.	Ensure battery is charged. If problem persists, contact customer support.

9. Specifications

Feature	Detail
Brand	CYBPOK
Model Name	PT6-8-P1
Capacity	2 Gallon (8 Liters)
Power Source	Battery Powered
Battery	7.4V 4000mAh Rechargeable
Runtime	Up to 2-3 hours
Charging Time	Approx. 4 hours
Charging Port	USB Type-C
Pressure Modes	3 (Low, Medium, High)
Nozzles Included	5 (Point Jet, Adjustable Cone, F Type Dual, Fan, 6 Hole Pattern)
Telescopic Wand Length	Extendable up to 23.6 inches (60 cm)
Product Dimensions	12"W x 6.3"H (Tank)

10. Warranty and Support

Specific warranty details for this product may vary. Please refer to the documentation included with your purchase or contact the retailer for warranty information.
For technical support, questions, or assistance with your CYBPOK Garden Sprayer, please contact our customer service team. Contact information can typically be found on the product packaging or the retailer's website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GRHD5RYH

More documents and user manuals: **https://manuals.plus/**