Feelfunn CRF011-16

Feelfunn 1.7 Cu.Ft Mini Fridge with Freezer - Instruction Manual

Model: CRF011-16

Introduction

Thank you for choosing the Feelfunn 1.7 Cu.Ft Mini Fridge with Freezer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions thoroughly before use and retain them for future reference.

Safety Information

To reduce the risk of fire, electric shock, or injury when using your refrigerator, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not touch cold surfaces, especially when hands are damp or wet. Skin may stick to extremely cold surfaces.
- Ensure the refrigerator is properly grounded.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Unplug the refrigerator before cleaning or making repairs.
- Keep ventilation openings clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Product Overview

The Feelfunn 1.7 Cu.Ft Mini Fridge with Freezer is designed for compact spaces, offering both refrigeration and a small freezer compartment. Key features include adjustable shelves, a reversible door, and energy-efficient operation.

Dimensions and Capacity

- **Product Dimensions:** 17.5" (W) x 16.9" (D) x 19.1" (H)
- **Total Capacity:** 1.7 cubic feet

- **Refrigerator Capacity:** 1.5 cubic feet
- **Freezer Capacity:** 0.2 cubic feet



Image: Front view of the Feelfunn 1.7 Cu.Ft Mini Fridge with Freezer, showing external dimensions and internal storage layout with food and beverages.

Included Components

- Mini Fridge with Freezer unit

- Removable Wire Shelf
- Ice Shovel
- Water Tray



Image: Detailed view of the mini fridge highlighting features like the reversible door, adjustable feet, and included accessories: removable wire shelf, ice shovel, and water tray.

Setup

Unpacking

1. Remove all packaging materials, including the foam base and adhesive tape.
2. Inspect the refrigerator for any damage. Report any damage to your retailer immediately.
3. Clean the interior and exterior of the refrigerator with a soft cloth and lukewarm water.

Placement

- Place the refrigerator on a firm, level surface away from direct sunlight and heat sources (e.g., stoves, heaters).
- Allow at least 4 inches (10 cm) of space around the back and sides for proper ventilation.
- The appliance is suitable for counter-top or freestanding installation.

Initial Use

1. After placing the refrigerator, allow it to stand upright for at least 2-4 hours before plugging it in. This allows the refrigerant to settle.
2. Plug the refrigerator into a dedicated 115V electrical outlet.
3. Set the temperature control to the desired setting (refer to the Operating Instructions section).
4. Allow the refrigerator to cool for several hours before placing food inside.

Operating Instructions

Temperature Control

Your Feelfunn mini fridge features an adjustable thermostat knob with 7 precise cooling levels, allowing you to customize the temperature from 32°F to 50°F.

- Settings 1-2: Ideal for fresh produce and less demanding cooling.
- Settings 3-4: Suitable for beverages and general refrigeration.
- Settings 5-6: Recommended for items requiring colder temperatures, such as ice cream.
- Setting 7: Provides the coldest temperature for micro-freezing.



Image: Diagram illustrating the 7-stage temperature control dial and a table showing the corresponding temperature ranges for refrigeration and micro-freezing modes.

Adjustable Shelves

The removable wire shelf can be adjusted to accommodate items of various sizes. To adjust, simply lift the shelf and slide it into the desired grooves.

Reversible Door

The door can be reversed to open from either the left or right side, offering flexibility for placement in different room layouts. Refer

to the detailed instructions in the Maintenance section for how to reverse the door.

Maintenance

Cleaning

1. Unplug the refrigerator before cleaning.
2. Wash the interior with a mild detergent and warm water. Use a soft cloth to prevent scratching.
3. Clean the door gasket regularly to ensure a proper seal.
4. Wipe the exterior with a damp cloth and dry thoroughly.
5. Do not use harsh chemicals, abrasive cleaners, or scouring pads.

Defrosting

This refrigerator features a manual defrost system. Frost will accumulate on the freezer compartment walls. To defrost:

1. Unplug the refrigerator.
2. Remove all food items from the freezer and refrigerator compartments.
3. Place the included water tray under the freezer compartment to collect melting ice.
4. Leave the door open to allow frost to melt naturally. You can use the ice shovel to gently remove thick ice, but do not use sharp objects.
5. Once defrosted, clean and dry the interior thoroughly before plugging the unit back in and returning food.

Reversing the Door Swing

The door swing can be reversed from right-hand opening to left-hand opening. This process requires careful handling and may involve small parts. It is recommended to have assistance if you are unfamiliar with such procedures.

1. Unplug the appliance from the power outlet.
2. Remove the top hinge cover and unscrew the top hinge.
3. Lift the door off the bottom hinge pin.
4. Remove the bottom hinge and transfer the hinge pin to the opposite side.
5. Reattach the bottom hinge to the new side.
6. Carefully place the door onto the new bottom hinge pin.
7. Reattach the top hinge to the opposite side, ensuring the door is aligned and seals properly.
8. Replace the top hinge cover.

Troubleshooting

Before contacting customer support, please refer to the following troubleshooting guide for common issues:

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; temperature control set to "OFF".	Ensure plug is secure; reset circuit breaker; adjust temperature control.
Temperature is not cold enough.	Door opened too frequently; warm food placed inside; poor ventilation; temperature control set too high.	Minimize door openings; allow hot food to cool before storing; ensure adequate clearance around unit; lower temperature setting.
Excessive frost buildup.	Door not sealed properly; high humidity; frequent door openings.	Check door gasket for proper seal; avoid opening door unnecessarily; perform manual defrost.

Problem	Possible Cause	Solution
Noise from the unit.	Unit not level; objects vibrating against the unit; normal compressor operation.	Adjust leveling feet; ensure nothing is touching the unit; some operational noise is normal (≤38 dB).

Specifications

Brand	Feelfunn
Model Name	mini fridge
Model Number	CRF011-16
Product Dimensions (D x W x H)	16.9" x 17.5" x 19.1"
Total Capacity	1.7 cubic feet
Fresh Food Capacity	1.5 cubic feet
Freezer Capacity	0.2 cubic feet
Color	Silver
Configuration	Compact Freezer-on-Top
Special Features	Adjustable Shelves, Compact, Energy Efficient, Low Noise
Installation Type	Counter-Top, Freestanding
Defrost System	Manual
Voltage	115 volts
Annual Energy Consumption	230 kilowatt hours per year
Noise Level	≤38 dB
Door Orientation	Reversible
Included Components	Mini Fridge with Freezer, Removable Wire Shelf, Ice Shovel, Water Tray

Warranty and Support

Warranty Information

This Feelfunn mini fridge is covered by a **1-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accident, alteration, neglect, or improper installation.
Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, warranty service, or to order replacement parts, please contact Feelfunn customer support. Contact information can typically be found on the product packaging or the official Feelfunn website.
When contacting support, please have your model number (CRF011-16) and purchase date available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question