Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kismile KS-IM5815NB-STEEL

Kismile Nugget Ice Maker User Manual

Model: KS-IM5815NB-STEEL

Introduction

Thank you for choosing the Kismile Nugget Ice Maker. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before using the ice maker and retain it for future reference.



Image: The Kismile Nugget Ice Maker providing fresh ice for various occasions, highlighting its convenience for gatherings.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury when using your ice maker, follow these basic precautions:

- Read all instructions before use.
- Do not touch the evaporator when the ice maker is in operation.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Supervise children when the appliance is in use.
- Unplug from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only potable water.
- Do not use outdoors.

- Ensure proper ventilation around the unit.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use for other than intended household use.

Product Overview

The Kismile Nugget Ice Maker is designed to produce chewable nugget ice quickly and efficiently. Familiarize yourself with its main components:

Key Features:

- **Rapid Ice Production:** Produces up to 35 lbs of nugget ice per day, with the first batch ready in approximately 7 minutes.
- **Chewable Nugget Ice:** Soft, crunchy ice that melts slowly and retains beverage flavor.
- **Self-Cleaning Function:** One-click activation for easy maintenance.
- **User-Friendly Design:** Intuitive LED indicators for water level, ice production, and cleaning status.
- **Compact Size:** Designed for countertop use with a transparent lid to monitor ice levels.

Components:

- Ice Maker Unit
- Detachable Ice Basket
- Ice Scoop
- Water Reservoir (internal)
- Control Panel with LED Indicators



Image: A user removing the detachable ice basket from the Kismile Nugget Ice Maker, showing its easy access for serving.



Image: A close-up of the unique, chewable nugget ice produced by the machine, ideal for various beverages.

Setup Guide

1. Unpacking

Carefully remove all packaging materials and inspect the ice maker for any damage. Ensure all accessories (ice basket, scoop) are present. Keep packaging for future storage or transport if needed.

2. Placement

- Place the ice maker on a flat, stable, and level surface.
- Ensure there is at least 4 inches (10 cm) of space around the unit for proper ventilation.
- Keep away from direct sunlight and heat sources (e.g., stoves, ovens).
- Do not place in an enclosed cabinet.

3. Initial Cleaning

Before first use, it is recommended to clean the unit. Refer to the "Maintenance and Cleaning" section for detailed instructions on how to perform the self-cleaning cycle and manual cleaning.

4. Water Filling

1. Open the lid of the ice maker.
2. Fill the water reservoir with potable water up to the "MAX" fill line. Do not overfill.
3. Close the lid securely.

Operating Your Ice Maker

1. Power On

Plug the ice maker into a grounded electrical outlet. Press the**ON/OFF** button to start the ice-making process. The indicator light will illuminate.

2. Ice Production

The ice maker will begin its cycle. The first batch of nugget ice typically takes about 7 minutes. Subsequent batches will be produced continuously as long as there is water in the reservoir and space in the ice basket.



Image: The ice maker's basket filled with freshly made nugget ice, demonstrating its 35 lbs/day capacity.

3. LED Indicators

- **ICE FULL:** When the ice basket is full, the "ICE FULL" indicator will light up, and the ice-making process will pause. Remove some ice to resume production.
- **ADD WATER:** If the water level in the reservoir is too low, the "ADD WATER" indicator will light up. Add more potable water to the reservoir, and the ice maker will automatically restart.

4. Serving Ice

Use the provided ice scoop to retrieve ice from the basket. Close the lid after use to help maintain the ice temperature.

5. Power Off

To stop the ice maker, press the**ON/OFF** button. Unplug the unit from the power outlet if it will not be used for an extended period.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your Kismile Nugget Ice Maker.

1. Self-Cleaning Function

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the **ON/OFF** button for 5 seconds. The "CLEAN" indicator will light up.
3. The self-cleaning cycle will run for approximately 15 minutes.
4. Once the cycle is complete, drain the water from the unit (refer to manual for drain plug location, typically at the bottom or side).
5. Rinse the reservoir with fresh water and drain again.



Image: An internal view of the Kismile Nugget Ice Maker demonstrating the water circulation during its self-cleaning function.

2. Manual Cleaning

- **Exterior:** Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.

- **Ice Basket & Scoop:** Wash with mild soap and warm water, then rinse thoroughly and dry.
- **Interior:** For a more thorough cleaning, unplug the unit, remove the ice basket, and wipe down the interior surfaces with a soft cloth dampened with a solution of water and white vinegar (1:1 ratio). Rinse with clean water and drain.

3. Descaling

Over time, mineral deposits can build up. If you notice reduced ice production or unusual odors, perform a descaling process using a descaling solution suitable for ice makers, following the product's instructions. Always rinse thoroughly afterward.

4. Storage

If storing the ice maker for an extended period, ensure it is completely drained, cleaned, and dry. Store in a cool, dry place.

Troubleshooting

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Ice maker not working	Not plugged in; Power outage; Unit is off.	Ensure unit is plugged in; Check power supply; Press ON/OFF button.
"ADD WATER" indicator on	Water reservoir is empty or low.	Add potable water to the reservoir up to the MAX line.
"ICE FULL" indicator on	Ice basket is full.	Remove ice from the basket.
No ice or very little ice produced	Water level too low; Ambient temperature too high; Poor ventilation; Mineral buildup.	Add water; Ensure room temperature is suitable (10-32°C); Ensure proper ventilation; Perform cleaning/descaling.
Ice has an unusual taste or smell	Stale water; Unit needs cleaning; Water source quality.	Change water frequently; Perform thorough cleaning; Use filtered water.

Specifications

Model Number	KS-IM5815NB-STEEL
Brand	Kismile
Ice Production Capacity	Up to 35 lbs (15.88 kg) per 24 hours
Water Tank Capacity	1.1 Liters (approx.)
Refrigerant	R600a
Product Dimensions (D x W x H)	28 x 21 x 31 cm (11.02" x 8.27" x 12.2")
Net Weight	Approx. 8.01 kg (17.66 lbs)

Included Components	Ice Maker, Ice Scoop

Warranty and Customer Support

For warranty information, please refer to the warranty card included with your product or contact the retailer where you purchased the Kismile Nugget Ice Maker.
If you encounter any issues or have questions not covered in this manual, please contact Kismile customer support for assistance. Have your model number (KS-IM5815NB-STEEL) and purchase details ready.
Contact information for Kismile customer support can typically be found on the product packaging, official website, or your purchase receipt.

© 2026 Kismile. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GS552T5S

More documents and user manuals: **https://manuals.plus/**