Tipdiy U9

Tipdiy U9 Cordless Vacuum Cleaner Instruction Manual

Model: U9 | Brand: Tipdiy

Introduction

The Tipdiy U9 Cordless Vacuum Cleaner is designed for efficient and versatile home cleaning. This lightweight, rechargeable stick vacuum features 40KPA suction power, a self-standing design, and a 7-layer filtration system, making it suitable for various surfaces including carpets, pet hair, and hardwood floors.



Image: The Tipdiy U9 Cordless Vacuum Cleaner with its main body, extension wand, and floor brush, showcasing its sleek design.

Product Components

Before assembly, ensure all components are present:

- Cordless Vacuum Main Unit
- Adjustable Metal Tube (Extension Wand)
- Electric Floor Brush (with S-Shape anti-tangle design)
- Crevice Nozzle
- 2-in-1 Brush Nozzle
- Power Adapter
- Wall Mount
- Filter x 2 (one pre-installed, one spare)
- Metal Filter (pre-installed)



Image: An exploded view showing all included components of the Tipdiy U9 vacuum cleaner, including the main engine, various nozzles, filters, and charging accessories.

Setup and Assembly

1. **Attach the Extension Wand:** Connect the adjustable metal tube to the main vacuum unit until it clicks securely into place.
2. **Attach the Floor Brush:** Connect the electric floor brush to the other end of the adjustable metal tube until it clicks. For handheld use, attach desired nozzle directly to the main unit.
3. **Charge the Battery:** Before first use, fully charge the vacuum cleaner. Connect the power adapter to the charging port on the main unit and plug it into a wall outlet. The indicator lights will show charging status.
4. **Wall Mount Installation (Optional):** Choose a suitable location for the wall mount. Secure it to the wall using appropriate screws and anchors (not included). This allows for convenient storage and charging.

Your browser does not support the video tag.

Video: An official product video demonstrating the assembly and use of the Tipdiy Cordless Vacuum Cleaner, including attaching the main components and using various nozzles.

Operating Instructions

1. **Power On/Off:** Press the power button on the main unit to turn the vacuum on or off.
2. **Adjust Suction Power:** Use the +/- button next to the power button to switch between the two available power levels (standard and max suction).
3. **Using the Electric Floor Brush:** This brush is ideal for hard floors and carpets. The integrated LED lights illuminate the cleaning path, making dust visible in dimly lit areas. The S-Shape anti-tangle design helps prevent hair from wrapping around the brush.
4. **Using Attachments:**
    - **Crevice Nozzle:** Attach directly to the main unit or extension wand for cleaning tight corners, edges, and narrow gaps.
    - **2-in-1 Brush Nozzle:** Use the brush mode for delicate surfaces like keyboards or upholstery, and the crevice mode for general dusting or reaching into small spaces.
5. **Self-Standing Feature:** The vacuum is designed to stand upright on its own, allowing you to pause cleaning and attend to other tasks without needing to lean it against a wall or lay it down.
6. **Flexible Head:** The electric floor brush features a highly flexible head that can swivel 180° left/right and 90° up/down, allowing easy maneuverability around furniture and into tight spaces.



Image: The Tipdiy U9 vacuum cleaner in action, illustrating its powerful 40KPA suction picking up various debris like hair, pet hair, and crumbs from a hard floor.



Image: The flexible head of the Tipdiy U9 vacuum cleaner demonstrating its ability to reach under low furniture and maneuver around corners with ease, highlighting its 180° and 90° rotation capabilities.

Maintenance

1. **Emptying the Dust Cup:**

   To empty the dust cup, hold the main unit over a trash bin. Press the dust cup release button to open the bottom flap and release collected debris. Close the flap securely after emptying.



Image: A diagram illustrating the one-touch dust cup emptying mechanism of the Tipdiy U9 vacuum cleaner, showing debris falling into a trash bin without direct contact.

2. **Cleaning the Filters:**

   The Tipdiy U9 features a 7-layer filtration system, including a metal filter and a high-efficiency filter cotton. Regularly clean these filters to maintain optimal suction and air quality.

   - Remove the dust cup from the main unit.
   - Twist and pull out the metal filter and the high-efficiency filter cotton.
   - Tap off loose dust. For a deeper clean, rinse the filters under running water. Ensure they are completely dry before reassembling.
   - Reassemble the filters and dust cup in reverse order.



Image: An exploded diagram of the Tipdiy U9's 7-layer filtration system, showing the dust cup, metal filter, cyclone filtration, secondary cyclone filtration, high-efficiency filter cotton, built-in sponge, and air outlet filtration system.



Image: A visual representation of the washable filter components of the Tipdiy U9 vacuum cleaner, submerged in water, emphasizing their reusability and ease of cleaning.

3. **Cleaning the Brush Roll:**

Periodically check the electric floor brush for tangled hair or debris. The S-Shape anti-tangle design minimizes this, but occasional cleaning may be necessary. Remove the brush roll from the head and clear any obstructions. Reinsert the brush roll securely.



Image: A comparison showing the S-shaped anti-tangle brush design of the Tipdiy U9 versus a traditional brush, highlighting its effectiveness in preventing hair from wrapping around.

Troubleshooting

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted or not charged.	Charge the vacuum fully using the provided power adapter.
Low suction power.	Dust cup is full, filters are clogged, or brush roll is obstructed.	Empty the dust cup. Clean or replace the filters. Remove any obstructions from the brush roll.
Brush roll stops rotating.	Hair or debris is tangled in the brush roll.	Turn off the vacuum and remove any tangled hair or debris from the brush roll.

Problem	Possible Cause	Solution
Vacuum makes unusual noise.	Obstruction in the air path or damaged component.	Check for blockages in the nozzle, wand, or main unit. If noise persists, contact customer support.

Specifications

Brand	Tipdiy
Model Name/Number	U9
Special Features	Self-Standing, Hands-Free, Lightweight, High-speed motor, Easy Handling, 7-layer Filtration, Versatile Nozzle, Telescopic pole
Filter Type	Cotton (High-efficiency filter cotton)
Surface Recommendation	Hard floors, hardwood floors, carpets, tiles, sofas, keyboards, stairs
Power Source	Battery Powered
Capacity	0.8 Liters
Color	Red
Portable	Yes
Number of Power Levels	2
Indoor Outdoor Usage	Indoor
Is Product Cordless	Yes
Item Weight	6 Pounds
Item Dimensions (L x W x H)	10.8"L x 5.5"W x 17.5"H
Voltage	220 Volts

Warranty and Support

For warranty information, technical support, or any inquiries regarding your Tipdiy U9 Cordless Vacuum Cleaner, please refer to the contact details provided in the packaging or visit the official Tipdiy website. Keep your purchase receipt as proof of purchase for warranty claims.
Optional protection plans may be available for extended coverage. Please check with your retailer for details.

© 2026 Tipdiy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question