VERMESS 47 Inch

VERMESS 47-inch Reversible L-Shaped Gaming Computer Desk User Manual

Model: 47 Inch | Brand: VERMESS

Introduction

Thank you for choosing the VERMESS 47-inch Reversible L-Shaped Gaming Computer Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your product. Please read this manual thoroughly before assembly and retain it for future reference.



Image: The VERMESS 47-inch L-Shaped Gaming Computer Desk, showcasing its design with integrated LED lighting and storage in a gaming environment.

Product Features

The VERMESS L-Shaped Gaming Computer Desk is designed for versatility and functionality, offering a comprehensive solution for your workspace or gaming setup. Key features include:

- **Reversible L-Shaped Design:** Allows for left or right-hand configuration to fit various room layouts.
- **Integrated Power Outlets:** Features 3 AC outlets and 2 USB ports for convenient device charging.
- **Monitor Stand:** An elevated shelf provides an ergonomic viewing angle for your monitor.
- **Ample Storage:** Includes four fabric storage drawers, two iron hooks, and a dedicated CPU stand.
- **LED Lighting:** Built-in RGB lighting with 7 color changes and 20 lighting modes to customize your ambiance.
- **Durable Construction:** Crafted from waterproof engineered wood boards and a sturdy iron frame with adjustable foot pads for stability.

Setup and Assembly

Assembly of your VERMESS desk is designed to be straightforward. Please follow these steps carefully. All necessary parts and tools are included.

1. Unpacking and Part Identification

- Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches.
- Verify that all parts listed in the included parts list are present. If any parts are missing or damaged, please contact customer support.
- Familiarize yourself with the different components, referring to the provided diagrams.



Image: Product dimensions and component breakdown for assembly planning.

2. Reversible Configuration

The L-shaped desk can be assembled with the longer section on either the left or right side to best suit your space. Decide on your preferred orientation before beginning assembly.



Image: Visual representation of the reversible desk configuration.

3. Step-by-Step Assembly

Follow the numbered instructions and diagrams provided in the separate assembly guide. Ensure all screws are tightened securely but do not overtighten. Pay close attention to the orientation of each piece as indicated in the diagrams.

- Assemble the main desk frame first.
- Attach the desktop panels.
- Install the monitor stand.
- Assemble and insert the fabric storage drawers.
- Attach the CPU stand and iron hooks.
- Adjust the foot pads to ensure the desk is stable and level on uneven surfaces.



Image: Detail of the fabric storage bag and open storage shelf installation.

Operating Instructions

Power Outlets and USB Ports

The desk is equipped with a built-in power strip for convenient access to power. To use, plug the desk's main power cord into a standard wall outlet.

- **AC Outlets:** 3 standard 120V/12A AC outlets are available for powering monitors, computers, and other devices.
- **USB Ports:** 1 USB port (5V/2A) and 1 Type-C port (5V/2A) are provided for charging smartphones, tablets, and other USB-powered devices.



Image: Detail of the power outlets and USB ports for charging devices.

LED Lighting System

The integrated LED lighting system enhances your desk environment. It is controlled via a remote or a button on the desk.

- **Color Change:** Cycle through 7 different colors to match your preference.
- **Lighting Modes:** Choose from 20 distinct lighting modes, including static colors, fades, and flashes.
- **Power:** Ensure the LED strip is properly connected to the power supply.



Image: The desk with its LED lighting system active, demonstrating various color options.

Storage Drawers and Accessories

Utilize the four fabric storage drawers for organizing documents, accessories, and other items. The two iron hooks can be used for headphones or bags, and the CPU stand keeps your computer tower off the floor for better airflow.



Image: The fabric storage drawers providing ample space for organization.

Maintenance and Care

Proper maintenance will extend the life and appearance of your VERMESS desk.

- **Cleaning Surfaces:** Wipe the engineered wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Although the desk is made with waterproof boards, promptly wipe up any spills to prevent water damage or staining.
- **Frame Care:** The iron frame can be wiped clean with a damp cloth. Ensure it is dried thoroughly to prevent rust.
- **Fabric Drawers:** The fabric drawers can be spot cleaned with a mild detergent and water. Allow them to air dry completely before reinserting.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Foot Pads:** Ensure the adjustable foot pads are correctly positioned and adjusted to maintain desk stability.

Troubleshooting

If you encounter any issues with your VERMESS desk, please refer to the following common solutions:

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Uneven floor; loose connections; foot pads not adjusted.	• Adjust the leveling foot pads on the bottom of the desk legs until stable. • Check all screws and bolts, tightening any that are loose. • Ensure the desk is placed on a flat surface.
LED lights are not working.	Power connection issue; remote control battery dead; LED strip damage.	• Ensure the LED strip is securely plugged into its power source and the wall outlet. • Check the remote control battery and replace if necessary. • Inspect the LED strip for any visible damage.
Power outlets/USB ports not functioning.	Desk power cord not plugged in; circuit breaker tripped; faulty device.	• Verify the desk's main power cord is securely plugged into a working wall outlet. • Check your home's circuit breaker. • Test with a different device to rule out a faulty device.
Difficulty during assembly.	Misinterpretation of instructions; incorrect part orientation.	• Review the assembly diagrams carefully, paying attention to part numbers and orientations. • Do not overtighten screws until all parts are loosely fitted. • If a part seems difficult to fit, re-check the previous steps.

Specifications

Feature	Detail
Brand	VERMESS
Model	47 Inch L-Shaped Gaming Computer Desk
Shape	L-Shape (Reversible)
Product Dimensions (D x W x H)	35.4"D x 47.2"W x 34"H
Color	Rustic Brown
Style	Modern
Base Material	Metal
Top Material Type	Engineered Wood

Feature	Detail
Finish Type	Wood
Special Features	Built-In USB Outlet, Reversible, Rust Resistant, Scratch Resistant, LED Lights, Monitor Stand, CPU Stand
Number of Drawers	4 (Fabric)
Item Weight	40.3 pounds
Power Outlets	3 AC Outlets (120V/12A), 1 USB Port (5V/2A), 1 Type-C Port (5V/2A)
LED Lighting	7 Color Change, 20 Lighting Modes

Customer Support

For any questions, missing parts, or assistance with assembly and operation, please contact VERMESS customer support. Our dedicated support team aims to respond within 24 hours to ensure your satisfaction.
Please refer to your purchase documentation or the VERMESS official website for contact information.

© 2026 VERMESS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question