Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GAOMON 44C-ZBGDF7IN5U9CYZ2E2KI-BI-UU

GAOMON 9FT 3-Tier Patio Umbrella with Solar LED Lights User Manual

Model: 44C-ZBGDF7IN5U9CYZ2E2KI-BI-UU

Important Safety Instructions

Please read and understand all instructions before assembling and using this product. Failure to follow these instructions may result in injury or product damage.

- Always close the umbrella during strong winds, heavy rain, or other severe weather conditions to prevent damage or injury.
- Ensure the umbrella base (not included) is heavy enough to provide adequate stability.
- Do not use the umbrella near open flames or heat sources.
- Keep children and pets away from the umbrella during assembly and operation.
- Inspect all parts for damage before assembly. Do not use if any parts are damaged.

Package Contents

Verify that all components are present before beginning assembly.

- Umbrella Canopy with Solar LED Lights
- Upper Pole
- Lower Pole
- Crank Handle (pre-attached)

Note: Umbrella base is not included and must be purchased separately.

Setup and Assembly

Follow these steps to assemble your GAOMON patio umbrella.

1. **Attach the Lower Pole to the Base:** Insert the lower pole into a suitable umbrella base (not included). Tighten any securing knobs on the base to ensure the pole is stable and upright.
2. **Connect Upper and Lower Poles:** Carefully slide the upper pole (with the canopy attached) into the lower pole.

Ensure the connection is secure. There may be a button or screw to lock the two sections together.

3. **Open the Umbrella:** Turn the crank handle clockwise to open the umbrella canopy. Continue cranking until the canopy is fully extended and taut.



Figure 1: Crank Lifting System and Push-Button Tilt. This image illustrates how to use the crank handle to open and close the umbrella, and the push-button for tilting the canopy.

4. **Positioning:** Once assembled, ensure the umbrella is positioned in a location where it can provide optimal shade and is not obstructed.



Figure 2: Wide Application. The umbrella is shown providing shade over an outdoor dining set, demonstrating its suitability for various outdoor settings like patios, courtyards, and gardens.

Operating Instructions

Opening and Closing the Umbrella

- To open, turn the crank handle clockwise until the canopy is fully extended.
- To close, turn the crank handle counter-clockwise until the canopy is fully retracted. Secure the canopy with the attached strap when closed.

Using the Tilt Function

- With the umbrella fully open, locate the push-button on the pole near the crank mechanism.
- Press and hold the button, then gently tilt the canopy to your desired angle. Release the button to lock the tilt position.
- To return to the upright position, press the button again and push the canopy back into place.

Solar LED Lights Operation

The umbrella features solar-powered LED lights that charge during the day and illuminate at night.

- Ensure the solar panel located on top of the umbrella is exposed to direct sunlight for optimal charging. A minimum of 6-7 hours of sun exposure is recommended for a full charge.
- The lights will automatically turn on at dusk and turn off at dawn, or can be manually controlled by a switch (if present, check your specific model for switch location).



Figure 3: Solar-Powered LED Lights. This image shows the umbrella's integrated LED lights glowing at night, powered by the solar panel visible in the inset.



Figure 4: Evening Ambiance. The umbrella's solar lights provide illumination for outdoor evening activities, as depicted by a couple enjoying a meal by the beach.

Maintenance and Care

Proper maintenance will extend the life of your patio umbrella.

- **Cleaning the Canopy:** Clean the polyester canopy with mild soap and water. Use a soft brush or cloth to gently scrub any soiled areas. Rinse thoroughly with clean water and allow to air dry completely before closing or storing. Do not use harsh chemicals or abrasive cleaners.
- **Frame Care:** Wipe the metal frame with a damp cloth to remove dirt and dust. For rust prevention, ensure the frame is dry after cleaning and consider applying a rust-inhibiting spray periodically.
- **Storage:** When not in use for extended periods or during off-season, close the umbrella, secure it with the strap, and store it in a dry, protected area. Using an umbrella cover is recommended to protect against dust, dirt, and weather elements.
- **Solar Panel:** Keep the solar panel clean and free of debris to ensure efficient charging.



Figure 5: Premium Material Features. This image details the canopy's construction from solution-dyed polyester, emphasizing its fade-resistant, UV-protective, and waterproof qualities, which contribute to its durability and ease of maintenance.

Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Umbrella does not open or close smoothly.	Crank mechanism is stiff or obstructed.	Apply a silicone-based lubricant to the moving parts of the crank mechanism. Check for any fabric or debris obstructing the ribs.

Problem	Possible Cause	Solution
LED lights are not turning on.	Insufficient solar charge; solar panel is dirty or obstructed; battery issue.	Ensure the solar panel receives direct sunlight for at least 6-7 hours. Clean the solar panel. Check if the power switch (if any) is in the "ON" position. If issues persist, the battery may need replacement (consult customer support).
Umbrella is unstable.	Base is too light or not properly secured; strong winds.	Ensure you are using a sufficiently heavy umbrella base. Tighten all securing knobs on the base. Close the umbrella during windy conditions.

Specifications

Feature	Detail
Model Number	44C-ZBGDF7IN5U9CYZ2E2KI-BI-UU
Umbrella Diameter	9 Feet (approx. 106.3 inches)
Canopy Type	3-Tier Ventilated
Canopy Material	High-Quality Polyester (UV-resistant, Fade-resistant, Water-resistant)
Frame Material	Rust-Resistant Steel
Ribs	8 Heavy Duty Ribs
Lighting	24 Solar-Powered LED Lights
Operation	Crank Lift System, Push-Button Tilt
Item Weight	15 Pounds
Color	Navy Blue



Figure 6: Strong & Stable Structure. This image highlights the robust construction of the umbrella, featuring 8 heavy-duty ribs designed for enhanced stability and wind resistance.



Figure 7: 3-Layer Ventilated Top. This diagram explains the function of the umbrella's three-tier design, which enhances airflow to reduce heat and improves wind resistance for greater stability.

Warranty Information

GAOMON products are manufactured to high-quality standards. For specific warranty details, please refer to the product packaging or contact customer support. Keep your purchase receipt as proof of purchase.

Customer Support

If you have any questions, require assistance, or need to report a missing or damaged part, please contact GAOMON customer support through the retailer's platform or the official GAOMON website.
Please have your model number (44C-ZBGDF7IN5U9CYZ2E2KI-BI-UU) and purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GTVFV4L5

More documents and user manuals: **https://manuals.plus/**