Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nordivale H21430-70BKBK

Nordivale 70-inch Fireplace TV Stand Instruction Manual

Model: H21430-70BKBK

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Nordivale 70-inch Fireplace TV Stand, Model H21430-70BKBK. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This entertainment center is designed to accommodate TVs up to 80 inches and features an integrated electric fireplace with adjustable settings and ample storage.

Product Overview

Product Size

TV Stand: 70"L×14.2"W× 33.5"H

Fireplace: 36"L×23.2"W× 18.3"H

Tabletop Weight Capacity: 150 LBS

Shelf Weight Capacity: 33 LBS

Middle Wood Weight Capacity: 44 LBS



Image: Product dimensions and weight capacities. The TV stand measures 70"L x 14.2"W x 33.5"H. The fireplace measures 36"L x 23.2"W x 18.3"H. Tabletop weight capacity is 150 lbs, shelf weight capacity is 33 lbs, and middle wood weight capacity is 44 lbs.



Image: TV size compatibility. This TV stand is suitable for televisions up to 80 inches.

The Nordivale Fireplace TV Stand combines a classic farmhouse design with modern functionality. It features a 36-inch electric fireplace, multiple storage options, and a durable wood construction. The unit is designed for stability and ease of use, providing both aesthetic appeal and practical utility for your living space.

Key Features

- **Integrated Electric Fireplace:** Features a 36-inch electric fireplace with realistic crystal stones, offering 12 flame colors and 5 levels of brightness. It provides supplemental heat for rooms up to 400 sq. ft.
- **Adjustable Heating and Timer:** The fireplace allows temperature adjustment from 60°F to 99°F and includes a timer setting from 0 to 9 hours, controllable via remote.
- **Ambient LED Lighting:** Equipped with 12 LED colors of light strips for customizable backlighting in the storage cabinets, enhancing the visual ambiance.
- **Ample Storage:** Designed with both open and closed storage cabinets, providing space for books, DVDs, electronic devices, and other necessities.

- **Cable Management:** Features large cable holes in the storage compartments for organized wire routing.
- **Durable Construction:** Made from wood with a double tabletop for enhanced stability and durability.
- **Magnetic Stopper:** Cabinet doors include magnetic stoppers to reduce noise and ensure secure closure.



Image: Fireplace control panel and remote. Illustrates heater control (62°F-82°F adjustable), timer (0H-8H setting), flame brightness control (5 levels), and power on/off. Features include tempered glass screen, front heated vents, 3D flame effect, and crystal stone decoration.



Image: 36-inch fireplace with 12 realistic flame colors and 5 levels of brightness, capable of warming up to 400 sq. ft.



Image: Product details. Shows elegant and comfortable handles, large cable holes for wire management, open storage compartments, and magnetic stoppers for quiet door closure.

Specifications

Attribute	Detail
Brand	Nordivale
Model Name	H21430-70BKBK
Material	Wood
Color	Black&black
Size	70 IN

Item Weight	133 Pounds
Included Components	TV Stand
Fireplace Size	36 inches
TV Compatibility	Up to 80 inches
Heating Area	Up to 400 sq. ft.
Temperature Range	60°F to 99°F
Timer Settings	0 to 9 hours

Setup and Assembly

Your Nordivale Fireplace TV Stand is delivered in two separate boxes, which may arrive on different days. Please ensure you have received both packages before beginning assembly. Assembly is designed to be straightforward, typically requiring approximately 1-2 hours with two people.

Required Tools (Not Included):

- Phillips head screwdriver
- Hammer

Assembly Steps:

1. **Unpack Components:** Carefully unpack all parts from both boxes. Verify that all components and hardware listed in the included parts list are present.
2. **Identify Parts:** Lay out all wooden panels and hardware, identifying each piece according to the labels in the assembly guide.
3. **Assemble Frame:** Follow the step-by-step diagrams in the separate assembly guide to construct the main frame of the TV stand. Ensure all connections are secure.
4. **Install Shelves and Doors:** Attach interior shelves and install the glass-paneled doors using the provided hinges and magnetic stoppers.
5. **Integrate Fireplace Insert:** Carefully slide the electric fireplace insert into the designated central opening. Ensure it is flush and secure.
6. **Cable Management:** Utilize the pre-drilled cable holes to route any electronic device wires neatly through the back of the unit.
7. **Final Placement:** Position the assembled TV stand in its desired location, ensuring it is on a stable, level surface.



Image: Delivery information. The product ships in two boxes, which may be delivered on different days.

Operating Instructions

Electric Fireplace Operation:

The electric fireplace can be controlled using the included remote control or the control panel located on the unit. Ensure the unit is plugged into a standard electrical outlet.

- **Power On/Off:** Press the power button on the remote or control panel to turn the fireplace on or off.
- **Flame Color Adjustment:** Use the flame color button to cycle through 12 different flame colors.
- **Flame Brightness:** Adjust the flame brightness through 5 levels using the dedicated brightness button.
- **Temperature Control:** Set the desired room temperature between 60°F and 99°F. The heater will activate to reach and maintain this temperature.
- **Timer Setting:** Activate the timer function to automatically turn off the fireplace after a set duration, from 0 to 9 hours.

LED Light Strip Operation:

The LED light strips in the storage cabinets can be controlled independently to match the fireplace ambiance or create a different mood. Refer to the remote control for specific buttons related to LED light color and mode changes.

Maintenance and Care

- **Cleaning the Stand:** Wipe the wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Cleaning the Fireplace:** Ensure the fireplace is turned off and unplugged before cleaning. Wipe the glass and exterior surfaces with a soft, lint-free cloth. Do not spray liquids directly onto the unit.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Electrical Safety:** Periodically check the power cord for any signs of damage. Do not operate the unit with a damaged cord.

Troubleshooting

- **Fireplace Not Turning On:**
  - Check if the power cord is securely plugged into a working outlet.
  - Ensure the power switch on the unit (if present) is in the "ON" position.
  - Verify remote control batteries are functional.
- **No Heat Output:**
  - Confirm the temperature setting is higher than the current room temperature.
  - Check if the heater function is activated on the remote or control panel.
- **Lights Not Changing/Working:**
  - Ensure the LED light strips are properly connected.
  - Check remote control batteries.
- **Unusual Noises:**
  - A slight fan noise is normal during heater operation.
  - If unusual or loud noises occur, turn off and unplug the unit immediately and contact customer support.

Warranty and Support

Specific warranty details for the Nordivale 70-inch Fireplace TV Stand are typically provided with your purchase documentation. Please refer to the warranty card or contact Nordivale customer service for information regarding warranty coverage, claims, and technical support.
For assistance, please visit the official Nordivale website or contact their customer support line.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GVDWK379

More documents and user manuals: **https://manuals.plus/**