Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cofun 2505

COFUN 5-in-1 Food Processor Attachment User Manual

Model: 2505

Introduction

This manual provides instructions for the safe and efficient use of your COFUN 5-in-1 Food Processor Attachment, designed for KitchenAid Stand Mixers. This attachment transforms your stand mixer into a versatile food preparation tool, offering dicing, slicing, shredding, strip cutting, and sauce preparation capabilities. Please read these instructions thoroughly before first use and retain for future reference.

Safety Information

- Always ensure the stand mixer is turned off and unplugged before attaching, detaching, or cleaning the food processor attachment.
- Keep hands and utensils out of the feed tube and discharge chute during operation to prevent injury. Use the food pusher provided.
- Do not immerse the main body/base of the attachment in water or other liquids. Wipe clean with a damp cloth.
- Ensure all parts are correctly assembled and the interlock lid is securely in place before operating.
- Blades are sharp. Handle with extreme care during assembly, disassembly, and cleaning.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not process extremely hard foods that could damage the blades or the attachment.

Setup and Assembly

Follow these steps to correctly assemble and attach the food processor to your KitchenAid Stand Mixer.

1. **Prepare the Mixer:** Ensure your KitchenAid Stand Mixer is unplugged and the power hub cover is removed.
2. **Attach the Main Body:** Align the food processor attachment's drive shaft with the power hub on your stand mixer. Insert and twist clockwise until it locks securely into place.
3. **Insert Disc/Blade:** Select the desired disc (slicing, shredding, strip cutting, dicing, or sauce) and carefully place it onto the drive shaft inside the processing bowl.
4. **Secure the Lid:** Place the lid onto the processing bowl, ensuring it is properly aligned and locked. The interlock

mechanism prevents operation if the lid is not secured.

5. **Position the Feed Tube:** Insert the food pusher into the feed tube.



Image: Step-by-step guide for tool-free installation of the food processor attachment onto a KitchenAid stand mixer.



Image: The COFUN food processor attachment securely installed on a KitchenAid stand mixer.

Operating Instructions

Once assembled, you can begin processing food. Always ensure the mixer is on a stable surface.

1. **Prepare Food:** For optimal results, ensure food items fit comfortably into the feed tube. The extra-wide feed tube accommodates larger items, reducing pre-cutting.
2. **Place Container:** Position a bowl or container under the discharge chute to collect processed food.
3. **Power On:** Plug in the stand mixer and turn it to the recommended speed setting for the task (refer to your KitchenAid mixer manual for specific speed guidelines for attachments).
4. **Feed Food:** Gradually feed food items into the feed tube using the food pusher. Apply gentle, even pressure. Do not force food through.
5. **Turn Off:** Once processing is complete, turn off the mixer and unplug it before disassembling or removing food.

Understanding the 5-in-1 Discs:

- **Reversible Slicing/Shredding Disc:** Use for uniform slices of vegetables (e.g., cucumbers, carrots) or for shredding cheese and firmer vegetables.
- **Strip Cutting Disc:** Creates consistent strips of vegetables, ideal for stir-fries or salads.
- **Sauce Disc:** Designed for pureeing ingredients to create smooth sauces, dips, or baby food.
- **Dicing Disc:** Produces uniform diced vegetables and fruits, saving significant prep time.



Image: Overview of the 5 versatile cutting functions and their corresponding discs.



Image: Demonstrating the precision dicing function for uniform vegetable cuts.



Image: The food processor attachment in action, compatible with various KitchenAid stand mixer models.

Care and Cleaning

Proper cleaning ensures the longevity and hygiene of your food processor attachment.

1. **Disassembly:** Unplug the mixer. Carefully remove the lid, then the disc/blade, and finally detach the main body from the power hub.
2. **Dishwasher Safe Parts:** All removable components, including the processing bowl, lid, food pusher, and discs, are top-rack dishwasher safe.
3. **Hand Washing:** For best results and to prolong the life of the blades, hand washing with warm, soapy water is recommended, especially for sharp discs. Use a brush to remove any food residue.
4. **Main Body Cleaning:** The main body/base of the attachment is NOT dishwasher safe. Wipe it clean with a damp cloth. Do not immerse it in water.
5. **Drying and Storage:** Ensure all parts are completely dry before reassembling or storing. Use the provided storage

case to keep all discs and parts organized and prevent loss.



Image: Cleaning instructions, showing dishwasher-safe parts and the method for cleaning the main base.



Image: The included storage case for organizing all attachment components.

Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Attachment does not operate.	Mixer not plugged in, power hub cover not removed, attachment not securely locked, lid not properly secured.	Ensure mixer is plugged in. Remove power hub cover. Re-attach and twist the attachment until it locks. Ensure the lid is fully closed and locked.
Food is not processed evenly or gets stuck.	Food items are too large, too much pressure applied, incorrect speed setting, dull blade (unlikely for new product).	Cut food into smaller pieces if necessary. Apply gentle, even pressure with the food pusher. Adjust mixer speed. Ensure the correct disc is used for the food type.

Problem	Possible Cause	Solution
Loud noise during operation.	Attachment not properly secured, foreign object inside, processing very hard food.	Turn off and unplug the mixer. Check that the attachment is securely locked. Inspect for any obstructions. Avoid processing extremely hard items.

Product Specifications

Brand: Cofun

Model Number: 2505

Material: Plastic, Stainless Steel

Special Features: Extra-Wide Feed Tube, Interlock Lid, Storage Case, 5-in-1 Versatility, Reversible Slicing/Shredding Disc

Included Components: Food Processor Attachment, Reversible Slicing/Shredding Disc, Strip Cutting Disc, Sauce Disc, Dicing Disc, Storage Case, Food Pusher

Product Care: Removable parts are top-rack dishwasher safe. Main body/base is hand wash only (wipe clean).

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact Cofun customer service directly. Keep your purchase receipt as proof of purchase.
Contact Information: Please visit the official Cofun website or refer to your product packaging for the most up-to-date customer service contact details.

© 2026 Cofun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GVNQRLM7

More documents and user manuals: **https://manuals.plus/**