KENSID B0GVQYWBHQ

KENSID 36-Inch Wood Ceiling Fan with Light and Remote User Manual

Model: B0GVQYWBHQ

Introduction

This manual provides comprehensive instructions for the safe installation, operation, and maintenance of your KENSID 36-inch wood ceiling fan with light and remote control. Please read this manual thoroughly before installation and retain it for future reference.

Important Safety Instructions

- Ensure power is disconnected at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes.
- Consult a qualified electrician if you are unsure about wiring procedures.
- The fan must be mounted to a structurally sound ceiling joist or outlet box capable of supporting the fan's weight.
- Do not bend blade holders during installation or cleaning.
- Keep children away from the fan during operation.
- Do not operate the fan with damaged blades.
- To protect the wood blades, avoid direct exposure to rain.

Package Contents

Verify that all components listed below are included in your package:

- Ceiling Fan Motor Assembly
- 5 Wood Fan Blades
- Light Kit with Acrylic Cover
- Remote Control
- Wall Switch (for optional use)
- 5-inch Downrod

- 10-inch Downrod
- Mounting Bracket
- Hardware Pack (screws, wire nuts, etc.)
- Installation Guide

Installation Guide

1. Mounting the Fan

The KENSID 36-inch ceiling fan is designed for downrod mount installation. It includes both 5-inch and 10-inch downrods to accommodate various ceiling heights. The fan can be installed on flat ceilings or sloped ceilings up to 15 degrees. For slopes exceeding 15 degrees, a special tilt kit may be required; contact customer support for assistance.



Image: KENSID 36-inch ceiling fan illustrating included downrods (5" and 10") and installation options for flat and sloped ceilings. The fan has a total height of 16" with the 5" downrod and 21" with the 10" downrod. If the ceiling tilt angle exceeds 15 degrees, a tilt kit is needed.

Steps:

1. Secure the mounting bracket to a ceiling joist or an approved outlet box.
2. Assemble the downrod with the motor housing, feeding wires through the downrod.
3. Hang the fan assembly onto the mounting bracket.
4. Connect electrical wiring according to local codes (Live, Neutral, Ground).

2. Attaching Fan Blades

Carefully attach the five wood fan blades to the motor housing using the provided screws. Ensure all screws are tightened securely.

3. Installing the Light Kit

Connect the light kit wiring to the fan motor wiring. Secure the light kit assembly to the bottom of the fan motor housing. Install the acrylic cover.

Operating Instructions

Your KENSID ceiling fan can be operated using the included remote control or an optional wall switch.

Remote Control Functions:

- **Power On/Off:** Turns the fan and light on or off.
- **Fan Speed Control:** Adjusts fan speed through 6 levels.
- **Light On/Off:** Controls the light independently.
- **Light Dimming:** Adjusts light brightness from 10% to 100%.
- **Color Temperature Adjustment:** Cycles through 3 color temperatures: 3000K (warm yellow), 4500K (natural light), and 6000K (cool white).
- **Timer Function:** Sets the fan to turn off automatically after 1, 4, or 8 hours.
- **Fan Direction (Reversible Motor):** Switches between forward mode (summer, downward airflow) and reverse mode (winter, upward airflow for air circulation).

Memory Function:

The fan features a memory function. After being turned off for 10 seconds and then restarted, it will automatically resume the last used fan speed and lighting mode settings.

Care and Maintenance

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Care:** The paulownia wood blades are handcrafted. To maintain their appearance and integrity, avoid direct exposure to rain or excessive moisture.
- **Light Source:** The LED light is replaceable. Refer to the specifications for compatible replacement types.
- **Tightness Check:** Annually check all screws and connections for tightness to ensure safe operation.

Troubleshooting Guide

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fan does not start	No power supply; Loose wire connections; Remote control battery low.	Check circuit breaker; Verify all wire connections; Replace remote control battery.
Light does not work	Loose wire connection; Faulty LED module.	Check light kit wiring; Contact customer support for LED module replacement.
Fan wobbles	Loose blade screws; Uneven blade weight; Loose mounting bracket.	Tighten all blade screws; Check for balanced blades; Ensure mounting bracket is secure.
Remote control not responding	Battery low or incorrectly installed; Remote not paired.	Replace battery, ensure correct polarity; Refer to remote pairing instructions (if applicable).

Product Specifications

Feature	Detail
Brand	KENSID
Model Number	B0GVQYWBHQ
Product Dimensions	36"D x 36"W x 10"H (with 5" downrod)
Blade Length	18 inches
Downrod Lengths Included	5 inches, 10 inches
Number of Blades	5
Blade Material	Paulownia Wood
Motor Type	DC Reversible Motor
Noise Level	Under 30 dB
Number of Speeds	6
Light Type	Dimmable LED
Color Temperatures	3000K, 4500K, 6000K
Control Method	Remote Control, Wall Switch (optional)
Voltage	110 volts
Wattage	25 watts
Indoor/Outdoor Use	Indoor, Covered Outdoor (not directly exposed to rain)
Certification	CE

Warranty and Customer Support

KENSID prioritizes customer satisfaction. This LED ceiling fan includes a 2-year customer support period. If you

have any questions, concerns, or require assistance with installation or operation, please contact KENSID customer support. Refer to your purchase documentation for contact details.