Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nonbliep Wireless Controller

Nonbliep Wireless Controller User Manual for Nintendo Switch and PC

Model: Wireless Controller

Introduction

Thank you for purchasing the Nonbliep Wireless Controller. This controller is designed to enhance your gaming experience across multiple platforms, including Nintendo Switch, Switch Lite, Switch OLED, Windows PC, Android, and iOS devices. It features Bluetooth connectivity, Turbo function, Gyro Axis, Dual Vibration, and a Screenshot button for versatile gameplay.
Please read this manual carefully before use to ensure proper operation and to maximize your enjoyment of the product.

Package Contents

- 2 x Nonbliep Wireless Controllers
- 2 x USB-C Charging Cables
- 1 x User Manual

Controller Layout



Image: Top and side view of the Nonbliep Wireless Controller with all buttons and ports clearly labeled. This includes the Left Stick, D-Pad, Turbo button, HOME button, Capture button, Right Stick, A/B/X/Y buttons, LED indicators, R, L, ZR, ZL triggers, and USB-C port.

Familiarize yourself with the controller's buttons and their functions:

- **Left Stick:** Movement and navigation.
- **D-Pad:** Directional input.
- **Turbo Button (T):** Activates/deactivates Turbo function.
- **HOME Button (H):** Returns to system home screen, powers on/off, and wakes up the console.
- **Capture Button:** Takes screenshots.
- **Right Stick:** Camera control and navigation.
- **A/B/X/Y Buttons:** Action buttons.
- **L/R Buttons:** Shoulder buttons.
- **ZL/ZR Buttons:** Trigger buttons.
- **USB-C Port:** For charging the controller.
- **LED Indicators:** Display connection status, player number, and charging status.

Setup and Pairing

Pairing with Nintendo Switch / Switch Lite / Switch OLED



Image: The Nonbliep Wireless Controller shown alongside various compatible devices including Nintendo Switch, Switch OLED, Switch Lite, Windows PC, and iOS/Android devices, illustrating its broad compatibility.

1. From the HOME Menu of your Nintendo Switch, select "Controllers" > "Change Grip/Order".
2. On the controller, press and hold the **HOME (H)** button for 3-5 seconds until the LED indicators start flashing rapidly.
3. The controller will automatically pair with your Switch. Once paired, the LED indicator(s) corresponding to the player number will remain solid.

One-Button Wake-Up Function



Image: The Nonbliep Wireless Controller highlighting the HOME button, indicating its use for waking up the Nintendo Switch console.

To wake up the Nintendo Switch console from sleep mode, simply press the **HOME (H)** button on the controller. (Note: This function may not be compatible with all generations of Switch consoles.)

Pairing with Windows PC / Android / iOS

The controller can also be connected to Windows PC, Android, and iOS devices via Bluetooth. The specific pairing steps may vary slightly depending on your device's operating system.

1. Ensure Bluetooth is enabled on your PC, Android, or iOS device.
2. On the controller, press and hold the **HOME (H)** button for 3-5 seconds until the LED indicators start flashing rapidly.
3. On your device, search for new Bluetooth devices and select "Pro Controller" or a similar name when it appears.
4. Once connected, the LED indicator(s) on the controller will become solid.

Operating Instructions

Turbo Function



Image: Illustration of the Turbo function on the Nonbliep Wireless Controller, showing the 'T' button and three adjustable turbo speeds (8, 15, 25 shots per second).

The Turbo function allows for rapid, automatic pressing of a button. This controller supports both manual and auto Turbo modes with three adjustable speeds.

- **To activate Turbo:** Press and hold the **Turbo (T)** button, then press the action button (A/B/X/Y, L/R, ZL/ZR) you wish to set to Turbo. Release both buttons. The button will now continuously register presses as long as you hold it down.
- **To activate Auto Turbo:** Repeat the above step. The button will now continuously register presses without needing to be held down.
- **To adjust Turbo speed:** While holding the **Turbo (T)** button, move the Right Stick Up or Down to cycle through the three available speeds (8, 15, or 25 rounds/second).
- **To deactivate Turbo:** Repeat the activation step for the specific button until the Turbo function is off, or press the **Turbo (T)** button and then the action button twice.

Dual Vibration and Motion Control (Gyro Axis)



Image: Depiction of the Nonbliep Wireless Controller highlighting its dual vibration motors for haptic feedback and built-in 6-axis gyro motion sensors for precise motion control in games.

The controller features built-in dual motion motors that provide 4-level adjustable vibration feedback, enhancing your gaming immersion. The integrated 6-axis gyro motion sensors allow for precise motion control in compatible games, offering a more interactive experience.

- **Adjusting Vibration:** The vibration intensity can typically be adjusted within the game settings or console settings, if supported.
- **Motion Control:** The gyro axis automatically activates in games that support motion sensing.

Screenshot Function

To capture a screenshot during gameplay, simply press the **Capture** button located on the controller. The screenshot will be saved to your console or device's gallery.

Charging the Controller



Image: The Nonbliep Wireless Controller highlighting its built-in 500mAh rechargeable battery, showing 8-10 hours working time, 2-3 hours charging time, and 720 hours standby time, along with its ergonomic design.

The Nonbliep Wireless Controller is equipped with a built-in 500mAh rechargeable battery.

- **Charging:** Connect the controller to a USB power source (e.g., console, PC, USB wall adapter) using the provided USB-C charging cable. The LED indicators will flash during charging and turn off or remain solid when fully charged, depending on the controller's state.
- **Charging Time:** Approximately 2-3 hours for a full charge.
- **Working Time:** Up to 8-10 hours of continuous gameplay on a full charge.
- **Standby Time:** Up to 720 hours.

Maintenance

- Keep the controller dry and away from moisture.
- Avoid exposing the controller to extreme temperatures.
- Clean the controller with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.

- Store the controller in a safe place to prevent damage from drops or impacts.
- Do not attempt to disassemble or modify the controller, as this will void any potential warranty.

Troubleshooting

Problem	Solution
Controller does not pair with device.	• Ensure the controller is charged. • Make sure Bluetooth is enabled on your device. • Try restarting both the controller (by holding the HOME button for 10 seconds) and your device. • Remove previous Bluetooth pairings for the controller on your device and attempt to pair again. • Ensure the controller is within the 10-meter wireless range.
Buttons are unresponsive or delayed.	• Check the controller's battery level. • Ensure there are no obstructions between the controller and the device. • Try re-pairing the controller. • If playing on PC, ensure drivers are up to date.
Controller disconnects frequently.	• Ensure the controller is fully charged. • Reduce the distance between the controller and the device. • Minimize interference from other wireless devices. • Try re-pairing the controller.
Turbo function not working.	• Ensure you are following the correct steps to activate Turbo (press T + action button). • Try deactivating and reactivating the Turbo function.

Specifications

- **Model:** Wireless Controller
- **Connectivity:** Bluetooth
- **Compatibility:** Nintendo Switch / Switch Lite / Switch OLED, Windows PC, Android, iOS
- **Battery Capacity:** 500mAh rechargeable lithium-ion
- **Charging Time:** Approximately 2-3 hours
- **Working Time:** Up to 8-10 hours
- **Standby Time:** Up to 720 hours
- **Wireless Range:** Up to 10 meters (33 feet)
- **Special Features:** Turbo function (3 speeds), Dual Vibration (4 levels), 6-axis Gyro Motion Control, Screenshot function, One-button wake-up.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GVXJFN8G

More documents and user manuals: **https://manuals.plus/**