Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jojoka YOBBZID

Jojoka 63 Inch TV Stand with 14 Fabric Drawers Instruction Manual

Model: YOBBZID | Brand: Jojoka

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Jojoka 63 Inch TV Stand with 14 Fabric Drawers. Please read all instructions carefully before assembly and use to ensure safe and proper functionality of the product. Keep this manual for future reference.



Image: The Jojoka 63 Inch TV Stand in white, showcasing its overall design and 14 fabric drawers.

Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- **Anti-Tip Mechanism:** Always install the included anti-tip safety mechanism to secure the TV stand to the wall. This prevents accidental tipping, especially important in households with children or pets.
- **Weight Capacity:** Do not exceed the maximum weight capacity of the tabletop (110 lbs) or individual drawers (small drawers 18 lbs, large drawers 22 lbs). Overloading can cause structural failure.
- **Stable Placement:** Place the TV stand on a flat, level surface to prevent wobbling. Adjust the leveling glides at the base if necessary.
- **Power Outlets:** Use the integrated power outlets and USB ports responsibly. Do not overload the circuit. Ensure cables are routed safely to avoid tripping hazards.
- **Assembly:** Follow all assembly instructions carefully. Do not use power tools for assembly unless specified, as this may overtighten screws and damage components.
- **Children:** Keep small parts and packaging materials away from children during assembly.

Image: Diagram illustrating the overall dimensions of the TV stand (63" W x 13.8" D x 29.5" H), tabletop weight capacity (110 lbs), and individual drawer weight capacities (18 lbs for small, 22 lbs for large).

Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x Jojoka 63 Inch TV Stand Frame
- 14 x Fabric Drawers (various sizes)
- 1 x Accessory Kit (includes screws, bolts, anti-tip kit, power strip)
- 1 x Instruction Manual

Setup and Assembly

Follow these steps for proper assembly. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface (like a carpet) to prevent scratches.
2. **Assemble Frame:** Connect the metal frame components using the provided screws and tools. Ensure all connections are secure but do not overtighten until the frame is fully assembled.
3. **Attach Wooden Panels:** Secure the wooden top panel and any other wooden support panels to the frame.
4. **Install Power Outlet:** Integrate the power strip into the designated slot on the tabletop. Ensure it is firmly seated.
5. **Insert Drawers:** Unfold the fabric drawers and insert the bottom panel into each. Place the assembled drawers into their respective slots in the frame.
6. **Install Anti-Tip Kit:** Attach the anti-tip strap to the back of the TV stand and secure it to a wall stud using the provided hardware. This is a critical safety step.
7. **Adjust Leveling Glides:** Once the stand is in its final position, adjust the leveling glides at the bottom of the legs to ensure the unit is stable and does not wobble.

Image: Detailed view of the TV stand's construction, highlighting the anti-tip mechanism, stable metal frame, wooden grain panels, and the texture of the fabric drawers.

Image: Illustration of the TV stand's stable construction with four rubber wood support legs, demonstrating the clearance underneath for robotic vacuum cleaners.

Operating Instructions

Using the Power Outlets

The integrated power station provides convenient access to power for your electronic devices.

- Plug the TV stand's power cord into a standard wall outlet.
- Use the 2 AC outlets for devices such as TVs, gaming consoles, or lamps.
- Use the 2 USB ports to charge smartphones, tablets, or other USB-powered devices.

- Ensure that the total power draw of connected devices does not exceed the power strip's rated capacity.



Image: The TV stand's desktop featuring the built-in power strip with 2 AC outlets and 2 USB ports, illustrating common devices like laptops, lamps, speakers, and mobile phones that can be connected.



Image: A close-up view of a smartphone charging via one of the USB ports on the integrated power strip, demonstrating its functionality.

Using the Fabric Drawers

The 14 fabric drawers provide versatile storage for various household items.

- Gently pull the handles to open and push to close the drawers. They are designed for smooth operation.
- Organize items such as clothing, bedding, books, toys, or media accessories.
- Do not overload drawers beyond their specified weight capacity (18 lbs for small, 22 lbs for large).



Image: Visual representation of the 14 fabric drawers, highlighting their key attributes: easy to clean, durable and scratch-proof material, high stability, and large storage capacity.



Image: An open view of the TV stand's interior, demonstrating the ample storage provided by the 14 fabric drawers, organized with various items like folded clothes, towels, and accessories.

Maintenance

Cleaning

- **Frame and Wooden Panels:** Wipe clean with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Drawers:** Spot clean with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash or tumble dry.
- **Power Outlets:** Ensure the power strip is unplugged from the wall before cleaning. Wipe the surface with a dry cloth. Do not use liquid cleaners near electrical components.

General Care

- Regularly check all screws and connections to ensure they remain tight. Retighten if necessary.
- Avoid exposing the unit to direct sunlight or extreme temperature changes, which can affect the material.
- Do not place hot items directly on the wooden top panel without protection.

Troubleshooting

Problem	Possible Cause	Solution
TV stand wobbles	Uneven floor; loose connections	Adjust leveling glides at the base. Check and tighten all screws.

Problem	Possible Cause	Solution
Drawers do not slide smoothly	Overloaded drawer; obstruction	Reduce contents in the drawer. Check for any items blocking the drawer's path.
Power outlets not working	Power cord unplugged; circuit overload; faulty outlet	Ensure the main power cord is securely plugged into a wall outlet. Unplug some devices to check for overload. Test the wall outlet with another device.
Anti-tip kit not secure	Improper installation; weak wall anchor	Re-install the anti-tip kit, ensuring it is anchored into a wall stud. Consult a professional if unsure.

Specifications

Brand	Jojoka
Model	YOBBZID
Product Dimensions (Overall)	63" W x 13.8" D x 29.5" H
Item Weight	48.7 Pounds
Material	Wood (panels), Metal (frame), Non-woven Fabric (drawers)
Number of Drawers	14
TV Size Compatibility	Up to 75 inches
Tabletop Weight Capacity	110 lbs
Drawer Weight Capacity	Small: 18 lbs, Large: 22 lbs
Power Outlets	2 AC Outlets, 2 USB Ports
Assembly Required	Yes

Warranty and Support

For warranty information, missing parts, or technical assistance, please contact Jojoka customer support through the retailer where the product was purchased. Please have your model name and purchase date available when contacting support.
You can also visit the official Jojoka store for more information:Jojoka Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GVY9M21F

More documents and user manuals: **https://manuals.plus/**