WINNY POOL CLEANER B1

WINNY B1 Robotic Pool Cleaner User Manual

Model: B1

Introduction

Thank you for choosing the WINNY B1 Robotic Pool Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read this manual thoroughly before first use and retain it for future reference.



Figure 1: WINNY B1 Robotic Pool Cleaner main unit.

Important Safety Instructions

- Read all instructions carefully before operating the appliance.
- Do not operate the cleaner when people are in the pool.
- Ensure the charging port is dry and securely sealed before placing the cleaner in water.
- Use only the charger supplied by the manufacturer.
- Keep the cleaner out of reach of children.
- Do not attempt to repair the cleaner yourself. Contact authorized service personnel.
- The unit is rigorously water-tested at the factory. Minor water marks inside the unit are normal and do not indicate a defect.

Setup

1. Initial Charging

Before first use, fully charge the WINNY B1. The charging time is approximately 3 hours. Connect the charger to the cleaner's charging port and plug it into a power outlet. The indicator light will show charging status.



Figure 2: Charging port location (illustrative).

2. App Installation and Connection

1. Download the official WINNY app from your smartphone's app store.
2. Ensure your smartphone's Bluetooth is enabled and your Wi-Fi signal reaches the pool area for initial setup.
3. Follow the in-app instructions to pair your WINNY B1 cleaner. You may need to select your pool material and shape within the app.



Figure 3: WINNY app interface (illustrative).

3. Initial Placement in Pool

Once charged and connected, carefully lower the WINNY B1 into the pool. It is designed to be lightweight (14.3 lbs) for easy handling. Ensure it settles flat on the pool floor.
Note: The package may include flotation blocks. These are typically used to adjust buoyancy for specific pool types or conditions. Refer to the app or WINNY support for guidance on their use if needed.

Operating Instructions

1. Cleaning Modes and Navigation

The WINNY B1 features smart navigation with 5 selectable modes, adaptable to various pool layouts. Use the app to select your desired cleaning mode:

- **Floor Cleaning:** Focuses on the pool floor, efficiently removing debris.
- **Wall Cleaning:** Climbs pool walls to scrub and clean the waterline.

- **Full Coverage:** Cleans both the floor and walls for a comprehensive clean.
- **Quick Clean:** A 1-hour option for lighter maintenance.
- **Spot Cleaning:** For targeted cleaning of specific areas (if available via app).

The cleaner is equipped with extra bottom roller brushes for superior traction, allowing it to glide over drains, seams, and uneven floors without interruption. Dual front side brushes ensure precise cleaning of edges and corners.



Figure 4: WINNY B1 operating on a pool floor (illustrative).

2. Runtime

The WINNY B1 provides up to 100 minutes of continuous cleaning on a full charge, suitable for pools up to 1150 sq. ft. The 1-hour quick clean mode is ideal for routine maintenance.

Maintenance

1. Filter Basket Cleaning

After each cleaning cycle, or when the filter basket is full, it is essential to clean it. The WINNY B1 features a large, top-loading filter basket for easy access.

1. Carefully remove the cleaner from the pool. The quick-drain design allows water to exit rapidly, reducing weight.
2. Open the top access compartment.
3. Remove the filter basket.
4. Rinse the collected leaves, sand, hair, and debris from the basket using a garden hose.
5. Reinsert the clean filter basket and securely close the top access compartment.



Figure 5: Top-loading filter basket (illustrative).

2. Software Updates (OTA)

The WINNY B1 supports Over-The-Air (OTA) firmware updates. Ensure your cleaner is connected to the app and has a stable internet connection to receive updates that improve performance and add new features. Check the app regularly for available updates.

Troubleshooting

Problem	Possible Cause	Solution
Cleaner not moving or stuck.	Debris caught in brushes or wheels; low battery.	Remove cleaner from pool, inspect and clear any obstructions. Recharge the unit.
Poor cleaning performance.	Full or dirty filter basket; incorrect cleaning mode selected.	Clean the filter basket thoroughly. Select a more appropriate cleaning mode via the app (e.g., Full Coverage). For very fine silt, a second cleaning cycle may be beneficial.
Cleaner not climbing walls effectively.	Low battery; specific pool surface material (e.g., acrylic) may reduce traction.	Ensure the unit is fully charged. Wall climbing performance can vary with pool surface types. Ensure brushes are clean and not worn.
App connection issues.	Weak Wi-Fi signal; Bluetooth off; app not updated.	Ensure strong Wi-Fi signal near the pool. Verify Bluetooth is active on your device. Update the WINNY app to the latest version.
Difficulty opening filter compartment latch.	Latch mechanism may be stiff.	Apply firm, even pressure to the latch. If persistent, contact customer support.

Specifications

Brand	WINNY POOL CLEANER
Model Name	B1
Material	Plastic, Polypropylene
Color	GrayBlue
Product Dimensions (L x W x H)	13.8" x 13.7" x 9.3"
Weight	14.3 lbs (approx.)
Power Source	Battery Powered
Control Method	App
Voltage	22.2 volts
Battery Type	Lithium-Ion (1 Nonstandard Battery required, included)
Lithium Battery Energy Content	57.72 watt-hours
Battery Weight	305 g
Charging Time	3 hours
Capacity (Filter)	2 liters

Max Pool Size	Up to 1150 sq. ft.
Installation Type	Robotic

Warranty and Support

Warranty Information

The WINNY B1 Robotic Pool Cleaner comes with a**1-year comprehensive protection** (Limited Warranty) from the date of purchase. This warranty covers manufacturing defects and ensures peace of mind. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, warranty claims, or any questions regarding your WINNY B1 Robotic Pool Cleaner, please contact WINNY POOL CLEANER customer support. Refer to the product packaging or the official WINNY website for the most current contact information.
Manufacturer: winny Pool Cleaner

© 2026 WINNY POOL CLEANER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question