Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DASH DMIC10005

DASH Disney Stitch My Mug Ice Cream Maker DMIC10005 Instruction Manual

Model: DMIC10005

Introduction

Welcome to the DASH Disney Stitch My Mug Ice Cream Maker instruction manual. This appliance is designed to create delicious single-serve frozen treats, including ice cream, sorbet, and frozen yogurt, directly in a collectible Disney Stitch mug. Please read these instructions thoroughly before first use to ensure safe and optimal operation.

Important Safeguards

To prevent personal injury or property damage, please adhere to the following safety precautions:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Parts & Features

Familiarize yourself with the components of your Ice Cream Maker:

- **Freezer Mug:** The insulated mug where ingredients are churned.
- **Motor with Lid:** Houses the motor and covers the mug during operation.
- **Stirring Paddle:** Attaches to the motor to churn ingredients.
- **Ingredient Chute:** Opening on the lid to add mix-ins during churning.



Image: An exploded view of the DASH Disney Stitch My Mug Ice Cream Maker showing the freezer mug, stirring paddle, and motor with lid.

Before First Use

Before using your Ice Cream Maker for the first time, follow these steps:

1. Wash the Freezer Mug, Stirring Paddle, and Lid in warm, soapy water. Rinse thoroughly and dry completely.
2. Wipe the Motor Base with a damp cloth. Do not immerse the Motor Base in water.
3. Ensure all parts are completely dry before assembly and use.

Setup

Proper setup is crucial for optimal performance:

1. **Freeze the Mug:** Place the empty Freezer Mug in your freezer for 24-48 hours. The mug must be completely frozen for the ice cream to churn properly.
2. **Prepare Ingredients:** Chill your ice cream mixture in the refrigerator for at least 2 hours before churning. This ensures the mixture is cold enough for quick freezing.
3. **Assemble:** Once the mug is frozen and ingredients are chilled, place the Stirring Paddle inside the Freezer Mug.
4. **Attach Motor:** Place the Motor with Lid onto the Freezer Mug, ensuring the stirring paddle engages with the motor mechanism.



Image: A visual guide showing the four main steps: freezing the mug, preparing ingredients, assembling the unit, and adding mix-ins.

Operating Instructions

Follow these steps to make your frozen treat:

1. Ensure the Freezer Mug is completely frozen (24-48 hours in freezer).

2. Place the Stirring Paddle inside the frozen Freezer Mug.
3. Attach the Motor with Lid onto the Freezer Mug.
4. Pour your chilled ice cream mixture through the Ingredient Chute into the Freezer Mug. Do not overfill; leave space for expansion.
5. Plug the appliance into a standard electrical outlet. The motor will begin to churn.
6. Allow the mixture to churn for approximately 20-25 minutes, or until it reaches your desired soft-serve consistency.
7. During the last 5 minutes of churning, you can add mix-ins like chocolate chips, sprinkles, or fruit through the Ingredient Chute.
8. Once desired consistency is reached, unplug the appliance.
9. Remove the Motor with Lid and Stirring Paddle.
10. Serve the soft-serve directly from the Stitch Mug. For a firmer consistency, transfer the ice cream to an airtight container and freeze for an additional 3-4 hours.

Your browser does not support the video tag.

Video: An official demonstration of the Dash My Mug Ice Cream Maker in operation, showing the churning process and final product.

Maintenance & Cleaning

Regular cleaning ensures the longevity and hygiene of your appliance:

1. Always unplug the Ice Cream Maker before cleaning.
2. Disassemble the Motor with Lid, Stirring Paddle, and Freezer Mug.
3. Wash the Freezer Mug, Stirring Paddle, and Lid in warm, soapy water. These parts are not dishwasher safe.
4. Rinse all washed parts thoroughly and dry completely before storing.
5. Wipe the Motor Base with a damp cloth. Do not immerse the Motor Base in water or place it in a dishwasher.
6. For compact storage, the Stirring Paddle and Motor with Lid can be nested inside the Freezer Mug.



Image: The Dash My Mug Ice Cream Maker disassembled, illustrating its easy-to-clean components and compact storage design.

Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Ice cream is not freezing or is too soft.	Freezer Mug not sufficiently frozen. Ingredients not chilled.	Ensure Freezer Mug is frozen for 24-48 hours. Chill ingredients for at least 2 hours before use.
Motor stops during churning.	Mixture is too thick or frozen solid. Overfilling the mug.	Unplug, remove some mixture, or allow it to soften slightly. Do not exceed the maximum fill line.
Stirring Paddle is not turning.	Paddle not correctly assembled. Motor not properly seated.	Check that the Stirring Paddle is correctly inserted and the Motor with Lid is securely attached.

Specifications

Technical details for the DASH Disney Stitch My Mug Ice Cream Maker:

- **Model Name:** Ice Cream Maker
- **Model Number:** DMIC10005
- **Brand:** DASH
- **Color:** Disney Stitch Blue
- **Capacity:** 0.5 pints
- **Special Feature:** Insulated freezer bowl
- **Operation Mode:** Automatic
- **Item Weight:** 2.6 pounds
- **UPC:** 810137398075
- **Manufacturer:** StoreBound LLC



Image: The Disney Stitch My Mug Ice Cream Maker showing its approximate dimensions of 5.5 inches in height and 7 inches in width.

Warranty

The DASH Disney Stitch My Mug Ice Cream Maker comes with a **2-Year Warranty**. To activate your warranty, product registration is required. Please visit bydash.com for more details and to register your product.

Customer Support

For any questions, concerns, or assistance with your DASH Disney Stitch My Mug Ice Cream Maker, please visit the official DASH website or contact their customer service department. Refer to the product packaging or the DASH website for the most current contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GXWMCSF9

More documents and user manuals: **https://manuals.plus/**