Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VIKIO HOME OW01-KNOB

VIKIO HOME 24-Inch Wall Oven (Model OW01-KNOB) Instruction Manual

Model: OW01-KNOB

1. Introduction

Thank you for choosing the VIKIO HOME 24-inch Wall Oven. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read these instructions thoroughly before using the oven and retain them for future reference.



Image 1.1: The VIKIO HOME 24-inch wall oven in a kitchen setting.

2. Safety Instructions

WARNING: To reduce the risk of fire, electric shock, injury to persons, or damage when using the oven, follow basic precautions, including the following:

- Read all instructions before using the appliance.
- Ensure the oven is properly installed and grounded by a qualified technician.
- Do not touch hot surfaces. Use oven mitts or pot holders.
- Never use the oven for warming or heating the room.
- Do not store flammable materials in or near the oven.
- Supervise children closely when they are near the appliance.
- Always disconnect power before servicing the oven.
- The oven door features a triple-layer tempered glass construction. While designed to retain heat and keep the outer surface

at a safe temperature, exercise caution.

3. Product Overview

The VIKIO HOME OW01-KNOB is a 24-inch electric wall oven designed for built-in installation. It features mechanical knob controls for ease of use and offers 8 distinct cooking functions. With a spacious 2.83 cubic feet (80 liters) interior, it accommodates various cooking needs.

Key Features:

- **Extra-Large Capacity:** 2.83 Cu.Ft (80 Liters) interior for cooking larger meals.
- **8 Cooking Modes:** Versatile functions including Rotisserie Chicken, Bread, Frozen Beef, Bake Cake, Convection Pizza, Broil Steak, Roast Potato, and Broil Sandwiches.
- **Mechanical Knob Controls:** Intuitive and straightforward operation.
- **Uniform and Rapid Heating:** Three high-performance heating elements and 360° circulating hot-air convection system ensure even cooking.
- **Thoughtful Design:** Triple-layer tempered glass door for safety and easy monitoring, with a detachable design for cleaning.



Image 3.1: Illustration of the oven's 2.83 Cu.Ft large capacity.

4. Installation

4.1 Dimensions and Cutout Requirements

The oven measures 23.43" (W) × 21.5" (D) × 23.43" (H). For proper installation, a cutout of 22.05" (W) × 21.65" (D) × 23.19" (H) is required. Ensure a minimum 2.76-inch opening at the bottom rear of the cabinet for ventilation.



Image 4.1: Oven dimensions and cabinet cutout requirements.

4.2 Electrical Connection

This electric oven operates on 240 volts and has a wattage of 3220 watts. Installation must be performed by a qualified electrician in accordance with all local codes and ordinances.

4.3 Included Accessories

The following accessories are included with your oven:

- 1 Rotisserie Spit Set
- 2 Stainless Steel Wire Racks
- 1 Enamel Baking Tray
- 1 Retrieval Handle




Image 4.2: Overview of included accessories.

5. Operating Instructions

5.1 Control Panel Overview

The oven features intuitive mechanical knob controls. Simply rotate the dials to select your desired cooking function and temperature.



Image 5.1: Mechanical knob controls for function and temperature selection.

5.2 Cooking Functions

The oven offers 8 preset cooking modes:

- **Rotisserie Chicken:** Ideal for evenly roasting poultry.
- **Bread:** Optimized for baking various types of bread.
- **Frozen Beef:** Suitable for cooking frozen meat products.
- **Bake Cake:** Perfect for baking cakes and pastries.
- **Convection Pizza:** Utilizes convection for crispy pizza crusts.
- **Broil Steak:** High heat for searing and broiling steaks.
- **Roast Potato:** For perfectly roasted potatoes.
- **Broil Sandwiches:** For toasting and broiling open-faced sandwiches.



Image 5.2: Visual representation of the 8 cooking modes.

5.3 Temperature Settings and Convection

The oven offers a wide temperature range from 50°F to 480°F. The true hot-air convection system ensures 360° circulating heating for uniform results and rapid preheating.




Image 5.3: Oven temperature range and suggested uses.



Image 5.4: Illustration of the oven's three heating elements and convection system.

6. Care and Maintenance

6.1 Cleaning the Oven Interior

Allow the oven to cool completely before cleaning. Use a damp cloth with mild detergent to wipe down the interior surfaces. For stubborn stains, use a non-abrasive oven cleaner according to the product instructions. Avoid using abrasive cleaners or scouring pads that can damage the oven's finish.

6.2 Cleaning the Oven Door

The oven door can be easily detached for convenient cleaning of crevices and interior lining edges. Refer to the detailed instructions in the full manual for safe door removal and reinstallation. Clean the tempered glass with a soft cloth and glass cleaner. Do not use harsh abrasive cleaners or sharp metal scrapers on the oven door glass as they can scratch the surface, which may result in shattering of the glass.

6.3 Cleaning Accessories

Wire racks and baking trays can be washed with warm, soapy water. The rotisserie spit set should also be cleaned after each use.

7. Troubleshooting

If you encounter issues with your oven, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not heat	No power supply; circuit breaker tripped; incorrect function/temperature setting.	Check power connection; reset circuit breaker; verify function and temperature knobs are correctly set.
Uneven cooking	Improper rack position; overcrowded oven; dirty convection fan.	Use recommended rack positions; avoid overcrowding; clean convection fan area.
Oven light not working	Bulb is loose or burned out.	Tighten or replace the oven light bulb (ensure oven is cool and power is disconnected).
Excessive smoke during cooking	Food spills; excessive grease buildup; incorrect temperature setting.	Clean oven interior thoroughly; reduce cooking temperature if necessary.

If the problem persists after attempting these solutions, please contact customer support.

8. Specifications

Detailed technical specifications for the VIKIO HOME OW01-KNOB Wall Oven:

Feature	Detail
Model Name	OW01-KNOB
Size	24 Inch
Capacity	2.83 cubic feet (80 Liters)
Installation Type	Built-In
Color	Black
Heating Method	Convection
Fuel Type	Electric
Voltage	240 volts
Wattage	3220 watts
Item Dimensions (D x W x H)	27.01"D x 26.38"W x 29.72"H (Overall)
Required Cutout Dimensions (W x D x H)	22.05"W x 21.65"D x 23.19"H
Item Weight	95.5 pounds
Material Type	Stainless Steel

Feature	Detail
Included Components	1 rotisserie spit set, 2 stainless steel wire racks, 1 enamel baking tray, 1 retrieval handle

9. Warranty and Customer Support

9.1 Manufacturer's Warranty

The VIKIO HOME 24-inch Wall Oven (Model OW01-KNOB) is covered by a **2-Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, warranty inquiries, or to order replacement parts, please contact VIKIO HOME customer support. Refer to the contact information provided with your purchase documentation or visit the official VIKIO HOME website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GY8NLPG5

More documents and user manuals: **https://manuals.plus/**