Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Oraimo OAF-261A

Oraimo NutriFry S1 OAF-261A Air Fryer 6 Litres User Manual

Model: OAF-261A | Brand: Oraimo

Introduction Safety Instructions Product Overview Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the Oraimo NutriFry S1 OAF-261A Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods with less oil. Please read this manual thoroughly before operating the appliance and retain it for future reference. Proper use and maintenance will ensure optimal performance and extend the lifespan of your air fryer.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.
- The appliance operates at high temperatures; keep hands and face away from steam and air outlets.

3. Product Overview

The Oraimo NutriFry S1 OAF-261A Air Fryer features a full-metal design, digital touch screen, and a 6-liter capacity for versatile cooking. Familiarize yourself with its components for optimal use.



Figure 3.1: Oraimo NutriFry S1 OAF-261A Air Fryer in a kitchen setting with various cooked foods.



Figure 3.2: The Oraimo NutriFry S1 Air Fryer showcasing its full-metal design, 230°C high-temperature roasting capability, PTFE nonstick coating, ridged base plate, 7-inch viewing window, and smart touch control panel.



Figure 3.3: Detailed view of the Oraimo NutriFry S1 Air Fryer's features, including 230°C high-temperature roasting, certified PTFE nonstick coating, ridged base plate design, full-metal interior and exterior, 7-inch viewing window, and smart touch control panel.



Figure 3.4: The full-metal interior and exterior construction of the Oraimo NutriFry S1 Air Fryer, designed to be odor-free and corrosion-resistant.



Figure 3.5: Cross-section diagram illustrating the multi-layer certified PTFE nonstick coating of the air fryer basket, highlighting its scratch and wear resistance and absence of PFOA/PFOS.



Figure 3.6: Close-up of the Oraimo NutriFry S1 Air Fryer's smart touch control panel, displaying various cooking presets and temperature/time settings for easy operation.



Figure 3.7: Diagram showing safety and design features of the Oraimo NutriFry S1 Air Fryer, including auto shut-off, triple layer insulated window, anti-slip silicone feet, and rear cooling exhaust vent.

4. Initial Setup

Before using your Oraimo NutriFry S1 Air Fryer for the first time, follow these steps:

1. **Unpack:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Clean:** Wash the frying basket and air fryer base with warm, soapy water. Rinse thoroughly and dry completely. Wipe the interior and exterior of the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the appliance for proper ventilation.
4. **First Use (Burn-in):** It is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) before cooking food. This helps to burn off any manufacturing residues and eliminate initial odors. A slight smell or smoke may occur, which is normal. Ensure the area is well-ventilated.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.

5. Operating Instructions

The Oraimo NutriFry S1 Air Fryer features a digital touch control panel for easy operation. Here's how to use it:

5.1 Basic Operation

1. **Prepare Food:** Place your ingredients into the frying basket. Do not overfill the basket to allow for proper air circulation.
2. **Insert Basket:** Slide the frying basket securely into the main unit of the air fryer.
3. **Power On:** Press the **Power** button on the touch control panel to turn on the appliance.
4. **Set Temperature and Time:**
    - Use the **Temperature** and **Time** buttons, along with the **Plus (+)** and **Minus (-)** icons, to adjust the desired cooking temperature (60°C to 200°C) and time.
    - Alternatively, select one of the pre-set cooking programs by pressing the **Menu** button and cycling through the options (e.g., Fries, Chicken, Fish, Steak, Egg Tart, Fried Bread, Veggies, Corn, Potato, Yogurt).
5. **Start Cooking:** Press the **Start/Pause** button to begin the cooking process. The air fryer will automatically preheat if necessary.
6. **Monitor Cooking:** The transparent viewing window allows you to monitor the cooking progress without opening the basket.
7. **Shake/Flip (Optional):** For even cooking, especially with smaller items like fries, you may need to shake or flip the food halfway through the cooking time. The air fryer may beep to remind you. Carefully remove the basket, shake/flip, and reinsert. The auto shut-off function will pause operation when the basket is removed.
8. **End of Cooking:** Once the set time has elapsed, the air fryer will beep and automatically shut off.
9. **Remove Food:** Carefully pull out the frying basket using the handle. Use heat-resistant tongs to remove the cooked food.
10. **Cool Down:** Allow the appliance to cool down completely before cleaning or storing.

5.2 Special Features

- **Auto Shut-Off Function:** For safety, the air fryer automatically stops operation when the basket is removed and resumes when it is reinserted.
- **Transparent Viewing Window:** Allows you to check on your food without interrupting the cooking cycle.
- **Even Heat Circulation:** The 360° hot air circulation system ensures faster and more evenly cooked meals.
- **Keep Warm Function:** Use the **Keep Warm** button to maintain food temperature after cooking.

6. Cleaning and Maintenance

Regular cleaning and maintenance will ensure your air fryer remains in excellent condition.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Clean Basket and Base:** The frying basket and air fryer base are dishwasher safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak them in warm water for about 10 minutes before cleaning.
3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth and a mild detergent. Do not use abrasive cleaners or metal scouring pads.
4. **Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

7. Troubleshooting

If you encounter any issues with your Oraimo NutriFry S1 Air Fryer, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in.	Ensure the power cord is securely plugged into a grounded outlet.
	The frying basket is not inserted correctly.	Push the frying basket completely into the appliance.
Food is not cooked evenly.	Too much food in the basket.	Reduce the amount of food in the basket. Cook in smaller batches.
	Food was not shaken or flipped.	Shake or flip the food halfway through the cooking time.
White smoke comes from the appliance.	Grease residue from previous use.	Clean the basket and base thoroughly after each use.
	Cooking fatty ingredients.	This is normal for fatty foods. Ensure proper ventilation.
Food is not crispy.	Not enough oil (if applicable) or incorrect temperature/time.	Lightly brush food with oil for extra crispiness. Adjust temperature or cooking time as needed.

If the problem persists after trying these solutions, please contact customer support.

8. Product Specifications

Feature	Specification
Model Number	OAF-261A
Capacity	6 Litres
Rated Power	1500 Watts
Rated Voltage	220-240V / 50-60Hz
Temperature Range	60°C - 200°C
Control Type	Digital Touch Control
Product Dimensions (D x W x H)	35 x 30 x 32 cm
Material	Full Metal Body and Lining
Non-stick Coating	Certified PTFE (PFOA/PFOS Free)
Dishwasher Safe Parts	Frying Basket, Air Fryer Base
Special Features	Transparent Viewing Window, Auto Shut-Off, Anti-Slip Feet, Rear Cooling Exhaust Vent, Even Heat Circulation

9. Warranty and Support

9.1 Warranty Information

The Oraimo NutriFry S1 OAF-261A Air Fryer comes with a**two-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage resulting from misuse, accident, alteration, neglect, or unauthorized repair.
Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Oraimo NutriFry S1 Air Fryer, please contact Oraimo customer support through their official website or the retailer where you purchased the product.
You can typically find contact information on the Oraimo official website or by referring to the packaging materials.

© 2026 Oraimo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GYGCHY7J

More documents and user manuals: **https://manuals.plus/**