X-Vcak KC-S01

X-Vcak Upgraded 2 Person Portable Steam Sauna Tent (Model KC-S01) Instruction Manual

Introduction

This manual provides detailed instructions for the safe and effective use of your X-Vcak Upgraded 2 Person Portable Steam Sauna Tent, Model KC-S01. Please read all instructions carefully before assembly and operation to ensure proper function and safety.

The X-Vcak portable sauna is designed for two individuals, offering a convenient way to enjoy steam sauna benefits at home. It features a 5-layer waterproof design for heat retention and durability, two high-power steamers for rapid steam generation, and a user-friendly design with internal pockets and transparent windows.

Safety Information

Before using the sauna, please observe the following safety precautions:

- Consult a physician before use if you have any medical conditions, are pregnant, or are taking medication.
- Do not use the sauna for more than 30 minutes at a time.
- Stay hydrated by drinking water before, during, and after your sauna session.
- Avoid consuming alcohol or heavy meals before using the sauna.
- Keep the steamer unit on a stable, flat surface and away from flammable materials.
- Ensure proper ventilation in the room where the sauna is used.
- Do not touch the hot steam outlet or the steamer heating element during operation.
- Unplug the steamer and allow it to cool completely before cleaning or refilling.
- Keep out of reach of children and pets.

Components List

Please ensure all components are present before beginning assembly:

- Sauna Tent (1)

- Steam Generator (Steamer) (2)
- Folding Chairs (2)
- Remote Controls (2)
- Steam Hoses (2)
- Connection Pipes/Frame Components
- Floor Mat/Blanket



Image: Overview of the X-Vcak Portable Steam Sauna Kit components.

Setup and Assembly

The X-Vcak 2 Person Portable Steam Sauna Tent is designed for quick and easy assembly, typically within 3 minutes.

Sauna Tent Assembly:

1. **Install the Bottom Frame:** Assemble the base frame components and place them on a flat, stable surface.
2. **Install the Top Frame:** Connect the vertical support pipes to the bottom frame, then attach the top frame components.
3. **Zip up the Side:** Drape the sauna tent fabric over the assembled frame. Ensure the tent is correctly oriented, then zip up the side panels to enclose the frame.
4. **Place Floor Mat:** Lay the provided floor mat or blanket inside the sauna tent on the bottom.
5. **Connect Steamers:** Connect the steam hoses from the two steam generators to the designated steam inlet boxes on the sauna tent. **Attention:** Ensure the pipes are not folded or kinked, as this will obstruct steam flow.
6. **Add Water to Steamers:** Fill the steamer reservoirs with clean water up to the maximum fill line. Do not overfill.



Image: Quick installation process for the sauna tent.

Image: Detailed steps for sauna tent frame and fabric assembly (Steps 1-3).



Image: Detailed steps for placing the floor mat, connecting steamers, and filling with water (Steps 4-6).

Video Guide: Setup and Operation

Your browser does not support the video tag.

Video: A demonstration of setting up and using the portable sauna. This video provides a visual guide to the assembly process and initial operation.

Your browser does not support the video tag.

Video: Another visual guide demonstrating the setup and features of the portable steam sauna for home use.

Operating Instructions

Once the sauna tent is assembled and steamers are filled, you can begin your sauna session.

Steamer Operation:

1. Plug in both steamer units. The display will illuminate.

2. Use the remote control or the buttons on the steamer to set the desired time (up to 99 minutes) and steam level (1-9). Start with a lower level and shorter duration if you are new to steam saunas.
3. The steamers will begin to preheat and generate steam. The two high-power steamers are designed to quickly reach the desired temperature within the tent.
4. Once steam is visibly entering the tent, you may enter.

Using the Sauna Tent:

- Place the two folding chairs inside the tent for comfortable seating.
- Enter the sauna tent and close the double-pull zipper securely.
- You can extend your head through the zippered transparent window for fresh air if desired.
- Use the internal pockets to store small items like a mobile phone, ensuring they are protected from steam.
- Monitor your comfort level throughout the session. If you feel unwell, exit the sauna immediately.
- After your session, turn off the steamers and unplug them. Allow the tent and steamers to cool down before handling.



Image: Two steamers providing higher temperatures within the sauna tent.



Image: Detailed view of convenient design features including transparent windows, pockets, and zippers.



Image: Explanation of the steam sauna's operational principle.

Maintenance

Regular maintenance ensures the longevity and hygiene of your X-Vcak portable sauna.

Cleaning the Sauna Tent:

- After each use, wipe down the interior of the tent with a clean, damp cloth to remove any moisture.
- Allow the tent to air dry completely before folding and storing to prevent mold or mildew.
- For deeper cleaning, use a mild soap solution and a soft cloth. Avoid harsh chemicals or abrasive cleaners.

Cleaning the Steamers:

- Always unplug the steamer and allow it to cool before cleaning.
- Empty any remaining water from the reservoir.
- Wipe the interior and exterior of the steamer with a damp cloth.
- To remove mineral deposits, fill the reservoir with a mixture of water and white vinegar (1:1 ratio) and let it sit for 30 minutes, then rinse thoroughly.

Storage:

- Ensure all components are dry before storing.
- Fold the sauna tent neatly and store it in its original carrying bag or a dry, cool place.
- Store steamers and accessories in a safe place, away from extreme temperatures.

Troubleshooting

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
No steam generated	Steamer not plugged in; Water level too low; Steamer not turned on; Overheating protection activated.	Ensure steamer is plugged in and power is on; Fill water reservoir to appropriate level; Press power button; Unplug, let cool, then restart.
Insufficient steam/low temperature	Steam level set too low; Steamer hose kinked or blocked; Tent zipper not fully closed; Not enough preheating time.	Increase steam level setting; Check and straighten steam hoses; Ensure tent is fully zipped; Allow 5-10 minutes for preheating.
Water leakage from steamer	Overfilled reservoir; Loose lid; Damaged hose connection.	Do not exceed max fill line; Ensure lid is securely fastened; Check hose connections for tightness.
Tent unstable	Frame not fully assembled; Uneven surface.	Ensure all frame pipes are securely connected; Place sauna on a flat, level surface.

Specifications

- **Model:** KC-S01
- **Dimensions (Assembled):** 71 inches (Height) x 49 inches (Width) x 36 inches (Depth)
- **Capacity:** 2 Person
- **Item Weight:** Approximately 24.8 pounds
- **Steamer Power:** 1000W per steamer (2 steamers included)
- **Voltage:** 110V
- **Timer Settings:** Up to 99 minutes
- **Steam Levels:** 9 adjustable levels
- **Material:** 5-Layer Waterproof Fabric (Inner Layer: Reflects Heat; Layer 2: Oxford Waterproof; Layer 3: Thickened Cotton Insulating; Layer 4: High-density Cotton Traps Heat; Layer 5: Waterproof Polyester Satin Fabric)
- **Safety Features:** Protection against dry heating, Earth leakage protection
- **Inner Lining:** Stainless steel (steamer)



Image: Product dimensions of the portable sauna.



Image: Explanation of the 5-layer waterproof design for enhanced insulation.



Image: Comparison of sauna sizes and features, highlighting the 2-person model.

Warranty and Support

For warranty information, technical support, or any questions regarding your X-Vcak Upgraded 2 Person Portable Steam Sauna Tent, please contact the manufacturer directly. Refer to the product packaging or the official X-Vcak website for specific contact details and warranty terms.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question