**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Bella Depot 3670**

# Bella Depot 36-inch Wagon Wheel Chandelier Ceiling Fan

Model: 3670

## 1. Product Overview

The Bella Depot 36-inch Wagon Wheel Chandelier Ceiling Fan combines rustic farmhouse aesthetics with modern functionality. This fandelier features a natural light wood-grain finish, an ultra-quiet DC motor, and an 8-light chandelier design. It is designed for standard 8-10 ft ceilings and includes a remote control for convenient operation.




Image 1.1: The Bella Depot 36-inch Wagon Wheel Chandelier Ceiling Fan, showcasing its wood-grain finish and eight light sockets.

### Key Features:

- Authentic light wood-grain finish for a modern farmhouse style.
- Designed for 8-10 ft ceilings with a fixed 7.8-inch downrod for stable installation.
- Ultra-quiet 6-speed reversible DC motor (below 35dB).
- Remote control with summer/winter modes and programmable timer (1/2/4/6H).
- Eight E12 light sockets (bulbs not included) for balanced illumination.
- Durable, scratch-resistant metal frame with wood-like appearance.

## 2. Safety Information

Please read and understand all instructions before beginning installation. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **WARNING:** To avoid possible electrical shock, turn off the electricity at the main fuse box or circuit breaker panel before beginning fan installation or before servicing the fan.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- Ensure the installation site can support the weight of the fan (approximately 15-20 lbs).
- Do not bend the blade holders during installation, balancing, or cleaning.
- Keep children away from the fan during operation.
- Use only E12 base bulbs (not included) as specified.

## 3. Specifications

| Specification | Detail |
|---|---|
| Brand | Bella Depot |
| Model Number | 3670 |
| Product Dimensions | 36"D x 36"W x 21.7"H |
| Downrod Length | 19.6 inches (fixed) |
| Power Source | DC |
| Voltage | 110 volts |
| Wattage | 40 watts |
| Number of Speeds | 6 |
| Noise Level | 35 dB |
| Number of Blades | 5 |
| Light Sockets | 8 x E12 (bulbs not included) |
| Material | Iron with wood-grain finish |
| Mounting Type | Downrod Mount |
| Indoor/Outdoor Usage | Indoor |




Image 3.1: Detailed dimensions of the 36-inch Wagon Wheel Chandelier Ceiling Fan.

## 4. Installation Instructions

This section provides general guidance for installing your ceiling fan. It is recommended to consult a qualified electrician

for installation to ensure safety and compliance with local codes.

### 4.1 Pre-Installation Checklist:

- Ensure power is OFF at the circuit breaker.
- Verify all components are present and undamaged.
- Confirm your ceiling can support the fan's weight and is suitable for downrod mounting.
- Prepare necessary tools (screwdriver, wire strippers, ladder, etc.).

### 4.2 Mounting the Fan:

1. Securely attach the mounting bracket to the ceiling junction box. The junction box must be listed for fan support.
2. Assemble the downrod and canopy. The fan comes with a fixed 19.6-inch downrod.
3. Carefully lift the fan assembly and hang it from the mounting bracket.

### 4.3 Wiring Connections:

1. Connect the fan's electrical wires to the household supply wires according to the wiring diagram provided in the full product manual (not included here). Ensure all connections are secure with wire nuts.
2. Connect the ground wires.
3. Tuck all wires neatly into the junction box.

### 4.4 Final Assembly:

1. Attach the fan blades to the motor housing.
2. Install the light kit and screw in the E12 bulbs (not included).
3. Secure the canopy to the mounting bracket.




Image 4.1: Illustration of fan dimensions and compatibility with various ceiling types (flat and sloped up to 15 degrees).

## 5. Operating Instructions

Your Bella Depot ceiling fan is operated using the included remote control. Ensure the remote has fresh batteries installed.

### 5.1 Remote Control Functions:




Image 5.1: Remote control layout and functions.

- **Light ON/OFF:** Press the light button to turn the chandelier lights on or off.
- **Fan OFF:** Press the fan off button to stop the fan.
- **6 Wind Speed:** Use the numbered buttons (1-6) to select your desired fan speed. Speed 1-2 is suitable for

sleeping, 3-4 for working, and 5-6 for sports/cooling.

- **Timing Setting:** Set a timer for 1, 2, 4, or 6 hours using the dedicated buttons.
- **Reversible Airflow:** The fan features a reversible DC motor for year-round comfort. Use the remote to switch between summer (downward airflow for cooling) and winter (upward airflow for circulating warm air) modes.




Image 5.2: Reversible airflow function for seasonal comfort.

Your browser does not support the video tag.

Video 5.1: An official product video demonstrating the features of the 36-inch Farmhouse Wagon Wheel Ceiling Fan Light.

## 6. Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish. Ensure power is off before cleaning.
- **Bulb Replacement:** Turn off power before replacing bulbs. Use only E12 base bulbs.
- **Tighten Fasteners:** Periodically check and tighten all screws and fasteners on the fan and mounting hardware.

Image 6.1: Comparison highlighting the durable, scratch-resistant construction of the Bella Depot fan.

## 7. Troubleshooting

If you experience issues with your fan, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Fan does not start | No power to the fan; loose wire connections; remote control battery low. | Check circuit breaker/fuse; ensure all wire connections are secure; replace remote control batteries. |
| Lights do not work | Loose wire connections; faulty bulbs; light switch off. | Check wire connections; replace bulbs; ensure light switch on remote is pressed. |
| Fan wobbles | Loose fan blades or mounting hardware; unbalanced blades. | Ensure all blade screws and mounting screws are tight; use a balancing kit (not included) if necessary. |

| | | |
|---|---|---|
| Noisy operation | Loose screws; fan not properly secured; internal motor issue. | Check and tighten all screws; ensure fan is securely mounted; if noise persists, contact customer support. |

If you are unable to resolve the issue using these steps, please contact Bella Depot customer support.

## 8. Warranty and Support

Bella Depot is committed to providing high-quality products and excellent customer service. For any after-sales issues or inquiries, please reach out to our support team.




Image 8.1: Guide on how to contact customer support for assistance.

We offer 24-hour question service to assist you with any concerns regarding your Bella Depot product. Please refer to your purchase documentation for specific warranty details.

You can typically find support information by:

1. Signing into your purchase platform (e.g., Amazon).
2. Navigating to your order history.
3. Locating the Bella Depot product and selecting the option to 'Ask a question' or 'Contact Seller'.

© 2023 Bella Depot. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0GYN9LK3M**

More documents and user manuals: **https://manuals.plus/**