Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CHULUX CL-NM831V-L

CHULUX Bafè-Pro 20Bar Espresso Coffee Machine User Manual

Model: CL-NM831V-L

1. Introduction

Welcome to the CHULUX Bafè-Pro 20Bar Espresso Coffee Machine user manual. This guide provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new espresso machine. Please read this manual thoroughly before first use and keep it for future reference.

Your CHULUX Bafè-Pro machine features a 1400W rapid heating system and a 20Bar Italian pump for fast extraction and rich crema. It offers one-touch buttons for Espresso and Lungo, an auto-eject capsule system, a 24oz removable water reservoir, and a compact design. The machine is designed for use with original line coffee pods.

Safety Precautions

- Always ensure the machine is placed on a stable, flat surface.
- Do not immerse the machine, power cord, or plug in water or other liquids.
- Keep out of reach of children.
- Unplug the machine from the power outlet before cleaning and when not in use.
- Do not operate the machine with a damaged cord or plug.
- This appliance is for household use only.

2. Included Components

Your CHULUX Bafè-Pro Espresso Coffee Machine comes with the following components:

- Espresso Machine Unit
- Removable Water Tank (24 oz capacity)
- Capsule Tray (Used Capsule Drawer)
- Foldable Drip Tray
- Removable Drip Tray Cover



Image: All removable parts of the CHULUX Bafè-Pro Espresso Coffee Machine laid out for easy cleaning.

3. Setup and First Use

1. **Unpack the Machine:** Carefully remove all packaging materials and place the machine on a clean, dry, and stable surface.
2. **Clean Components:** Wash the water tank, drip tray, and capsule container with warm, soapy water. Rinse thoroughly and dry.
3. **Fill Water Tank:** Remove the water tank from the back of the machine. Fill it with fresh, potable water up to the MAX level. Place the tank back securely.



Image: Removing and filling the 24oz removable water tank.

4. **Initial Rinse Cycle:**
    - Ensure the water tank is filled.
    - Place an empty cup under the coffee outlet.
    - Plug the machine into a grounded power outlet. The indicator lights will flash.
    - Press either the Espresso or Lungo button. The machine will preheat in 15-20 seconds.
    - Once preheated, water will dispense into the cup. Repeat this process 2-3 times to clean the internal system.
    - Discard the water. Your machine is now ready for use.

4. Operating Instructions

1. **Power On:** Plug the machine into a power outlet. The indicator lights will flash during the 15-20 second preheating phase. Once steady, the machine is ready.
2. **Insert Capsule:** Lift the lever on top of the machine. Insert a compatible original line coffee capsule into the capsule slot. Close the lever firmly.



Image: Inserting an espresso capsule into the machine.

3. **Place Cup:** Place your desired cup on the drip tray. The drip tray is foldable to accommodate taller cups.
4. **Select Brew Size:**
    - Press the **Espresso button** for a short, rich shot.
    - Press the **Lungo button** for a longer, smoother coffee.



Image: Selecting between Espresso and Lungo brew options.

5. **Brewing:** The machine will begin brewing. Once the desired amount is dispensed, the brewing will stop automatically.
6. **Capsule Ejection:** After brewing, lift the lever again. The used capsule will automatically eject into the internal capsule tray. Close the lever.
7. **Power Off:** The machine will automatically shut off after 5 minutes of inactivity to save energy. You can also manually unplug it.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your espresso machine.

Daily Cleaning

- **Empty Used Capsule Drawer:** Regularly empty the used capsule drawer. It has a large capacity, but should be emptied when full.



Image: The large-capacity used capsule drawer.

- **Clean Drip Tray and Capsule Container:** The drip tray and capsule container are removable and dishwasher-safe for easy cleaning. Wash them with warm, soapy water or place them in the dishwasher.
- **Wipe Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Rinse Water Tank:** Rinse the water tank with fresh water daily.

Descaling

Over time, mineral deposits (limescale) can build up in your machine, affecting performance and coffee taste. Descale your machine every 3-6 months, or more frequently if you have hard water.

1. Empty the water tank and used capsule drawer.
2. Fill the water tank with a descaling solution (follow the descaler manufacturer's instructions) or a mixture of white vinegar and water (1 part vinegar to 2 parts water).
3. Place a large container under the coffee outlet.
4. Run several Lungo cycles until the water tank is empty.
5. Rinse the water tank thoroughly and fill it with fresh water.

6. Run several Lungo cycles with fresh water to rinse out any remaining descaling solution.

6. Troubleshooting

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply.	Check if the power cord is securely plugged into a working outlet.
No coffee dispenses.	Water tank is empty; capsule not inserted correctly; machine needs descaling.	Fill water tank; ensure capsule is properly seated and lever is closed; perform descaling.
Coffee is cold or not hot enough.	Machine not preheated; internal heating element issue.	Allow machine to fully preheat (lights steady); if problem persists, contact support.
Water leaks from the machine.	Water tank not seated correctly; drip tray overflowing.	Ensure water tank is firmly in place; empty and clean the drip tray.
Indicator lights are flashing unusually.	Error state or specific warning.	Refer to the full manual for specific light patterns or contact customer support.

7. Specifications

Feature	Detail
Brand	CHULUX
Model Name	Eespresso Maker
Model Number	CL-NM831V-L
Color	Lavender
Capacity	24 fluid ounces (Water Tank)
Product Dimensions (D x W x H)	9.54"D x 4.57"W x 13.94"H
Item Weight	6.2 pounds
Wattage	1400 watts
Voltage	120 volts
Output Pressure	20 bar
Special Features	15-20s Fast Preheating, Auto Shut-Off, Compatible with Nes Original Pod, One Button Operation, Single and Double Shot
Material	Plastic



Image: Dimensions of the CHULUX Bafè-Pro Espresso Coffee Machine.

8. Warranty Information

This CHULUX coffee maker is guaranteed for a period of**1 year** from the date of original purchase against defects in mechanical and electrical components. Please retain your proof of purchase for warranty claims.

The warranty does not cover damage resulting from misuse, neglect, unauthorized modification, or failure to follow the instructions in this manual.

9. Customer Support

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact CHULUX customer support. Refer to the product packaging or the official CHULUX website for the most current contact information.

When contacting support, please have your product model number (CL-NM831V-L) and purchase date available.

© 2023 CHULUX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GZ4B96J3

More documents and user manuals: **https://manuals.plus/**