Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ninja NC601BR

Ninja CREAMi XL Deluxe Gen 2 11-in-1 Ice Cream Maker

Model: NC601BR

Introduction

The Ninja CREAMi XL Deluxe Gen 2 is an advanced 11-in-1 ice cream maker designed to transform various ingredients into a wide range of frozen treats. This appliance features a redesigned second-generation styling and expanded capacity with XL tubs, allowing for greater versatility and larger servings. It offers 11 one-touch programs, including classic options like ice cream, sorbet, and gelato, alongside new functions such as Dairy-Free, Smoothie Bowl, and CreamiFit. This manual provides essential information for safe operation, assembly, use, and maintenance of your CREAMi XL Deluxe.



Image: The Ninja CREAMi XL Deluxe Gen 2 appliance in Mocha, showcasing its ability to create a variety of frozen desserts and drinks.

Important Safeguards

Please read all instructions before using your Ninja CREAMi XL Deluxe. Failure to follow these safeguards may result in property damage, personal injury, or death.

- Always ensure the appliance is properly assembled and the outer bowl is securely locked in place before operation.
- Do not operate the appliance with a damaged cord or plug. Contact customer service for assistance.
- Keep hands and utensils out of the container while processing to reduce the risk of severe injury to persons or damage to the appliance.
- Do not use attachments not recommended or sold by Ninja, as this may cause fire, electric shock, or injury.
- Ensure the motor base is placed on a clean, dry, level surface before use.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.

What's Included

Your Ninja CREAMi XL Deluxe Gen 2 package includes the following components:

- Motor Base with Dual-Drive Motors
- Outer Bowl
- (2) 24 oz. CREAMi XL Tubs with Storage Lids
- XL Creamerizer Paddle
- Lid to house pint while processing



Image: Two 24 oz. CREAMi XL Tubs with their storage lids, highlighting the fill lines for different treat types.

Setup

Before first use, wash all components that will come into contact with food. The XL tubs, lids, and Creamerizer Paddle are top-rack dishwasher safe. The motor base should be wiped clean with a damp cloth.

1. Place the motor base on a clean, dry, level surface.
2. Insert the Creamerizer Paddle into the outer bowl lid. Ensure it clicks securely into place.
3. Place a filled CREAMi XL Tub into the outer bowl.
4. Place the outer bowl lid with the paddle onto the outer bowl, aligning the arrow on the lid with the handle. Turn the lid clockwise to lock it.
5. Place the assembled outer bowl onto the motor base, aligning the handle with the right side of the motor base. Turn the outer bowl clockwise to lock it into place. You will hear a click when it is properly secured.



Image: Visual representation of the preparation and serving steps for the Ninja CREAMi XL Deluxe.

Operating Instructions

The Ninja CREAMi XL Deluxe offers 11 one-touch programs to create a variety of frozen treats. Follow these general steps for optimal results:

General Process

1. **Prep:** Prepare your desired base mixture in the CREAMi XL Tub. Ensure ingredients do not exceed the MAX FILL line.
2. **Freeze:** Place the tub with the base mixture in a freezer set to 0°F (-18°C) for at least 24 hours. A properly frozen base is crucial for successful processing.
3. **Process:** Assemble the unit as described in the Setup section. Select one of the 11 programs based on your desired treat. The appliance will automatically process the frozen base.
4. **Re-Spin (Optional):** If the processed treat is crumbly or powdery, select the RE-SPIN function for a creamier texture.
5. **Mix-In (Optional):** After initial processing, create a 1.5-inch wide hole in the center of your treat. Add your favorite mix-ins (e.g., chocolate chips, nuts, candy, fruit) into the hole. Re-assemble the unit and select the MIX-IN program to evenly distribute them.



Image: A visual guide demonstrating the three core steps: preparing the base, freezing it for 24 hours, and processing it in the CREAMi XL Deluxe.

Available Programs

The control panel features 11 one-touch programs:

- Ice Cream
- Lite Ice Cream
- Gelato
- Sorbet
- Frozen Yogurt
- Dairy-Free
- Smoothie Bowl
- CreamiFit
- Frappe
- Milkshake
- Mix-In



Image: The control panel of the Ninja CREAMi XL Deluxe, clearly displaying the 11 available one-touch programs for various frozen creations.

Maintenance and Cleaning

Proper cleaning and maintenance ensure the longevity and optimal performance of your Ninja CREAMi XL Deluxe.

Cleaning Instructions

- Always unplug the motor base before cleaning.
- The XL tubs, lids, and the Creamerizer Paddle are top-rack dishwasher safe.
- For manual cleaning, wash these components in warm, soapy water using a non-abrasive cleaning brush. Rinse thoroughly.
- Wipe the motor base with a clean, damp cloth. Do not immerse the motor base in water or any other liquid.
- Ensure all parts are completely dry before storing or reassembling.



Image: The removable components of the Ninja CREAMi XL Deluxe, including the tubs and lids, are shown being loaded into a dishwasher, indicating their dishwasher-safe design.

Troubleshooting

If you encounter issues with your Ninja CREAMi XL Deluxe, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; outer bowl or lid not properly assembled.	Ensure the power cord is securely plugged into an outlet. Verify the outer bowl and lid are correctly locked into the motor base.
Treat is crumbly or powdery after processing.	Base not frozen solid enough; recipe requires re-spin.	Ensure the base was frozen for a full 24 hours at 0°F (-18°C). Use the RE-SPIN function to achieve a creamier texture.

Problem	Possible Cause	Solution
Paddle is not spinning.	Paddle not installed correctly; motor base not engaged.	Check that the Creamerizer Paddle is securely clicked into the outer bowl lid. Ensure the outer bowl is fully locked onto the motor base.
Loud noise during operation.	Normal operation; hard ingredients.	Some noise is normal during processing, especially with harder frozen bases. If the noise is excessive or unusual, ensure all components are correctly assembled.

Specifications

- **Model Number:** NC601BR
- **Brand:** Ninja
- **Color:** Mocha
- **Capacity:** 1.5 pounds (per XL tub, includes two 24 oz. tubs)
- **Material:** Plastic, Stainless Steel
- **Special Features:** Automatic Shut-Off, Digital Display, Programmable
- **Dimensions (L x W x H):** 18.58" x 9.61" x 19.45"
- **Item Weight:** 15.4 pounds
- **Operation Mode:** Automatic
- **Product Care Instructions:** Dishwasher Safe (XL tubs, lids, Creamerizer Paddle - top-rack only)

Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Ninja website. If you require further assistance, have questions about your product, or need to order replacement parts, please contact Ninja customer support. Contact details can typically be found in the product packaging or on the manufacturer's website. **Online Resources:** For additional recipes, tips, and frequently asked questions, visit the official Ninja website or their dedicated support pages.

© 2023 Ninja. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GZWLRPBH

More documents and user manuals: **https://manuals.plus/**