Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mz Soundbar Karaoke

MZ M51 Bluetooth Soundbar Speaker with Wireless Microphone User Manual

Model: Mz Soundbar Karaoke

1. Introduction

Thank you for purchasing the MZ M51 Bluetooth Soundbar Speaker with Wireless Microphone. This system is designed to provide an immersive audio experience for music listening and karaoke. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan.

2. Safety Instructions

- Do not expose the device to rain, moisture, or extreme temperatures.
- Do not disassemble or attempt to repair the unit yourself. Refer all servicing to qualified personnel.
- Keep the device away from heat sources, direct sunlight, and flammable materials.
- Ensure proper ventilation around the soundbar to prevent overheating.
- Use only the provided USB charging cable or a certified equivalent.
- Avoid listening at high volume levels for extended periods to prevent hearing damage.

3. Package Contents

Please check the box for the following items:

- MZ M51 Soundbar Speaker
- Wireless Microphone
- USB Charging Cable
- User Manual (this document)



Image: Contents of the MZ M51 package, showing the soundbar, wireless microphone, and product box.

4. Product Overview

4.1 Soundbar Front and Top View



Image: Front view of the MZ M51 Soundbar with a smartphone placed in its integrated dock, alongside the wireless microphone. This view highlights the speaker grille and the MZ logo.

1. **Speaker Grille:** Protects the speaker drivers.
2. **Smartphone Dock:** Slot to hold your smartphone or tablet.
3. **Control Buttons (Top Panel):** Power, Mode, Volume Up/Next, Volume Down/Previous, Play/Pause.
4. **MZ Logo:** Brand indicator.

4.2 Soundbar Rear View and Ports



Image: Rear view of the MZ M51 Soundbar, displaying the various input ports including USB, TF card slot, AUX input, and the charging port.

1. **USB Port:** For USB drive playback.
2. **TF Card Slot:** For TF/MicroSD card playback.
3. **AUX Input:** For wired audio connection (e.g., from a TV or PC).
4. **DC 5V Charging Port:** For charging the soundbar.

4.3 Wireless Microphone

1. **Power Button:** To turn the microphone on/off.
2. **Volume Controls:** Adjust microphone volume.
3. **Echo Control:** Adjust echo effect.
4. **Microphone Head:** Audio input.

5. Setup

5.1 Charging the Soundbar

1. Connect the small end of the USB charging cable to the DC 5V port on the soundbar.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off.

5.2 Charging the Wireless Microphone

The wireless microphone typically uses internal rechargeable batteries or standard AA/AAA batteries. Refer to the microphone's specific instructions for charging or battery replacement.

5.3 Initial Power On

1. Press and hold the Power button on the soundbar for a few seconds until you hear a power-on prompt or see an indicator light.
2. Turn on the wireless microphone by pressing its power button. It should automatically connect to the soundbar.

6. Operating Instructions

6.1 Bluetooth Pairing

1. Turn on the soundbar. It will automatically enter Bluetooth pairing mode (indicated by a flashing LED or voice prompt).
2. On your smartphone, tablet, or other Bluetooth device, go to Bluetooth settings and search for available devices.
3. Select "MZ M51" (or similar name) from the list.
4. Once paired, you will hear a confirmation sound, and the LED indicator will stop flashing.
5. You can now play audio from your device through the soundbar.

6.2 Using Other Audio Sources

- **USB/TF Card:** Insert a USB drive or TF card into the respective port. The soundbar will automatically switch to USB/TF mode and begin playing audio files.
- **AUX Input:** Connect an audio cable (3.5mm jack, not included) from your external device (e.g., TV, PC) to the AUX port on the soundbar. Press the "Mode" button on the soundbar until "AUX" mode is selected.

6.3 Karaoke Mode

1. Ensure the soundbar is connected to your audio source (e.g., Bluetooth from a phone playing karaoke tracks).
2. Turn on the wireless microphone. It should automatically connect to the soundbar.
3. Adjust the microphone volume and echo effect using the controls on the microphone.
4. Adjust the overall music volume using the soundbar's controls or your connected device.

6.4 Control Buttons

- **Power Button:** Press and hold to turn on/off. Short press to change lighting modes (if applicable).
- **Mode Button:** Short press to cycle through input modes (Bluetooth, USB, TF, AUX).
- **Volume Up** / **Next Track:** Short press for volume up. Long press for next track.
- **Volume Down** / **Previous Track:** Short press for volume down. Long press for previous track.
- **Play** / **Pause:** Short press to play or pause music.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the soundbar and microphone. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, fully charge the device before long storage periods and recharge every few months if not in use.

8. Troubleshooting

Problem	Possible Solution
No power	Ensure the soundbar is charged. Check the charging cable and power source.
No sound	Check volume levels on both the soundbar and the connected device. Ensure the correct input mode is selected. Re-pair Bluetooth if necessary.
Microphone not working	Ensure the microphone is turned on and charged/has fresh batteries. Check microphone volume.
Bluetooth connection unstable	Move the soundbar closer to the Bluetooth device. Avoid obstacles between devices. Disconnect and re-pair.
Distorted sound	Reduce volume on both the soundbar and the source device. Check audio source quality.

9. Specifications

Brand	Generic
Model Name	Mz Bluetooth Soundbar With Wireless Microphone
Model Number	Mz Soundbar Karaoke
Speaker Maximum Output Power	10 Watts
Frequency Response	20000 Hz
Connectivity Technology	Bluetooth, Wireless
Audio Output Mode	Stereo
Mounting Type	Tabletop / Wall Mountable
Colour	Black
Bluetooth Range	10 Metres
Signal-to-Noise Ratio	80 dB
Number of Audio Channels	2.0
Item Dimensions (D x W x H)	8D x 40W x 8H Centimeters

Item Weight	200 Grams
Power Source	AC Adapter / USB Powered
Compatible Devices	Desktop Computer, Laptop, Smartphone, Tablet, Television

10. Warranty and Support

Warranty: This product comes with NO WARRANTY as per manufacturer specifications. Please refer to your point of purchase for any return or exchange policies.
Support: For any issues or questions not covered in this manual, please contact the retailer or manufacturer directly.

© 2023 MZ Electronics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H183SDTS

More documents and user manuals: **https://manuals.plus/**