Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JCQASRT DD-2616JS-60-12-SS

JCQASRT Modern Crystal Chandelier User Manual

Model: DD-2616JS-60-12-SS | Brand: JCQASRT

1. Introduction

Thank you for choosing the JCQASRT Modern Crystal Chandelier. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.



Image 1.1: The JCQASRT Modern Crystal Chandelier illuminating a contemporary living space.

2. Safety Information

- **Electrical Safety:** Always turn off the main power supply at the circuit breaker before installing, cleaning, or servicing the fixture. Consult a qualified electrician if you are unsure about electrical wiring.
- **Proper Grounding:** Ensure the fixture is properly grounded to avoid potential electrical shock.
- **Voltage Compatibility:** This fixture is designed for 110-volt electrical systems. Do not use with incompatible voltage.
- **Bulb Requirements:** Use only E12 base bulbs. Do not exceed the maximum recommended wattage of 50 watts for the entire fixture.
- **Handling Crystals:** Crystals are fragile. Handle with care during installation and cleaning to prevent breakage.
- **Indoor Use Only:** This fixture is rated for indoor use and is not water-resistant. Do not install in damp or wet locations.

3. Package Contents

Carefully unpack all components and inspect for any damage. Keep all packaging materials until you are satisfied with the product. The package should include:

- Chandelier Frame (Gold-finished Iron)
- Crystal Pendants and Natural Shell Discs
- Mounting Hardware (Canopy, Mounting Bracket, Screws, Wire Nuts)
- Remote Control
- Instruction Manual



Image 3.1: Detailed view of the chandelier's premium components, including K9 crystals and natural shell discs.

4. Specifications

Feature	Detail
Brand	JCQASRT
Model Number	DD-2616JS-60-12-SS
Color	Gold
Material	Iron (Frame), K9 Crystal (Pendants), Natural Shell (Discs)
Style	Modern, Contemporary
Fixture Form	Chandelier, Pendant Lighting
Dimensions	Diameter: 60 cm (approx. 23.6 inches), Height: 36 cm (approx. 14.2 inches)
Mounting Type	Ceiling Mount, Semi Flush Mount
Power Source	Corded Electric
Voltage	110 Volts
Bulb Base	E12 (Bulbs not included)
Number of Lights	12
Max Wattage	50 Watts (Total for fixture)
Special Features	Dimmable, Remote Control, 3 CCT Modes (with compatible bulbs/system)
Indoor/Outdoor Use	Indoor Only
Water Resistance	Not Water Resistant



Image 4.1: Detailed dimensions of the chandelier.

5. Setup and Installation

Professional installation is recommended. Ensure all power is disconnected at the circuit breaker before proceeding.

5.1. Preparation

1. Turn off power at the main circuit breaker.
2. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
3. Identify all parts against the package contents list.

5.2. Mounting the Fixture

1. Attach the mounting bracket to the junction box in the ceiling using the provided screws. Ensure it is securely fastened.

2. Connect the fixture's wires to the house wires: black to black (live), white to white (neutral), and bare copper/green to bare copper/green (ground). Secure connections with wire nuts.
3. Carefully tuck all wires into the junction box.
4. Attach the chandelier canopy to the mounting bracket, securing it with the decorative nuts or screws.

5.3. Attaching Crystals and Bulbs

1. Carefully hang each crystal pendant and natural shell disc onto the designated hooks on the chandelier frame. Refer to the product images for the correct arrangement.
2. Install 12 E12 base bulbs (not included) into the sockets. Ensure bulbs are compatible with dimming and CCT features if you intend to use them.

6. Operating Instructions

Once installed and power is restored, your chandelier is ready for operation.

6.1. Power On/Off

- Use the wall switch to turn the chandelier on or off.
- Alternatively, use the remote control's power button (usually marked with an 'ON/OFF' symbol).

6.2. Remote Control Functions

The included remote control allows for convenient operation of your chandelier's features:

- **Dimming:** Use the brightness adjustment buttons (often marked '+' and '-') to increase or decrease the light intensity.
- **Color Temperature (CCT) Adjustment:** If using compatible CCT-adjustable E12 bulbs or if the fixture has integrated CCT LEDs, use the dedicated buttons on the remote to switch between different color temperatures (e.g., Warm Light, Neutral Light, White Light).



Image 6.1: The chandelier demonstrating its 3 CCT modes: Warm Light (4000K), Neutral Light (4800K), and White Light (6000K).

7. Maintenance

Regular cleaning and proper care will ensure your chandelier maintains its appearance and functionality.

7.1. Cleaning

- **Always turn off power** to the fixture before cleaning.
- **Metal Frame:** Wipe the gold-finished iron frame with a soft, dry, lint-free cloth. Do not use abrasive cleaners or chemicals, as they may damage the finish.
- **Crystals and Shell Discs:** Gently wipe crystals and shell discs with a soft, damp cloth. For a deeper clean, a mild glass cleaner can be sparingly applied to the cloth (not directly to the crystals) and then wiped dry. Avoid harsh chemicals.

7.2. Bulb Replacement

- Ensure power is off before replacing any bulbs.
- Allow bulbs to cool completely before touching them.
- Unscrew the old E12 bulb and screw in a new E12 bulb. Do not exceed 50 watts total for the fixture.

8. Troubleshooting

If you encounter issues with your chandelier, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power, loose wiring, faulty bulb, remote battery dead.	Check circuit breaker. Ensure all wire connections are secure. Replace bulbs. Replace remote control batteries.
Light flickers.	Loose bulb, incompatible dimmer switch, loose wiring.	Tighten bulbs. Ensure dimmer switch is compatible with LED bulbs (if using LEDs). Check wiring connections.
Remote control not working.	Dead batteries, remote out of range, interference.	Replace remote batteries. Ensure remote is within operating range. Remove any obstructions.
Crystals appear dull.	Dust or residue buildup.	Clean crystals as per maintenance instructions.

9. Warranty and Support

9.1. Manufacturer Warranty

This JCQASRT chandelier is covered by a **3-year manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by improper installation, misuse, accidents, or unauthorized modifications.

9.2. Customer Support

For technical assistance, warranty claims, or replacement parts, please contact JCQASRT customer service. Please have your model number (DD-2616JS-60-12-SS) and proof of purchase ready when contacting support.
Contact information for JCQASRT customer service can typically be found on the product packaging or the retailer's website where the product was purchased.

© 2026 JCQASRT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H1C19MY5

More documents and user manuals: **https://manuals.plus/**