Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Diyeeni Diyeenixfw13a5izn-12

Diyeeni Game Flash Card Instruction Manual

Model: Diyeenixfw13a5izn-12

1. Product Overview

The Diyeeni Game Flash Card is a versatile accessory designed to enhance your gaming experience on compatible Nintendo DS series consoles. It features a built-in 64GB memory, allowing you to store and play a large library of games from a single cartridge. This flash card supports a wide range of consoles and includes features like customizable keys, easy menu navigation, and automatic game save backups.

Key Features:

- **Broad Console Compatibility:** Compatible with NDS, NDSL, NDSi, NDSi XL, 2DS, 3DS, 3DSL, NEW 3DS, NEW 3DS X, and 2DSXL consoles.
- **Built-in 64GB Memory:** Provides ample storage for numerous game titles.
- **Customizable Keys:** Allows for personalized A/B key functions.
- **Instant Menu Access:** Return to the main menu with a single button press.
- **Easy Game Management:** Simple drag-and-drop file transfer via USB connection to a computer.
- **Automatic Save Backup:** Game progress is automatically saved to the internal memory.
- **Extended Battery Life:** Designed with technology to optimize console battery usage.



Image 1.1: Overview of the Diyeeni Game Flash Card highlighting its main features.

2. Setup Instructions

Follow these steps to prepare and use your Diyeeni Game Flash Card:

1. **Prepare Game Files:** Obtain compatible game ROMs (files) for your Nintendo DS series console. Ensure they are in a format recognized by the flash card.
2. **Transfer Game Files:** Connect the Diyeeni Game Flash Card to your computer using a compatible USB adapter (not included, if required, or directly if it has a USB port). Drag and drop your game files into the appropriate folder on the flash card's built-in 64GB memory. Ensure all files are transferred completely.
3. **Insert Flash Card:** With your Nintendo DS series console powered off, carefully insert the Diyeeni Game Flash Card into the game cartridge slot until it clicks into place. Do not force the card.
4. **Power On Console:** Power on your Nintendo DS series console. The console should recognize the flash card and display its menu.



Image 2.1: Proper insertion of the flash card into a compatible console.



Image 2.2: The flash card being held, ready for insertion.

3. Operating Instructions

Once the flash card is recognized by your console, you can begin using it:

1. **Navigating the Menu:** Use your console's directional pad and A/B buttons to navigate through the flash card's on-screen menu. Select games from the list.
2. **Launching Games:** Highlight the desired game and press the 'A' button (or equivalent) to launch it.
3. **Returning to Menu:** During gameplay, you can typically return to the flash card's main menu by pressing a designated button combination or a single customizable key, as specified in the flash card's internal software settings.
4. **Game Saves:** The flash card supports automatic game saving. Your progress will be backed up to the built-in memory. Ensure you allow sufficient time for saves to complete before powering off the console during critical moments.
5. **Customizing Keys:** Refer to the flash card's internal software settings for options to customize A/B key functions or other controls, if available.

4. Maintenance

To ensure the longevity and optimal performance of your Diyeeni Game Flash Card, follow these maintenance guidelines:

- **Keep Contacts Clean:** Periodically inspect the gold contacts on the flash card. If they appear dirty, gently clean them with a soft, dry, lint-free cloth or a cotton swab lightly dampened with isopropyl alcohol. Ensure contacts are completely dry before re-inserting into the console.
- **Proper Storage:** When not in use, store the flash card in its protective case or a clean, dry environment away from extreme temperatures, humidity, and direct sunlight.
- **Avoid Physical Damage:** Handle the flash card with care. Do not bend, drop, or expose it to excessive force, as this can damage the internal components or external casing.
- **Software Updates:** Check the manufacturer's website periodically for any available firmware or software updates for the flash card. Follow update instructions carefully to avoid bricking the device.

5. Troubleshooting

If you encounter issues with your Diyeeni Game Flash Card, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Flash card not recognized by console.	Improper insertion, dirty contacts, or console incompatibility.	• Ensure the card is fully and correctly inserted into the console slot. • Clean the gold contacts on the flash card and inside the console slot (if accessible) with a soft, dry cloth. • Verify your console model is listed as compatible (NDS, NDSL, NDSi, NDSi XL, 2DS, 3DS, 3DSL, NEW 3DS, NEW 3DS X, 2DSXL).
Games do not load or crash.	Corrupt game files, incorrect file format, or incomplete transfer.	• Re-transfer the game files to the flash card, ensuring the transfer completes without interruption. • Verify that the game files are in a compatible format. • Try a different game file to isolate if the issue is with a specific game or the card itself.
Game saves are not working or lost.	Insufficient memory space, interruption during save, or software issue.	• Ensure there is sufficient free space on the flash card's memory. • Do not power off the console or remove the card during gameplay or saving. • Check for any available software updates for the flash card that might address save issues.

6. Product Specifications

Model Number	Diyeenixfw13a5izn-12
Brand	Diyeeni

Material	ABS
Storage	Built-in 64GB Memory
Compatible Consoles	NDS, NDSL, NDSi, NDSi XL, 2DS, 3DS, 3DSL, NEW 3DS, NEW 3DS X, 2DSXL Original Host
Supported File Systems	FAT, FAT16, FAT32
Supported Mappers	MAPPERs, MBC1, MBC2, MBC3, MBC5
Game Cheat Function	Supported
Dimensions (L x W x H)	Approximately 14 x 12 x 2 cm
Weight	Approximately 70 g

7. Warranty Information

This Diyeeni Game Flash Card is covered by a manufacturer's warranty for**90 days** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or external causes.
Please retain your proof of purchase for warranty claims.

8. Customer Support

For further assistance, technical support, or warranty inquiries, please contact the seller or visit the official Diyeeni website. When contacting support, please provide your product model number (Diyeenixfw13a5izn-12) and a detailed description of the issue.
Diyeeni Official Store: Visit Store

© 2023 Diyeeni. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H1G3ZMV3

More documents and user manuals: **https://manuals.plus/**