Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cosori CFD-P103-KUS

Cosori Food Dehydrator CFD-P103-KUS User Manual

Brand: Cosori | **Model:** CFD-P103-KUS

1. Important Safeguards

Please read all instructions carefully before using your Cosori Food Dehydrator. Failure to follow these instructions may result in damage to the appliance, property damage, or personal injury.

- **Electrical Safety:** Always plug the dehydrator into a grounded electrical outlet. Do not operate if the cord or plug is damaged. Do not immerse the appliance, cord, or plug in water or other liquids.
- **Heat Warning:** The stainless steel exterior and internal components may become hot during operation. Avoid touching hot surfaces. Use oven mitts or heat-resistant gloves when handling trays or food during or immediately after operation.
- **Ventilation:** Ensure adequate ventilation around the dehydrator during use. Do not block air vents. Keep the appliance at least 6 inches (15 cm) away from walls or other appliances.
- **Flammable Materials:** Do not place the dehydrator near flammable materials such as curtains, tablecloths, or paper products.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.
- **Intended Use:** Use the dehydrator only for its intended purpose of dehydrating food. Do not use it for any other purpose.
- **Maintenance:** Unplug the dehydrator from the outlet before cleaning or performing any maintenance.

2. Package Contents

Carefully unpack all components and ensure you have received the following items:

- 1 x Cosori Stainless Steel Food Dehydrator
- 10 x Stainless Steel Trays
- 1 x Mesh Screen (BPA-free)
- 1 x Fruit Roll Sheet (BPA-free)
- 1 x Recipe Book

- 1 x User Manual (this document)



Image: All included accessories for the Cosori Food Dehydrator.

3. Getting Started (Setup)

3.1 Unpacking

1. Remove all packaging materials from the dehydrator and its accessories.
2. 3.2 Placement
    1. Place the dehydrator on a stable, flat, and heat-resistant surface.
    2. Ensure there is at least 6 inches (15 cm) of clear space on all sides of the dehydrator for proper air circulation.
    3. Do not place the dehydrator on or near a hot gas or electric burner, or in a heated oven.

3.3 First Use

1. Before first use, wipe the exterior of the dehydrator with a clean, damp cloth.
2. Wash the stainless steel trays, mesh screen, and fruit roll sheet with warm, soapy water. Rinse thoroughly and dry completely.
3. To eliminate any manufacturing odors, place the empty trays inside the dehydrator, close the door, and run the unit at 167°F (75°C) for 30 minutes. Ensure the area is well-ventilated during this process.
4. After this initial run, allow the unit to cool completely before use.

4. Operating Your Dehydrator

4.1 Control Panel Overview

The control panel is located on the top front of the dehydrator and features a digital display and touch controls:

- **TEMP/TIME Button:** Toggles between temperature and time settings.
- **+/- Buttons:** Adjust temperature and time values.
- **Preset Button:** Selects from 10 pre-programmed drying settings.
- **Light Button:** Turns the interior light on or off.
- **Start/Stop Button:** Starts or stops the dehydration process.



Image: Control panel with preset options.

4.2 Setting Temperature and Time

1. Plug in the dehydrator. The display will illuminate.
2. Press the TEMP/TIME button to select either temperature or time. The selected value will blink.
3. Use the +/- buttons to adjust the temperature (range: 95°F–167°F / 35°C–75°C) or time (range: 30 minutes–48 hours). Temperature adjusts in 1°F increments.
4. Once settings are desired, press the Start/Stop button to begin dehydration.

4.3 Using Presets

The dehydrator includes 10 one-touch presets for common foods:

1. Press the Preset button to cycle through the available presets (e.g., Apple, Banana, Lemon, Beef/Pork, Chicken, Fish, Mushroom, Vegetables, Fruit Roll, Yogurt).
2. Each preset has a default temperature and time. You can adjust these settings using the TEMP/TIME and +/- buttons if needed.
3. Press the Start/Stop button to begin dehydration with the selected preset.

4.4 Drying Tips and Features

- **Horizontal Airflow:** The dehydrator uses horizontal airflow technology for consistent drying across all 10 trays, eliminating the need to rotate or rearrange food during the process.
- **Viewing Windows & Light:** Two viewing windows and a built-in interior light allow you to monitor the drying progress without opening the door.




Image: Dehydrator with food visible through viewing windows.

- **Quiet Operation:** The dehydrator operates at a low noise level, typically under 48 dB, allowing for use day or night without significant disturbance.
- **Auto Shut-off:** The unit will automatically shut off once the set drying time has elapsed.




Image: Dehydrator operating quietly with auto-shutoff feature.

4.5 Food Preparation Guidelines

- **Slice Evenly:** For best results, slice food items to a uniform thickness to ensure even drying.
- **Do Not Overload:** Arrange food in a single layer on the trays, leaving space between pieces for air circulation. Do not stack food.
- **Pre-treatment:** Some fruits and vegetables may benefit from pre-treatment (e.g., blanching, soaking in lemon juice) to prevent discoloration or improve texture. Refer to the included recipe book for specific recommendations.

5. Maintenance and Cleaning

Regular cleaning will help maintain the performance and longevity of your food dehydrator.

5.1 Cleaning the Trays and Accessories

- The stainless steel trays, mesh screen, and fruit roll sheet are dishwasher-safe.
- Alternatively, wash them by hand with warm, soapy water. Use a non-abrasive sponge or cloth to prevent scratching.
- Rinse thoroughly and dry completely before storing or reusing.




Image: Dishwasher-safe trays for easy cleanup.

5.2 Cleaning the Unit

- Always unplug the dehydrator before cleaning.
- Wipe the exterior of the dehydrator with a damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
- For the interior, wipe with a damp cloth and mild detergent if necessary. Ensure the interior is completely dry before plugging the unit back in.

- Do not immerse the dehydrator in water or any other liquid.

5.3 Storage

Ensure the dehydrator and all its components are clean and completely dry before storing. Store the unit in a cool, dry place.

6. Troubleshooting

If you encounter any issues with your dehydrator, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Dehydrator does not turn on.	Not plugged in; power outlet not working; unit not switched on.	Ensure the unit is securely plugged into a working outlet. Press the Start/Stop button.
Food is not drying evenly.	Food sliced unevenly; trays overloaded; door not fully closed.	Slice food to uniform thickness. Do not overload trays. Ensure the door is securely closed.
Dehydrator is too noisy.	Unit not on a flat surface; internal fan obstruction.	Place the dehydrator on a stable, flat surface. Check for any obstructions around the fan (unplug first).
Display shows an error code.	Internal malfunction.	Unplug the unit for 5 minutes, then plug it back in. If the error persists, contact customer support.

7. Specifications

Model Number	CFD-P103-KUS
Power Supply	AC 120V, 60Hz
Rated Power	640W
Temperature Range	95°F–167°F (35°C–75°C)
Timer Range	30 min–48 hr
Number of Trays	10 Stainless Steel Trays
Total Drying Area	7.4 ft^2
Dimensions (D x W x H)	14.8" x 12.3" x 13" (37.6 cm x 31.2 cm x 33 cm)
Item Weight	17 pounds (7.7 kg)
Material	Stainless Steel

Color	Metal Silver

8. Warranty and Support

This Cosori Food Dehydrator comes with a**2-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover:

- Damage due to accident, misuse, abuse, or improper operation.
- Damage caused by unauthorized repairs or modifications.
- Normal wear and tear.

For warranty claims, technical support, or any questions regarding your product, please contact Cosori Customer Support. Have your order number and product model number ready when contacting support.

Website: www.cosori.com
Email: support@cosori.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H3PDPV1L

More documents and user manuals: **https://manuals.plus/**