Music Sound NUMIA

Music Sound Numia Wireless Earbuds User Manual

Model: NUMIA

1. Introduction

The Music Sound Numia wireless earbuds are designed to provide a high-quality audio experience with advanced features such as Active Noise Cancellation (ANC) and Transparency Mode. This manual will guide you through the setup, operation, and maintenance of your earbuds to ensure optimal performance and longevity.



Image 1.1: Music Sound Numia Wireless Earbuds in their charging case.

2. Package Contents

Please check the package for the following items:

- Numia TWS Earbuds
- USB-C Charging Cable

- User Manual

3. Setup

3.1 Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging port on the case and to a compatible USB power source. The charging indicator on the case will show the charging status.

3.2 Bluetooth Pairing

1. Ensure the earbuds are in the charging case and the case has sufficient battery.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "Music Sound Numia" from the list of found devices to connect.
5. Once connected, the earbuds will automatically pair with your device when removed from the case in the future.

3.3 Ergonomic Fit

For optimal sound quality and comfort, ensure a secure fit. The earbuds feature an in-ear ergonomic design. Gently insert each earbud into your ear canal and twist slightly until it feels snug and comfortable. A proper seal is crucial for effective Active Noise Cancellation.



Image 3.1: Proper fit of the Numia earbuds for comfort and stability.

4. Operating Instructions

4.1 Touch Controls

The Numia earbuds feature touch controls on the outer surface of each earbud. Specific functions are activated by single, double, or long presses. Refer to the quick start guide included in the package for a detailed list of touch commands for playback, call management, and mode switching.

4.2 Active Noise Cancellation (ANC)

Active Noise Cancellation reduces external environmental noise, allowing for a more immersive listening experience. This feature is particularly useful in noisy environments such as public transport or busy offices.



Image 4.1: Visual representation of Active Noise Cancellation blocking external sound.

To activate or deactivate ANC, use the designated touch control on the earbuds. Please note that some user reviews indicate that the ANC setting may reset when the earbuds are placed back in the case or powered off, requiring manual re-activation.

4.3 Transparency Mode

Transparency Mode allows you to hear your surroundings without removing the earbuds. This is beneficial for maintaining awareness in urban environments, listening to announcements, or engaging in brief conversations.



Image 4.2: Visual representation of Transparency Mode allowing external sound to pass through.

To activate or deactivate Transparency Mode, use the designated touch control on the earbuds.

5. Charging and Battery Life

The Numia earbuds offer up to 30 hours of total playback time with the charging case. A full charge of the earbuds and case takes approximately 2 hours.

- **Earbud Playtime:** Up to 5 hours on a single charge.
- **Total Playtime with Charging Case:** Up to 30 hours.
- **Charging Time:** Approximately 2 hours for a full charge of the case and earbuds.



Image 5.1: Battery life indication for earbuds and charging case.

To charge the earbuds, place them back into the charging case. The case will automatically begin charging them. To charge the case, connect it to a power source using the USB-C cable.

6. Maintenance

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Moisture:** Do not expose the earbuds or charging case to water or excessive moisture.
- **Temperature:** Avoid storing or using the earbuds in extreme temperatures.

7. Troubleshooting

If you encounter issues with your Music Sound Numia earbuds, refer to the following common solutions:

Problem	Solution
Earbuds do not pair with device.	1. Ensure Bluetooth is enabled on your device. 2. Place earbuds in the case, close, then open to re-enter pairing mode. 3. Forget/remove the earbuds from your device's Bluetooth list and try pairing again. 4. Ensure earbuds and case are charged.
No sound or low volume.	1. Check device volume and earbud volume. 2. Ensure earbuds are properly seated in your ears for a good seal. 3. Reconnect the earbuds to your device. 4. Clean any debris from the earbud speakers.
Active Noise Cancellation (ANC) is not working or resets.	1. Ensure ANC is activated via touch control. 2. Confirm earbuds have a secure fit in your ears. 3. If ANC resets, re-activate it manually after removing earbuds from the case.
Earbuds not charging.	1. Ensure the charging cable is securely connected to both the case and the power source. 2. Check if the charging contacts on the earbuds and inside the case are clean and free of debris. 3. Try a different USB-C cable or power adapter.

8. Specifications

Key technical specifications for the Music Sound Numia Wireless Earbuds:

- **Model Name:** NUMIA
- **Model Number:** BTMSTWSNUMIAK
- **Brand:** Music Sound
- **Connectivity Technology:** Wireless
- **Wireless Communication Technology:** Bluetooth
- **Bluetooth Version:** 6.0
- **Bluetooth Range:** 10 meters
- **Form Factor:** In-ear
- **Noise Control:** Active Noise Cancellation
- **Control Method:** Touch
- **Battery Life (Earbuds):** Up to 5 hours
- **Battery Life (with Charging Case):** Up to 30 hours
- **Battery Charge Time:** Approximately 2 hours
- **Weight:** 103 grams (total)
- **Included Components:** Numia TWS Earbuds, USB-C Cable, User Manual
- **Manufacturer:** Cellularline S.p.A.
- **Country of Origin:** China

9. Warranty and Support

The Music Sound Numia Wireless Earbuds come with a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use.
For warranty claims, technical support, or further assistance, please contact your retailer or visit the official Music Sound website. Keep your proof of purchase for warranty validation.

© 2026 Music Sound. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question