GoodHome 5059340214887

GoodHome Rand Metal High Cabinet User Manual

Model: 5059340214887

1. Important Safety Information

WARNING: To prevent tipping, this furniture must be securely fixed to the wall using the provided wall mounting system. Failure to do so can result in serious injury.

Screws and wall plugs suitable for your specific wall type are not included and must be purchased separately. Always ensure you use appropriate fixings for your wall material (e.g., plasterboard, concrete, wood).

Keep children away during assembly. Ensure all components are correctly installed before use.

2. Product Overview

The GoodHome Rand Metal High Cabinet is a robust storage solution designed for environments such as garages, workshops, or cellars. Constructed from steel with a matte black powder-coated finish, it offers durability and resistance to rust.

- **Dimensions:** H 180 cm x W 80 cm x D 40 cm
- **Storage:** Features 3 adjustable shelves, allowing you to customize the storage space to fit various item sizes. The cabinet has a total of 4 shelf positions (including the base).
- **Security:** Equipped with a key locking system for secure storage and controlled access to contents.
- **Stability:** Adjustable feet ensure optimal stability on uneven floor surfaces.
- **Load Capacity:** Maximum load per shelf and overall stability up to 50 kg.



Figure 2.1: Front view of the GoodHome Rand Metal High Cabinet.

3. Package Contents

Please check that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- 1 x GoodHome Rand Metal High Cabinet (unassembled)
- 1 x Instruction Manual
- 2 x Keys for locking mechanism
- 1 x Installation Kit (includes cabinet hardware for assembly, excluding wall fixings)
- Adjustable Feet

4. Assembly Instructions

Self-assembly is required for this cabinet. It is recommended to have two people for assembly. Ensure you have adequate space and the necessary tools (e.g., screwdriver, wrench, drill for wall mounting) before starting.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all components listed in Section 3 are present.
2. **Assemble Frame:** Follow the diagrams in the included installation kit to connect the side panels, back panel, and top/bottom panels using the provided screws and fasteners. Do not overtighten screws initially.
3. **Install Shelves:** Insert the shelf supports into the desired slots on the side panels. Place the adjustable shelves onto the supports. Ensure shelves are level and securely seated.
4. **Attach Doors:** Mount the cabinet doors using the hinges provided. Adjust hinges as necessary to ensure doors close properly and are aligned.
5. **Install Locking Mechanism:** Secure the locking mechanism and handle to the door as per the installation kit instructions. Test the lock with the provided keys.
6. **Attach Adjustable Feet:** Screw the adjustable feet into the base of the cabinet. Once the cabinet is in its final position, adjust the feet to ensure the cabinet is level and stable on the floor.
7. **Wall Mounting (Crucial Safety Step):** Position the assembled cabinet in its desired location. Mark the wall through the pre-drilled holes in the cabinet's back panel for the wall mounting system. Drill appropriate holes in the wall and

insert suitable wall plugs (not supplied). Secure the cabinet to the wall using screws (not supplied) that are compatible with your wall plugs and wall material. This step is essential to prevent the cabinet from tipping over.



Figure 4.1: Interior view of the cabinet, showing adjustable shelves.

5. Operating Instructions

- **Adjusting Shelves:** To adjust the height of the shelves, first empty the shelf. Lift the shelf slightly, remove the shelf supports from their current slots, and reinsert them into the desired new slots. Carefully place the shelf back onto the supports, ensuring it is level and secure.
- **Using the Locking Mechanism:** Insert one of the provided keys into the lock on the cabinet door. Turn the key to lock or unlock the cabinet. Always remove the key after locking to prevent unauthorized access.
- **Adjusting Feet:** If the cabinet is unstable or wobbles, gently tilt it to access the adjustable feet at the bottom. Rotate the feet clockwise to shorten them or counter-clockwise to lengthen them until the cabinet is level and stable on the floor.

6. Maintenance

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the matte black powder-coated finish.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary. Inspect the wall mounting for any signs of loosening or damage.
- **Rust Prevention:** While the cabinet has a resistant finish, avoid prolonged exposure to excessive moisture or corrosive substances to maintain its appearance and prevent rust.

7. Troubleshooting

- **Cabinet is Unstable/Wobbles:**
  - Ensure the adjustable feet are properly adjusted to level the cabinet on uneven floors (refer to Section 5).
  - Verify that all assembly screws are tightened.
  - Confirm the cabinet is securely wall-mounted as per safety instructions (Section 1 and 4).

- **Doors Do Not Close Properly:**
  - Check hinge alignment and adjust if necessary.
  - Ensure the cabinet itself is level and square.
- **Lock Mechanism Not Working:**
  - Ensure the key is fully inserted and turned correctly.
  - Check for any obstructions preventing the lock from engaging.
  - Verify the lock mechanism was installed correctly during assembly.

8. Specifications

Brand:	GoodHome
Model Name:	Rand
Model Number:	5059340214887
Material:	Alloy Steel
Color:	Matte Black
Dimensions (H x W x D):	180 cm x 80 cm x 40 cm
Item Weight:	31.5 Kilograms
Maximum Load Capacity:	50 Kilograms (per shelf and overall)
Number of Shelves:	4 (3 adjustable)
Lock Type:	Key Lock
Special Features:	Adjustable feet, Rust resistant, Lockable
Assembly Required:	Yes
Mounting Type:	Floor Mount (Wall mounting recommended)
Country of Origin:	China

9. Warranty

This GoodHome Rand Metal High Cabinet is covered by a**10-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects and material faults under normal use and maintenance conditions.

Please retain your proof of purchase for any warranty claims. The warranty does not cover damage caused by improper assembly, misuse, neglect, accidents, or unauthorized modifications.



Figure 9.1: Manufacturer's 10-year warranty.

10. Support & Recycling

For further assistance, technical support, or to report missing/damaged parts, please refer to the contact information provided with your purchase documentation or visit the GoodHome official website.

Recycling Information:

Please dispose of packaging materials responsibly. Cardboard and plastic components should be separated and placed in appropriate recycling bins.

At the end of its life cycle, this metal cabinet should be recycled according to local regulations. Consider donating or recycling the product through designated collection points or facilities.



Figure 10.1: Instructions for recycling packaging and the product.

© 2023 GoodHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question