Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Prestige 40217

Prestige Stellora Stainless Steel 3 Burner LP Gas Stove User Manual

Model: 40217

1. Introduction

Thank you for choosing the Prestige Stellora Stainless Steel 3 Burner LP Gas Stove. This manual provides essential information for the safe and efficient use, installation, maintenance, and troubleshooting of your new gas stove. Please read these instructions carefully before operating the appliance and retain them for future reference.

2. Important Safety Instructions

WARNING: Failure to follow these safety instructions may result in fire, explosion, property damage, personal injury, or death.

- Ensure proper ventilation in the kitchen area when the gas stove is in use.
- Do not store flammable materials near the gas stove.
- Keep children and pets away from the appliance during operation.
- Always use appropriate cookware for gas stoves.
- If you smell gas, immediately turn off the gas supply, open windows, and do not operate any electrical switches or appliances. Contact your gas supplier or a qualified technician.
- The gas tube must be checked regularly for wear or leaks. It must be replaced every two years. If it is damaged or if you notice a leak, the gas tube should be replaced immediately.
- Do not attempt to repair or modify the appliance yourself. Contact authorized service personnel.

3. Product Overview and Features

The Prestige Stellora gas stove is designed for efficient and convenient cooking. It features a durable stainless steel body and brass burners.

Key Features:

- **Stainless Steel Body:** Durable and easy to clean.
- **Brass Burners:** Designed for even heat distribution and long-lasting performance.

- **Heavy-Duty Pan Supports:** Provides stable support for various cookware.
- **User-Friendly Ezy Tray:** Removable spill tray for quick and effortless cleaning.
- **Convenient Cleaning Stand:** Elevated design for easy access and thorough cleaning underneath.
- **Anti-skid Legs:** Ensures stability during use.
- **360° Revolving Nozzle:** Offers flexible gas connection.
- **Ergonomic Knobs:** For comfortable and precise flame control.



Figure 1: Designed for Durability and Convenience, featuring Jumbo Burners, Heavy-Duty Pan Support, and Sabaf Burner.



Figure 2: User-Friendly Ezy Tray, a removable spill tray for quick and effortless cleaning.



Figure 3: Convenient Cleaning Stand, an elevated design for easy access and thorough cleaning underneath.



Figure 4: Efficient Hassle-Free Cooking with High-Speed Jumbo Burner and Anti-skid Legs.



Figure 5: 360° Revolving Nozzle and Ergonomic Knob for ease of use.



Figure 6: Removable pan supports and drip tray for less cleaning time.

4. Setup and Installation

4.1 Unpacking

- Carefully remove the gas stove from its packaging.
- Check for any damage during transit. If damaged, do not use and contact customer support.
- Ensure all components are present: Gas Stove unit, 3 Brass Burners, 3 Pan Supports.

4.2 Placement

- Place the gas stove on a stable, flat, and heat-resistant surface.
- Ensure adequate clearance from walls and overhead cabinets for proper ventilation and safety.
- The stove is designed for LPG (Liquefied Petroleum Gas) use only.



Figure 7: Dimensions of the gas stove for proper placement (approx. 79 cm length, 45 cm width, 11 cm height).

4.3 Gas Connection

- Connect the gas stove to an LPG cylinder using a certified gas hose and regulator.
- Ensure all connections are tight and leak-free. Use soapy water to check for leaks (bubbles indicate a leak).
- The 360° revolving nozzle allows for flexible connection of the gas tube.
- It is recommended that installation be performed by a qualified technician.

5. Operating Instructions

5.1 Lighting a Burner

1. Ensure the gas cylinder valve is open.
2. Push and turn the desired burner knob counter-clockwise to the 'ON' position (usually indicated by a flame symbol).
3. Simultaneously, use a gas lighter to ignite the burner. Hold the lighter near the burner until the flame ignites.

4. Once lit, adjust the flame intensity by rotating the knob between the 'SIM' (simmer) and 'OFF' positions.

5.2 Adjusting Flame

- Rotate the ergonomic knob towards 'SIM' for a lower flame and towards 'ON' for a higher flame.
- Always ensure the flame is blue and stable. A yellow or flickering flame may indicate improper gas-air mixture, requiring professional adjustment.

5.3 Turning Off

- To turn off a burner, rotate its knob clockwise to the 'OFF' position.
- After cooking, it is recommended to close the main valve of the gas cylinder.

6. Care and Maintenance

6.1 Daily Cleaning

- Allow the stove to cool completely before cleaning.
- Wipe the stainless steel body with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners.
- Remove the pan supports and clean them with soap and water.
- The Ezy Tray can be easily removed and cleaned to manage spills.



Figure 8: Cleaning the removable Ezy Tray.

6.2 Burner Cleaning

- Periodically clean the brass burners to ensure efficient flame.
- Remove the burners and wash them with warm soapy water. Use a soft brush to clear any clogged holes.
- Ensure burners are completely dry before placing them back on the stove.

6.3 Gas Tube Inspection

- Regularly inspect the gas tube for any signs of wear, cracks, or damage.
- Replace the gas tube every two years, or immediately if any damage or leaks are detected.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Burner not lighting	◦ Gas cylinder valve closed ◦ Gas tube kinked or blocked ◦ Burner holes clogged ◦ No gas supply	◦ Open gas cylinder valve ◦ Check and straighten gas tube ◦ Clean burner holes ◦ Check gas supply from provider
Uneven or yellow flame	◦ Burner holes clogged ◦ Improper air-gas mixture	◦ Clean burner holes ◦ Contact a qualified technician for adjustment
Gas smell	◦ Gas leak from connections or tube ◦ Burner not fully off	◦ Immediately turn off gas supply, ventilate area, do not operate electrical switches. Contact gas supplier/technician. ◦ Ensure all knobs are in the 'OFF' position.

8. Specifications

Feature	Detail
Brand	Prestige
Model Number	40217
Fuel Type	LPG (Liquefied Petroleum Gas)
Number of Burners	3
Burner Type	Open, Brass
Body Material	Stainless Steel
Product Dimensions (D x W x H)	88D x 52W x 15.5H Centimeters
Item Weight	11300 Grams
Included Components	Gas Stove, Burners

9. Warranty Information

This Prestige Stellora Gas Stove comes with a**15 Year Manufacturer Warranty**.
For detailed terms and conditions, please refer to the warranty card included with your product or contact Prestige customer support.

10. Customer Support

For any queries, service requests, or assistance, please contact Prestige customer support:

- **Manufacturer:** TTK PRESTIGE LIMITED

- **Registered Office:** Plot No. 38, SIPCOT Industrial Complex, Hosur – 635126, Tamil Nadu, India
- **Phone:** 080-6000 4411
- **Email:** customercare@ttkprestige.com

Please have your model number (40217) and purchase details ready when contacting support.

© 2026 Prestige. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H4LYM3BD

More documents and user manuals: **https://manuals.plus/**