HOMSHADE HY21LB

HOMSHADE 10ft Cantilever Patio Umbrella with Light

Model: HY21LB

Introduction

Thank you for choosing the HOMSHADE 10ft Cantilever Patio Umbrella. This manual provides essential information for the safe assembly, operation, maintenance, and care of your new umbrella. Please read these instructions carefully before use and retain them for future reference.

Setup and Assembly

The HOMSHADE 10ft Cantilever Patio Umbrella is designed for straightforward assembly. It includes a complete base system for stability. For optimal stability, the sandbag base requires filling with sand (sand not included).

Components Overview

- Umbrella Canopy with Frame
- Main Pole
- Cross Base
- 2 Large-Capacity Sandbags
- Premium Fabric Base Cover
- Hardware (screws, tools if included)

Assembly Steps

1. **Install the Screws:** Attach the main pole to the cross base using the provided screws. Ensure all connections are secure.
2. **Set the Base Frame:** Position the cross base in your desired location.
3. **Fill Sandbags:** Fill the two large-capacity sandbags with sand. The integrated anchoring system is designed to hold up to 180 lbs of sand for maximum stability. *(Note: Sand is not included and must be purchased separately.)*

4. **Place Fabric Base Cover:** Once sandbags are filled and placed on the cross base, cover them with the premium fabric base cover for a neat appearance and added protection.



Figure 1: Base Installation Steps

Your browser does not support the video tag.

Video 1: Demonstrates the assembly process for the HOMSHADE patio umbrella, including base setup.

Operating Instructions

Opening and Closing the Umbrella

To open or close the umbrella, use the heavy-duty clockwise crank handle located on the main pole. Turn the crank handle clockwise to open the canopy and counter-clockwise to close it. Ensure the canopy is fully open or closed before leaving it unattended.



Figure 2: Crank System and Tilt Mechanism

Adjusting the Tilt

The umbrella features a secure locking mechanism that allows you to adjust the vertical tilt up to 45 degrees. This enables you to track the sun's movement and optimize shade throughout the day. To adjust, locate the tilt handle on the pole, adjust to the desired angle, and secure the lock.

Using the LED Lights

The umbrella is equipped with 32 built-in warm LED lamp beads, powered by a high-efficiency top-mounted solar panel and an 1800 mAh rechargeable battery. The lights are designed to glow brightly day and night. Ensure the solar panel is exposed to direct sunlight during the day for optimal charging. The lights will automatically turn on at dusk or can be manually controlled if a switch is present (refer to specific product details for switch location if applicable).

Maintenance and Care

Proper maintenance will extend the life and appearance of your HOMSHADE patio umbrella.

- **Cleaning the Canopy:** The 260gsm solution-dyed fabric is water repellent. Clean the canopy periodically with mild soap and water. Rinse thoroughly and allow to air dry completely before closing or storing. Avoid harsh chemicals or abrasive cleaners.
- **Frame Care:** The powder-coated steel frame is rust-resistant. Wipe down the frame with a damp cloth as needed to remove dirt and debris.
- **Storage:** When not in use for extended periods or during inclement weather, close the umbrella and secure it with the integrated ties. For long-term storage, it is recommended to use a protective cover and store the umbrella in a dry, sheltered location to prevent damage.
- **Sandbag Maintenance:** Periodically check the sandbags for any damage or leaks. Ensure they remain adequately filled to provide the necessary stability.

Troubleshooting

If you encounter issues with your HOMSHADE patio umbrella, refer to the following common solutions:

- **Umbrella Wobbles in Wind:** Ensure the sandbag base is filled to its maximum capacity (up to 180 lbs of sand). Verify all connections between the pole and base are tightened securely. While designed to withstand winds up to 30 MPH, it is recommended to close the umbrella in strong winds or severe weather conditions.
- **LED Lights Not Working:** Check that the solar panel is clean and receiving direct sunlight for several hours during the day. Ensure the rechargeable battery is properly installed and charged. If the issue persists, the battery may need replacement.
- **Crank Mechanism Stiff:** Apply a silicone-based lubricant to the moving parts of the crank mechanism if it becomes stiff. Avoid oil-based lubricants that can attract dirt.

Specifications

Model Number	HY21LB
Umbrella Diameter	10 ft (3.05 m)
Overall Height	8.7 ft (2.65 m)
Canopy Material	260gsm Solution-Dyed Acrylic Fabric, UPF 50+ coating
Frame Material	Powder-Coated Steel (1.9-inch pole, 18x12mm ribs)
Wind Resistance	Up to 30 MPH
LED Lights	32 Warm LED Lamp Beads, Solar-Powered
Battery	1 x 12V rechargeable battery (included)
Base Included	Cross Base, 2 Sandbags (sand not included), Fabric Cover
Approx. Item Weight	39.6 lbs (17.96 kg)



Figure 3: Product Dimensions

Warranty Information

The HOMSHADE 10ft Cantilever Patio Umbrella canopy is crafted from ultra-premium 260gsm solution-dyed fabric with a high-density UPF 50+ coating. This material is certified to remain vibrant for 5 years and is designed to be fade-resistant for up to 8 years, blocking 99.9% of harmful UVA/UVB rays. For specific warranty details regarding other components or to make a warranty claim, please contact HOMSHADE customer support.

Customer Support

For any questions, assistance, or to report issues with your HOMSHADE patio umbrella, please contact HOMSHADE customer support. Refer to your purchase documentation or the HOMSHADE official website for contact information.