Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

eKids B26

eKids KPop Demon Hunters Bluetooth Karaoke Microphone B26 User Manual

Model: B26 | Brand: eKids

Introduction

Thank you for purchasing the eKids KPop Demon Hunters Bluetooth Karaoke Microphone. This wireless microphone allows you to connect to compatible Bluetooth devices to stream music and amplify your voice for karaoke fun. It features multi-colored LED lights, vocal effects, and a built-in rechargeable battery for portability.

Important Safety Information

- Read all instructions before use.
- Keep this manual for future reference.
- Do not expose the unit to extreme temperatures, direct sunlight, dust, or moisture.
- Clean only with a dry cloth.
- Do not attempt to repair this unit yourself. Refer all servicing to qualified service personnel.
- Use only the charging cable provided.

Package Contents

- 1 x KPop Demon Hunters Bluetooth Karaoke Microphone (Model B26)
- 1 x USB Charging Cable

Parts and Controls

Familiarize yourself with the microphone's buttons and ports:



Figure 1: Microphone Controls and Ports Overview

This diagram illustrates the location and function of each button and port on the microphone, including the charging port, power switch, and control panel.

Button/Feature	Function
Power Switch (ON/OFF/DEMO)	Slides to turn the microphone On, Off, or into Demo mode.
Charging Cable Port (DC 5V)	Connects the USB charging cable to recharge the internal battery.
Light Show Button	Press to activate or change the multi-colored LED light show.
Bluetooth Pairing Button	Press and hold to initiate Bluetooth pairing mode.
Microphone Volume + / Next Track	Press to increase microphone volume. Press and hold for the next track.
Microphone Volume - / Previous Track	Press to decrease microphone volume. Press and hold for the previous track.

Button/Feature	Function
Sound Effects Button	Press to cycle through various sound effects.
Play/Pause Button / Siri/Google	Press to play or pause music. Press and hold to activate Siri or Google Assistant on a connected device.
Echo Effect Button	Press to apply or adjust the echo effect on your voice.
Slide Mic Switch (ON to Sing!)	Slide to the ON position to enable the microphone for singing.

Setup

1. Charging the Microphone

The microphone has a built-in rechargeable battery. Before first use, fully charge the microphone.

1. Connect the small end of the included USB charging cable to the DC 5V charging port on the microphone.
2. Connect the large end of the USB charging cable to a powered USB port (e.g., computer, USB wall adapter - not included).
3. The charging indicator light will illuminate during charging and turn off when fully charged.

2. Powering On/Off

- To turn ON: Slide the Power Switch to the 'ON' position.
- To turn OFF: Slide the Power Switch to the 'OFF' position.
- Demo Mode: Slide the Power Switch to 'DEMO' for a brief demonstration of features.

3. Bluetooth Pairing

Connect the microphone wirelessly to your smartphone, tablet, or other compatible Bluetooth device to stream music.



Figure 2: Bluetooth Compatible Devices

The microphone can connect wirelessly to a variety of devices including PCs, smartphones, tablets, and game devices.

1. Ensure the microphone is powered ON.
2. Activate Bluetooth on your device (e.g., smartphone).
3. Press and hold the **Bluetooth Pairing Button** on the microphone until the indicator light flashes, indicating it is in pairing mode.
4. On your device, search for Bluetooth devices and select "eKids B26" (or similar) from the list.
5. Once paired, the microphone will indicate a successful connection, and you can now stream audio from your device.

Operating Instructions

1. Singing with Music

After successfully pairing your device, you can start your karaoke session.



Figure 3: Singing with the Microphone
The microphone amplifies your voice and features a dynamic light show while you sing along to your favorite tunes.

1. Play music from your connected Bluetooth device.
2. Slide the **Mic Switch** to 'ON' to enable your voice.
3. Adjust your microphone volume using the **Mic Volume +/- Buttons**.
4. Use the **Play/Pause Button** to control music playback. Press and hold the **Mic Volume +/- Buttons** to skip tracks.

2. Using Vocal Effects

Enhance your performance with built-in vocal effects.

- Press the **Sound Effects Button** to cycle through different vocal sound effects.

- Press the **Echo Effect Button** to add or adjust the echo effect on your voice.

3. Activating the Light Show

The microphone features multi-colored LED lights that flash with the music and your voice.

- Press the **Light Show Button** to activate the light show.
- Press the button again to change light patterns or turn off the light show.

4. Voice Control (Siri/Google)

Access your device's voice assistant directly from the microphone.

- Press and hold the **Play/Pause Button** to activate Siri (for iOS devices) or Google Assistant (for Android devices).

5. Group Singing

While this microphone operates independently, multiple eKids KPop Demon Hunters microphones can be used simultaneously with a single Bluetooth audio source for group singing experiences.



Figure 4: Group Singing with Multiple Microphones
Enjoy karaoke with friends by using multiple microphones connected to the same music source.

Product Demonstration Video

Your browser does not support the video tag.

Video 1: Kpop Demon Hunters Bluetooth Karaoke Microphone for Kids
This video provides a visual overview of the microphone's features and how it operates, including the light show and vocal effects.

Maintenance

Cleaning

- Wipe the microphone with a soft, dry cloth.
- Do not use liquid cleaners or abrasive materials.

Storage

- Store the microphone in a cool, dry place away from direct sunlight.
- Avoid storing in areas with extreme temperatures or high humidity.

Troubleshooting

Problem	Solution
Microphone does not turn on.	Ensure the battery is charged. Connect the USB charging cable and allow it to charge for at least 30 minutes before attempting to power on again.
Cannot pair via Bluetooth.	• Ensure the microphone is in pairing mode (indicator light flashing). • Make sure Bluetooth is enabled on your device. • Move the microphone closer to your device. • Forget the device from your Bluetooth settings and try pairing again.
No sound from microphone when singing.	• Ensure the **Mic Switch** is slid to the 'ON' position. • Check the microphone volume using the **Mic Volume + Button**. • Ensure music is playing from your connected Bluetooth device.
Lights are not flashing.	Press the **Light Show Button** to activate the light show. Ensure the microphone is powered on.

Specifications

- **Model Name:** B26
- **Connectivity Technology:** Bluetooth
- **Connector Type:** USB (for charging)
- **Special Feature:** Echo Control, Vocal Effects, Light Show
- **Compatible Devices:** Laptop, Smartphone, Tablet
- **Power Source:** Battery Powered (1 Nonstandard Battery included)
- **Microphone Form Factor:** Handheld
- **Enclosure Material:** Plastic
- **Manufacturer:** KIDdesigns
- **UPC:** 092298966427

Warranty Information

This product comes with a **1 Year Limited Warranty**. For specific terms and conditions, please refer to the warranty card included with your purchase or contact customer support.

Customer Support

For further assistance, technical support, or warranty inquiries, please visit the eKids official website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.
eKids Brand Store: Visit eKids Store on Amazon

© 2026 eKids. All rights reserved. KPop Demon Hunters is a trademark of its respective owners.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H73KPFN9

More documents and user manuals: **https://manuals.plus/**