Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wisoqu Wisoqu8cvtjo32ar-11

Wisoqu 4K Digital Camera 64MP User Manual

Model: Wisoqu8cvtjo32ar-11

1. Introduction

Thank you for choosing the Wisoqu 4K Digital Camera. This manual provides detailed instructions for the proper use, setup, and maintenance of your new camera. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.

This camera is designed to capture high-quality photos and videos, featuring 4K video recording, 64-megapixel photography, 18x digital zoom, and built-in Wi-Fi for easy sharing. Its compact design makes it suitable for various uses, from travel to vlogging.



Image 1.1: The Wisoqu 4K Digital Camera in an outdoor environment, highlighting its portability.

2. Package Contents

Please verify that all items listed below are included in your package:

- 1 x Wisoqu 4K Digital Camera
- 1 x Camera Strap
- 1 x NP-40 Lithium Battery (1350mAh)
- 1 x USB Cable (Type-C)
- 1 x User Manual (this document)
- 1 x Camera Pouch

3. Camera Overview

Familiarize yourself with the main components and features of your Wisoqu 4K Digital Camera.



Image 3.1: Key features of the Wisoqu 4K Digital Camera, including its 64MP sensor, 18x digital zoom, Wi-Fi, and creative filters.



Image 3.2: Ergonomic design and key functionalities such as 4K resolution and built-in flash.

4. Getting Started

4.1. Charging the Battery

1. Insert the provided NP-40 lithium battery into the camera's battery compartment.
2. Connect the camera to a power source using the USB Type-C cable.
3. The charging indicator light will illuminate. Charging typically takes 2 to 3 hours.
4. Once fully charged, the indicator light will change or turn off.

4.2. Inserting a Memory Card

The camera supports standard memory cards up to 128GB (not included).

1. Locate the memory card slot on the camera.
2. Insert the memory card with the contacts facing the correct direction until it clicks into place.
3. To remove, gently press the card until it springs out.

5. Basic Operation

5.1. Powering On/Off

- To power on, press and hold the Power button.
- To power off, press and hold the Power button again until the screen turns off.

5.2. Taking Photos

1. Turn on the camera.
2. Select the desired photo mode (e.g., Normal Photo, Continuous Photos, Special Effects Filter Photos) using the mode dial or menu.
3. Frame your shot using the 2.8-inch screen.
4. Press the Shutter button halfway to activate auto-focus.
5. Press the Shutter button fully to capture the image.



Image 5.1: Camera display showing photo settings and a captured image.

5.3. Recording Videos

1. Turn on the camera.
2. Select the desired video mode (e.g., Normal Video, Slow Motion Video, Time-lapse Video) using the mode dial or menu.
3. Press the Shutter button to start recording.
4. Press the Shutter button again to stop recording.

6. Advanced Features

6.1. 18X Digital Zoom

Use the zoom controls (usually marked 'W' for Wide and 'T' for Telephoto) to adjust the 18x digital zoom. This allows you to bring distant subjects closer.

6.2. Auto Focus

The camera features intelligent auto-focus technology. When taking a photo, press the Shutter button halfway to allow the camera to automatically focus on your subject before fully pressing to capture.

6.3. Built-in Flash

The built-in flash provides additional illumination in low-light conditions. Access flash settings through the camera menu to select modes such as Auto Flash, Fill Flash, or Flash Off.

6.4. Creative Filter Modes

The camera offers 7 diverse filter modes to add creativity and unique styles to your photos. These can be selected via the camera's menu settings under 'Special Effects Filter Photos'.

6.5. Wi-Fi Sharing

The camera's built-in Wi-Fi allows for seamless transfer of photos and videos to your smartphone or other compatible devices. Refer to the camera's on-screen menu for Wi-Fi connection instructions and app recommendations.

7. Maintenance and Care

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for camera lenses. Avoid harsh chemicals.
- **Cleaning the Screen:** Wipe the screen gently with a microfiber cloth.
- **Storage:** When not in use, store the camera in its pouch in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove the battery if the camera will not be used for an extended period.
- **Avoid Water:** This camera is not waterproof. Avoid exposure to water or high humidity.

8. Troubleshooting

Problem	Possible Cause	Solution
Camera does not power on.	Battery is low or not inserted correctly.	Charge the battery fully. Ensure the battery is inserted with correct polarity.

Problem	Possible Cause	Solution
Cannot take photos/videos.	Memory card is full, not inserted, or corrupted.	Insert a memory card. Delete unnecessary files or format the card (this will erase all data). Replace the card if corrupted.
Images are blurry.	Lens is dirty, insufficient light, or camera shake.	Clean the lens. Use the flash in low light. Hold the camera steady or use a tripod.
Wi-Fi connection issues.	Incorrect password, out of range, or app issues.	Ensure correct Wi-Fi password. Move closer to the connected device. Restart camera and device.

9. Specifications

- **Maximum Video Resolution:** 4K, 30fps
- **Maximum Photo Resolution:** 64MP
- **Screen Size:** 2.8 inches
- **Digital Zoom:** 18X
- **Connectivity:** Wi-Fi
- **Focus:** Auto Focus
- **Flash:** Built-in Lens Fill Light
- **Battery Type:** NP-40 Lithium Battery
- **Battery Capacity:** 1350mAh
- **Charging Time:** 2 to 3 hours (via Type-C USB)
- **Storage Support:** Up to 128GB standard memory card (not included)
- **Photography Modes:** Normal Photo, Normal Video, Slow Motion Video, Time-lapse Video, Continuous Photos, Special Effects Filter Photos
- **Dimensions:** Approximately 15 x 13 x 7 cm
- **Weight:** Approximately 402 g
- **Model Number:** Wisoqu8cvtjo32ar-11
- **Country of Origin:** China

10. Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

© 2026 Wisoqu. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H7T6H3LF

More documents and user manuals: **https://manuals.plus/**