EROMMY PXWQG109WH-4

EROMMY 20x30 FT High Peak Party Tent Instruction Manual

Model: PXWQG109WH-4

1. Introduction and Safety Information

This manual provides essential instructions for the safe assembly, operation, and maintenance of your EROMMY 20x30 FT High Peak Party Tent. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Product Overview

The EROMMY 20x30 FT High Peak Party Tent features a spacious, pole-free design with a durable 350GSM waterproof PVC canopy and a commercial-grade galvanized steel frame. It is designed for various outdoor events, providing reliable shelter and an unobstructed interior space.

Safety Warnings

- **Weather Conditions:** This tent is designed for temporary use in mild weather conditions. It is suitable for wind speeds up to 25 mph when properly anchored. Do not use in heavy rain, strong winds, lightning, or heavy snowfall. Disassemble the tent immediately if severe weather is anticipated.
- **Anchoring:** Always ensure the tent is securely anchored to the ground using all provided stakes and ropes. Failure to do so may result in property damage or personal injury.
- **Assembly:** Assembly requires at least two adults. Do not attempt to assemble the tent alone.
- **Clearance:** Ensure adequate clearance from power lines, trees, and other structures during setup.
- **Fire Safety:** Keep all flame and heat sources away from the tent fabric. The fabric is not fireproof.



Image 1.1: The EROMMY 20x30 FT High Peak Party Tent providing shelter for an outdoor event.

2. Product Components

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact customer support immediately.

Main Components:

- Galvanized Steel Frame Poles (legs, cross beams, connectors)
- 350GSM Waterproof PVC Canopy Fabric
- Thickened Heavy-Duty Solid Base Plates
- Ground Stakes
- Tension Ropes
- Rope Tighteners

- Assembly Gloves (recommended for handling poles)



Image 2.1: A visual representation of all included components and accessories.

3. Setup Instructions

Follow these steps carefully for proper and safe assembly. It is highly recommended to have at least two people for assembly.

1. **Prepare the Area:** Choose a flat, level surface free from obstructions. Clear any sharp objects that could damage the canopy.
2. **Unpack Components:** Lay out all frame poles, connectors, and the canopy fabric. Organize them for easy access.
3. **Assemble the Base Frame:** Connect the horizontal and vertical poles to form the rectangular base of the tent. Ensure all connections are secure.
4. **Install Roof Structure:** Attach the roof cross beams and center structure components. The reinforced tent center structure uses 42mm-diameter, 1.2mm-thick galvanized steel tubes for stability.
5. **Drape the Canopy:** Carefully spread the 350GSM PVC canopy fabric over the assembled frame. Ensure the high peak sections are correctly aligned with the frame's peak points.
6. **Secure the Canopy:** Attach the canopy to the frame using the integrated fasteners. Ensure the fabric is taut and evenly distributed to prevent water pooling. Utilize the 6 rope tighteners to adjust the tightness of the top fabric, preventing water accumulation.
7. **Anchor the Tent:** Attach the thickened, widened wind ropes to the designated points on the tent frame. Drive the heavy-duty ground stakes firmly into the ground at an angle, ensuring they are fully embedded. Secure the wind ropes to the stakes, adjusting tension as needed. The thickened heavy-duty solid base plates (52mm diameter galvanized metal tube, 1.4mm thickness) provide additional stability.
8. **Final Check:** Inspect all connections, anchoring points, and canopy tension to ensure the tent is stable and secure before use.



Image 3.1: Visual guide for the tent setup process.



Image 3.2: Detail of a rope tightener for canopy tension adjustment.



Image 3.3: Detail of the thickened heavy-duty solid base for tent legs.



Image 3.4: Reinforced wind ropes and ground stakes for enhanced stability.

4. Operating Instructions

Once assembled, the EROMMY High Peak Party Tent provides a versatile space for various outdoor applications.

General Use

- The tent is ideal for weddings, parties, exhibitions, markets, and other outdoor gatherings.
- The pole-free interior allows for flexible arrangement of tables, chairs, and equipment.

Weather Considerations

- Regularly check the weather forecast. If strong winds (above 25 mph), heavy rain, or snow are predicted, it is recommended to disassemble the tent.
- In rainy conditions, periodically check the canopy for water accumulation. Use the rope tighteners to maintain canopy tension and prevent pooling.
- The 350GSM PVC canopy offers reliable waterproof and UV-resistant protection.



Image 4.1: The tent's outstanding weatherproof features.

5. Maintenance

Proper maintenance will extend the lifespan of your EROMMY Party Tent.

Cleaning

- **Canopy:** Clean the PVC canopy with mild soap and water. Do not use harsh chemicals or abrasive cleaners, as these can damage the fabric's protective coating. Rinse thoroughly and allow to air dry completely before storage.
- **Frame:** Wipe down the galvanized steel frame with a damp cloth to remove dirt and debris. Ensure all parts are dry to prevent rust.

Storage

- Before disassembling and storing, ensure all components, especially the canopy, are completely dry to prevent mold and mildew.
- Disassemble the tent in reverse order of assembly.
- Store the canopy and frame components in a cool, dry place, protected from direct sunlight and extreme temperatures.

Inspection

- Periodically inspect the frame for any signs of damage, bending, or corrosion.
- Check the canopy for tears, punctures, or weakened areas.
- Ensure all ropes, stakes, and tighteners are in good working condition. Replace any worn or damaged parts.

6. Troubleshooting

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Water pooling on canopy	Canopy not taut enough; improper tension	Adjust rope tighteners to increase canopy tension. Ensure even distribution.
Tent instability in wind	Insufficient anchoring; loose ropes/stakes	Ensure all ground stakes are fully embedded and ropes are taut. Add additional anchoring if necessary (e.g., sandbags, weights). Disassemble in strong winds.
Difficulty connecting frame poles	Misalignment; debris in connectors	Ensure poles are correctly oriented. Clear any debris from connectors. Apply slight pressure and twist gently. Do not force connections.

7. Specifications

Feature	Detail
Brand	EROMMY
Model Number	PXWQG109WH-4

Feature	Detail
Product Dimensions (L x W x H)	360"L x 240"W x 204.72"H (20x30 FT)
Item Weight	317 pounds
Frame Material	Galvanized Steel (2.05-inch legs, 42mm cross beams)
Canopy Material	350GSM Waterproof PVC
Water Resistance Level	Waterproof
Ultraviolet Light Protection	Yes
Color	White

8. Warranty and Support

Warranty Information

Please refer to your purchase documentation or contact the seller for specific warranty details regarding your EROMMY 20x30 FT High Peak Party Tent. Typically, warranties cover manufacturing defects under normal use conditions.

Customer Support

For any questions, missing parts, or assistance with assembly or operation, please contact EROMMY customer service or the retailer from whom you purchased the product. Have your model number (PXWQG109WH-4) and purchase date ready when contacting support.
You may also visit the official EROMMY store for additional product information and support resources:EROMMY Store

© 2023 EROMMY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question