Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DGM-EFR19

Generic 18-inch Adjustable Pedestal Fan

Model: DGM-EFR19 / SF1

Important Safety Instructions

Please read all instructions carefully before using this appliance and retain for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Always ensure the fan is unplugged from the power outlet before cleaning, assembling, or disassembling. Do not operate the fan with a damaged cord or plug. Do not run the power cord under carpeting or cover it with throw rugs.
- **High Surge Safe Plug:** This fan is equipped with a high surge safe plug designed to protect the appliance and your home electrical system from power surges. Do not bypass or modify this plug.
- **Placement:** Place the fan on a stable, level surface to prevent it from tipping over. Do not use the fan in wet or damp locations, such as bathrooms or laundry areas. Keep the fan away from curtains, drapes, or any objects that may be drawn into the fan blades.
- **Children and Pets:** Keep children and pets away from the fan, especially when it is operating. Ensure fingers or other objects are not inserted into the fan grille.
- **Ventilation:** Do not block air openings. Ensure adequate space around the fan for proper air circulation.
- **Overheating:** If the fan overheats, immediately unplug it and allow it to cool down before attempting to use it again.

Package Contents

Verify that all components are present and in good condition before assembly.

- 1 x 18-inch Electric Pedestal Fan (unassembled)
- 1 x High Surge Safe Plug (pre-attached to power cord)
- User Manual

Assembly Instructions

Follow these steps to assemble your pedestal fan. Ensure the fan is unplugged during assembly.

1. **Assemble the Base:** Attach the main pole to the base unit. Secure it firmly using the provided screws or locking mechanism.
2. **Attach the Adjustable Pole:** Insert the adjustable height pole into the main pole. Adjust to desired height and secure with the height adjustment knob.
3. **Mount the Motor Unit:** Place the motor unit onto the top of the adjustable pole and secure it with the locking screw

or knob.

4. **Install the Rear Grille:** Position the rear grille onto the motor unit, aligning the mounting holes. Secure it with the provided locking nut.
5. **Attach the Fan Blades:** Slide the fan blades onto the motor shaft. Ensure they are seated correctly and secure them with the blade cap.
6. **Install the Front Grille:** Place the front grille over the fan blades, aligning it with the rear grille. Secure both grilles together using the clips or screws provided around the circumference.



Figure 1: Fully assembled 18-inch pedestal fan, ready for operation.

Operating Instructions

Once assembled, your fan is ready for use.

1. **Power Connection:** Insert the high surge safe plug into a standard 220-240V, 50Hz electrical outlet.
2. **Turn On/Speed Control:** Locate the rotary switch or push buttons on the motor unit. Turn the switch to position '1', '2', or '3' to select the desired fan speed. '0' typically indicates off.
3. **Oscillation Function:** To activate oscillation (fan head rotates side-to-side), push down the oscillation knob located on top of the motor unit. To stop oscillation, pull the knob up.
4. **Tilt Adjustment:** To adjust the vertical angle of the fan head, loosen the tilt adjustment knob on the side of the motor unit, tilt the head to the desired angle, and then tighten the knob firmly.
5. **Height Adjustment:** To adjust the fan's height, loosen the height adjustment knob on the pole, raise or lower the pole to the desired height, and then tighten the knob securely.
6. **Turn Off:** Turn the speed control switch to the '0' position and unplug the fan from the power outlet when not in use.



Figure 2: Side view of the pedestal fan, illustrating its adjustable features.

Maintenance and Cleaning

Regular cleaning will help maintain the fan's performance and extend its lifespan.

- **Always Unplug:** Before any cleaning or maintenance, ensure the fan is unplugged from the power outlet.
- **Exterior Cleaning:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Grille and Blades:** To clean the fan blades and inside the grilles, you may need to carefully remove the front grille. Use a soft cloth or a vacuum cleaner with a brush attachment to remove dust and debris. Ensure all parts are dry before reassembling and operating the fan.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

Troubleshooting

If you encounter issues with your fan, refer to the following common problems and solutions.

- **Fan Does Not Turn On:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the speed control switch is set to an 'ON' position (1, 2, or 3).
  - Verify that the electrical outlet is functioning by plugging in another appliance.
- **Weak Airflow:**
  - Increase the fan speed setting.
  - Check for any obstructions around the fan grilles that might be blocking airflow.
  - Clean the fan blades and grilles if they are dusty.
- **Unusual Noise:**
  - Ensure the fan is placed on a stable, level surface.
  - Check if the fan grilles or blades are loose or damaged. Tighten any loose parts.

- Inspect for any foreign objects caught in the fan blades or motor housing.

- **Fan Stops Unexpectedly:**
  - The fan may have overheated. Unplug it and let it cool down for at least 30 minutes before attempting to use it again. Ensure proper ventilation.
  - Check the power connection and the electrical outlet.

If the problem persists after trying these solutions, please contact customer support or a qualified electrician.

Specifications

Model Number	DGM-EFR19 / SF1
Fan Size	18 inches (45.7 cm)
Power Consumption	55W
Voltage	220-240V
Frequency	50Hz
Number of Blades	3
Speed Settings	3-Speed Control
Special Features	Adjustable Height, Oscillation, Tilt-adjustable Fan Head, High Surge Safe Plug
Approx. Dimensions (D x W x H)	50D x 21W x 58H cm (assembled)
Approx. Weight	4.5 kg
Material	Plastic, Stainless Steel
Noise Level	55 Decibels

Warranty and Support

For warranty information, product support, or service inquiries, please refer to the documentation provided at the time of purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0HJZBDZ33

More documents and user manuals: **https://manuals.plus/**