Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SKMEI SKM-1389

SKMEI SKM-1389 Men's Analog Digital Watch Instruction Manual

Model: SKM-1389

1. Introduction

Thank you for choosing the SKMEI SKM-1389 Analog Digital Watch. This manual provides detailed instructions for setting up, operating, and maintaining your watch. Please read it carefully to ensure proper use and to enjoy all the features of your new timepiece.



Image: The SKMEI SKM-1389 watch, showcasing its design on a wrist.

2. Product Overview

The SKM-1389 watch combines analog and digital displays with multiple functions designed for daily use and active lifestyles. Key features include:

- Dual Time Display (Analog and Digital)
- Chronograph (Stopwatch)
- Alarm Function
- Date and Week Display
- LED Backlight

- 12/24 Hour Format
- Countdown Timer
- 30M Water Resistance



Image: Visual representation of the watch's multifunction capabilities, including 3 time zones, alarm, countdown, stopwatch, date/week, LED light, and 12/24 hour format.

Watch Components and Button Functions

Familiarize yourself with the watch's buttons and their primary functions:



Image: Detailed diagram labeling the LIGHT, MODE, START/STOP, and RESET buttons, along with indicators for Week, Date, Time, and Seconds on the watch face.

- **LIGHT Button:** Activates the LED backlight.
- **MODE Button:** Cycles through different modes (Time, Chronograph, Alarm, Countdown, Second Time Zone).
- **START/STOP Button:** Used to start/stop functions like chronograph or countdown, and to adjust settings.
- **RESET Button:** Used to reset functions or confirm settings.

Product Video Overview

Your browser does not support the video tag.

Video: An official product video from SKMEI Official demonstrating the Military Analog Digital Watch with Multi Time Chronograph features.

3. Setup Instructions

Setting the Digital Time and Date

1. In normal time display mode, press the **MODE** button repeatedly until the digital time display starts flashing (usually the seconds).
2. Press the **START/STOP** button to adjust the flashing value (e.g., seconds, minutes, hours).
3. Press the **RESET** button to move to the next setting item (e.g., from seconds to minutes, then hours, date, month, year).
4. Repeat steps 2 and 3 until all desired settings (seconds, minutes, hours, 12/24 hour format, month, date, day of week) are correctly set.
5. Press the **MODE** button once to exit the setting mode and return to normal time display.

Setting the Analog Time

1. Pull out the crown (the small knob on the side of the watch case) to the first or second click position (depending on the model).
2. Rotate the crown to move the analog hands to the correct time.
3. Once the analog time is set, push the crown back in to its original position.

12/24 Hour Format

While in time setting mode, you can toggle between 12-hour (AM/PM) and 24-hour formats by pressing the **START/STOP** button when the hour setting is flashing.

Second Time Zone (T2)

This watch supports a second time zone display. To set it:

1. From normal time display, press the **MODE** button until you reach the T2 (second time zone) display.
2. Press and hold the **RESET** button until the T2 time starts flashing.
3. Use the **START/STOP** button to adjust the flashing value (hours, then minutes).
4. Press the **RESET** button to move between hours and minutes.
5. Once set, press the **MODE** button to exit.

4. Operating Instructions

Using the Chronograph (Stopwatch)

1. Press the **MODE** button until you reach the Chronograph mode (indicated by 'STW' or 'CHM').
2. Press the **START/STOP** button to start the stopwatch.
3. Press the **START/STOP** button again to pause the stopwatch.
4. Press the **RESET** button to reset the stopwatch to zero.
5. To resume timing after pausing, press the **START/STOP** button.

Setting the Alarm

1. Press the **MODE** button until you reach the Alarm mode (indicated by 'ALM').
2. Press and hold the **RESET** button until the alarm hour starts flashing.
3. Use the **START/STOP** button to adjust the hour.
4. Press the **RESET** button to move to the minute setting.
5. Use the **START/STOP** button to adjust the minutes.
6. Press the **MODE** button to exit the alarm setting mode.
7. To turn the alarm ON/OFF, press the **START/STOP** button while in Alarm mode (without holding). An alarm icon will appear/disappear.

Using the Countdown Timer

1. Press the **MODE** button until you reach the Countdown mode (indicated by 'TMR' or 'CD').
2. Press and hold the **RESET** button until the countdown time starts flashing.
3. Use the **START/STOP** button to adjust the hours, then minutes, then seconds.
4. Press the **RESET** button to move between setting items.
5. Press the **MODE** button to exit the countdown setting mode.
6. To start the countdown, press the **START/STOP** button.
7. To pause, press **START/STOP** again. To resume, press **START/STOP**.
8. To reset the countdown, press the **RESET** button while the countdown is paused.

LED Backlight

Press the **LIGHT** button to illuminate the digital display for easy viewing in low-light conditions. The backlight will typically stay on for a few seconds.

5. Maintenance

Water Resistance

This watch is rated for 30 meters (3 ATM) water resistance. This means it is suitable for daily use, such as hand washing, splashes, and brief immersion in water. It is **not** suitable for prolonged underwater activities like swimming, diving, or showering with hot water. **Do not press any buttons while the watch is submerged in water.**



Image: Visual details highlighting the watch's 3ATM daily waterproof rating, luminous display, high hardness glass, and stainless steel strap.

Cleaning

To clean your watch, wipe it gently with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners or abrasive materials, as these can damage the watch's finish.

Battery Replacement

The watch is powered by 1 Lithium Ion battery (included). When the display becomes dim or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and water resistance.

6. Troubleshooting

- **Digital display is blank or dim:** The battery may be low or depleted. Replace the battery.
- **Analog hands are not moving:** Check if the crown is pushed in completely. If it is, the battery might need replacement or there could be a mechanical issue.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this model typically does not have a lock function). Try resetting the watch by pulling out the crown and pushing it back in, or if possible, temporarily removing and reinserting the battery (consult a professional).
- **Water inside the watch:** Immediately take the watch to a professional for inspection and repair to prevent further damage.

7. Specifications



Image: Detailed product information diagram showing brand, model, weight, movement type, crystal, case material, band material, buckle material, water resistance, and functions.

SKM-1389 Technical Specifications

Feature	Detail
Brand	SKMEI
Model Number	SKM-1389
Movement Type	Japanese Quartz (Analog), Digital
Display Type	Analog-Digital
Case Material	Zinc Alloy
Band Material	Stainless Steel
Clasp Type	Buckle
Crystal Material	Glass
Water Resistance Depth	30 Meters (3 ATM)

Feature	Detail
Case Diameter	40 mm
Case Thickness	15.9 mm
Band Width	22 mm
Band Length	250 mm (adjustable)
Item Weight	164 g
Power Source	Battery Powered (1 Lithium Ion battery included)

8. Warranty

This product comes with a Limited Warranty. For specific terms and conditions, please refer to the warranty information provided at the time of purchase or contact SKMEI customer support.

9. Support

If you encounter any issues or have questions not covered in this manual, please refer to the official SKMEI website or contact their customer service for assistance. Keep your purchase receipt for warranty claims.
For more information, visit the SKMEI Store on Amazon.

© 2026 SKMEI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0HKN1YLX2

More documents and user manuals: **https://manuals.plus/**