Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YITAHOME MAYIHtxQzn

YITAHOME Farmhouse TV Stand 70-inch (Model: MAYIHtxQzn) Instruction Manual

For Models Supporting 75/80 Inch TVs

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your YITAHOME Farmhouse 70-inch TV Stand. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This media console is designed to accommodate flat-panel televisions up to 80 inches and offers versatile storage solutions.

Safety Information

- Ensure all parts are present and undamaged before assembly. Do not use damaged parts.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly.
- Always use the provided anti-tipping kit to secure the TV stand to a wall, especially if children or pets are present.
- Do not exceed the maximum weight capacity of the stand or shelves.

Package Contents

Verify that all components listed in the assembly instructions are present. The package typically includes:

- TV Stand panels (engineered wood)
- Hardware kit (screws, dowels, cam locks, etc.)
- Adjustable shelf pins
- Anti-tipping kit
- Assembly Instruction Manual

Setup and Assembly

Follow the step-by-step instructions provided in the included assembly manual. General steps include:

1. **Unpack and Identify Parts:** Lay out all panels and hardware. Refer to the parts list in your assembly manual to ensure everything is accounted for.
2. **Assemble the Base:** Connect the bottom panel to the side panels using the specified hardware.
3. **Install Dividers and Shelves:** Insert the middle dividers and adjustable shelves into their designated slots. The middle shelf is adjustable to accommodate various component heights.
4. **Attach the Top Panel:** Secure the top panel to the assembled structure.
5. **Install Back Panel:** Attach the back panel, ensuring cable cutouts are correctly positioned.
6. **Apply Anti-Tipping Kit:** Securely attach the anti-tipping kit to the back of the TV stand and to a wall stud. This is a critical safety step.



Image: Key features of the YITAHOME Farmhouse TV Stand, including cable management openings, the anti-tipping kit, safety-conscious curved edges, and the decorative retro arched design.

Operating Instructions

Once assembled, your YITAHOME Farmhouse TV Stand is ready for use.

- **TV Placement:** Carefully place your flat-panel television (up to 80 inches) on the top surface of the stand. Ensure the TV's base is fully supported and centered.
- **Storage Utilization:** Use the open tiers and adjustable shelves to store media components, gaming consoles, books, or decorative items. The middle shelf can be adjusted to fit taller components.
- **Cable Management:** Utilize the pre-cut openings in the back panel to route power cords and signal cables. This helps keep wires organized and out of sight, maintaining a clean aesthetic.



Image: The TV stand's spacious storage compartments, highlighting the adjustable middle shelf for flexible organization of various items.



Image: Visual representation of the TV stand's capacity to hold televisions up to 80 inches, illustrating various TV sizes for reference.

Maintenance

To ensure the longevity and appearance of your TV stand:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the engineered wood.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Heat and Moisture:** Keep the stand away from excessive heat sources and high humidity. Use coasters under hot or wet items.
- **Hardware Check:** Periodically check and tighten all hardware to ensure stability.

Troubleshooting

If you encounter any issues with your TV stand, consider the following:

- **Instability:** Ensure all screws are tightened. Verify the stand is on a level surface. If the issue persists, re-check assembly steps.
- **Damaged Parts:** If any part arrived damaged or becomes damaged during assembly, do not proceed. Contact customer support for replacement parts.
- **Missing Hardware:** If hardware is missing, refer to the parts list in the assembly manual and contact customer support for assistance.

Specifications

Feature	Detail
Brand	YITAHOME
Model Number	MAYIHtxQzn
Color	Black Oak
Style	Farmhouse
Material Type	Engineered Wood
Item Dimensions (L x D x H)	70 x 15.7 x 26.7 inches (178 x 40 x 68 cm)
Item Weight	78.9 pounds
Supported TV Size	Up to 80 inches
Storage	Configurable storage layout with adjustable middle shelf
Cable Management	Rear cable openings
Safety Feature	Anti-tipping kit included

Image: Comprehensive dimensions of the TV stand, including external measurements and internal shelf spacing for planning your setup.

Warranty Information

Specific warranty details for this product are not provided in the available information. Please refer to the product packaging or contact YITAHOME customer service for warranty terms and conditions.

Support

For further assistance, missing parts, or any inquiries regarding your YITAHOME Farmhouse TV Stand, please contact YITAHOME customer support. You can often find contact information on the product packaging, the brand's official website, or through the retailer where the product was purchased.
Visit the official YITAHOME Store: YITAHOME Store on Amazon

© 2023 YITAHOME. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0HN4XD8H2

More documents and user manuals: **https://manuals.plus/**