Manuals+ — User Manuals Simplified.

AVATIME 914MDT100M Mini Digital Timer Instructions

AVATIME
KITCHEN TIMERS
**914MDT100M Mini Digital Timer
Instructions**

Contents

914MDT100M Mini Digital Timer

Before Use: Carefully remove plastic strip from battery compartment. This is included to preserve battery life.

Remove film from LCD display.
Cleaning and Care: Hand wash only. Do not immerse in water or put in the dishwasher.

Count down:

1. Press MIN and SEC to set desired time. Press and hold each button for fast advance.
2. Press START/STOP to start the count down.
3. Press START/STOP to pause and resume the count down.
4. When timer counts down to 0, press START/STOP to turn o the alarm and recall last time setting.
5. Press MIN and SEC simultaneously to clear the time.

Note: Set desired time in minutes and seconds up to 99 minutes and 59 seconds.

Count up:

1. Press START/STOP to start the count up.
2. Press START/STOP to pause and resume the count up.
3. Press MIN and SEC simultaneously to clear the time.

Note: The timer will count up to 99 minutes and 59 seconds.

914MDT100M

Documents / Resources

AVATIME 914MDT100M Mini Digital Timer [pdf] Instructions
914MDT100M Mini Digital Timer, 914MDT100M, Mini Digital Timer, Digital Timer, Timer