AXESS PABT6018 Double 4" LED Bluetooth Speaker Instruction Manual

**WHERE CREATIVITY &
TECHNOLOGY MEET
PABT6018
Double 4" LED
BLUETOOTH SPEAKER**

For correctly operating, please read this manual carefully before using it. Any content revise of the manual won't declare again, and we are not responsible for consequences caused by fault or oversight of this manual.

Contents <u>hide</u>

TO CUSTOMERS

Thank you for your support and trust in purchasing the products of our company. To fully exert the function of the product, we suggest you read the operating instruction carefully before using it, for the convenience of grasping the connection method and using points. Please take care of the operating instruction after reading them for the purpose of further reference.

SPECIFICATIONS

4-inch x2 Subwoofer speakers	FM radio function
10M Bluetooth range	100W (PMPO) Output power
Brilliant LED lights	1200mAh battery capacity
True Wireless Speaker (TWS Link+)	DC 5V Charging port
TF card slot, AUX input, USB input	Frequency response 150Hz-18khz
Microphone input	

ACCESSORIES

Remote Control
Charging Cable
Auxiliary Cable
Detachable strap

MODE CYCLE
Press the "MODE" button to switch USB→TF→BT→FM→AUX

OPERATING BLUETOOTH MODE

- Bluetooth version: 5.0 version, works within a 10-meter operating range
- After the power is turned ON, the led screen display will flash "BLUE" and the speaker will indicate that it is ready for a Bluetooth connection with an audible tone
- Turn on your mobile device and put it in Bluetooth mode, search for the device name "PABT6018" and confirm the connection when it appears
- Once the pairing is successful, the speaker will emit another beep tone, and the "BLUE" character will stay lit on

the screen

OPERATING TF/MICRO SD MODE

- Insert a TF card speaker and the speaker will detect the card and change it's status to TF mode
- The character "PLAY" will appear on the led screen and will start playing the music stored on the TF or MicroSD card
- The display will show "PLAY" during playback and "PAUS" will its paused

OPERATING USB disk MODE

- Inserting a USB drive into the speaker, it will automatically be detected by the device and will begin to playback the music stored in the drive
- The display will show "PLAY" during playback and "PAUS" will its paused

OPERATING FM MODE

- Press the button "MODE", enter into FM mode
- This speaker has a built-in radio antenna, doesn't need an external antenna
- Press and hold the button "PLAY/PAUSE" to automatically search the radio stations; press the same button again to pause the scanning

OPERATING AUX MODE

- Plug one end of the 3.5mm audio cable into the speaker's AUX jack, and the other end to your mobile device (cellphone, laptop, tablet, etc)
- The speaker will automatically detect the plugin to change to AUX mode and will begin playback of the music streaming on your mobile device
- Control your music from the play/pause or forward/backward buttons on the speaker panel or directly from the mobile device.

OPERATING LED FUNCTION

Press and hold 'MODE' button to turn ON or OFF the LED display lights

OPERATING TWS FUNCTION

- Begin by using your mobile device to successfully pair one of 2 Bluetooth speakers on Bluetooth mode.
- When pairing is successful, move on to the second speaker. Make sure that speaker #2 is on Bluetooth mode as well and double click the "PLAY/PAUSE" button to turn on its TWS mode.
- If both speakers are close to each willing pairing, they should quickly connect together and begin to play your music simultaneously.

CHARGING

- Take the USB charging cable and plug it into the DC 5V charging port. And charge it directly into a wall plug or into a computer USB port to charge
- To make sure your speaker is being charged, look for the charging indicator located on the right side of the LED screen. It will light up when charging and will stop lighting up when the speaker is fully charged.

Prompt
When people sleep, they need a quiet environment.
Please turn off the music or turn off the power while sleeping.

This symbol indicates to the user that the machine with risk of electric shock

⚠ This symbol indicates to the user that the machine with the important operation and maintenance instruction

NOTE:
When the speaker is not in use please turn off the device to conserve battery life.
Make sure to turn down the volume when you turn off the device so you can maintain the speakers' (sub)woofer in good condition. This way you are less like to burn out or damage the device.

<div align="center">

Axess Products Corporation
6649 Valjean Ave. Van Nuys, 91406
Tel. 818-785-4000 Fax. 818-785-5081 **info@axessusa.com**
Questions? Comments? Contact us at **support@axessusa.com**
© 2018 Axess Products Corporation. All rights reserved.

</div>

Documents / Resources

AXESS PABT6018 Double 4" LED Bluetooth Speaker [pdf] Instruction Manual
PABT6018, Double 4 LED Bluetooth Speaker

Manuals+,

- **home**
- **privacy**