🌿 Manuals+

☰

CORSAIR

DROP

CSTM80 MECHANICAL KEYBOARD

QUICK START GUIDE

CSTM80

Contents [hide]

GETTING STARTED WITH YOUR NEW CSTM80 KEYBOARD

INITIAL START-UP

- The keyboard should work out of the box with macOS, Windows and Linux operating systems.
- For CSTM80 customizability instructions, please scan the QR code or visit dro.ps/cstm80-quickstart

DEFAULT HOT KEYS

Hold Fn key + listed keys to activate

LED KEYS

Fn +	W	LED Brightness Increase
	S	LED Brightness Decrease
	E	LED Animation Speed Increase
	D	LED Animation Speed Decrease
	R	LED Hue Increase
	F	LED Hue Decrease
	T	LED Saturation Increase Off)
	G	LED Saturation DecreaseToggle
	0	LED Toggle (On / Off)
	A	LED Animation Toggle
	Z	LED Mono Color Mode
	X	LED Breathing Effect
	C	LED Rainbow Mode
	V	LED Rainbow Pinwheel Modezz

MISC CONTROL

Hold Esc (Before connecting USB)	Boot Magic (Clear EEPROM State and reboot in Bootloader)

KEYBOARD OPTION KEYS

	N	Toggle keyboard 6KRO/NKRO (Default state is 6KRO)
Fn +	LCtr1+0	Windows / MacOS Swap (System / Alt location change)
	LCtrl+|\	LCtrl / Capslock Swap
	LCtrl+ Backspace	Reset Keyboard

CUSTOMIZABLE FIRMWARE

To configure your keymap and hotkeys, please visit: dro.ps/cstm-configurator

Documents / Resources

[CORSAIR CSTM80 Custom Mechanical Keyboard](...) [[pdf](...)] Owner's Manual CSTM80, CSTM80 Custom Mechanical Keyboard, Custom Mechanical Keyboard, Mechanical Keyboard, Keyboard

References

- [User Manual](...)

📁 Corsair

🏷 Corsair, CSTM80, CSTM80 Custom Mechanical Keyboard, Custom Mechanical Keyboard, Keyboard, Mechanical keyboard

---

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz   **Search**