Manuals+ — User Manuals Simplified.

CRUMAR Mojo Desktop User Guide

Contents

CRUMAR Mojo Desktop

Features

DRAWBARS
The reason why you want the Mojo Desktop!
These typical controllers for electronic organs are used to change the sound registration.

VIBRATO/CHORUS CONTROLS
Two buttons, one large knob and 6 leds for selection of vibrato and chorus effect.

MANUAL SELECTION BUTTONS
Select which manual should be controlled by drawbars.

PERCUSSION BUTTONS
4 buttons for on/off, soft/normal, fast/slow, harmonic.

ROTARY SPEAKER SPEED BUTTONS

6 KNOBS
Used for Volume, Bass, Treble Click, Drive, Reverb.

3.2" TFT TOUCH DISPLAY
Make your deep sound editing easy by the touch functions.

TWO PARALLEL MIDI INPUTS
Typically plug here two midi keyboards, one for upper (Ch1) and one for lower (Ch2).

VALUE ENCODER
Rotate and push for data entry.

HEADPHONES

FOOT SWITCH INPUT
Trs Jack input - dedicated plug for Crumar dual rail rotary control.

BALANCED OUTPUTS
Audio left and right TRS balanced outputs.

MIDI IN/OUT USB
Device type B USB port used to connect Mojo Desktop to your computer for MIDI input and output connectivity.

SWELL PEDAL INPUT
Trs Jack input - signal on ring from 10k to 50k linear pot.

SYSTEM USB PORTS
USB-host ports - use them to connect USB class compliant midi keyboards, USB flash drives.

POWER SUPPLY CONNECTION
9VDC - center positive.

POWER ON/OFF BUTTON

Getting Started
1. Connect power supply.
2. Connect audio outs to your mixer/amp.
3. Connect your midi keyboard.
4. Power the Mojo Desktop on.
5. Be sure to match midi channels.
6. Start playing.

Getting Started

1. Connect power supply.

2. Connect audio outs to your mixer/amp.

3. Connect your midi keyboard.

4. Power the Mojo Desktop on.

5. Be sure to match midi channels.

6. Start playing.

Documents / Resources

	CRUMAR Mojo Desktop [pdf] User Guide CRUMAR, Mojo Desktop, MJ DSK