# gembird JPD-PS4BT-01 Wireless Game Controller for Playstation 4 or PC User Manual

**JPD-PS4BT-01 Wireless Game Controller for Playstation 4 or PC User Manual**

**Contents** [ **hide** ]

## JPD-PS4BT-01 Wireless Game Controller for Playstation 4 or PC

Wireless Game Controller for Playstation 4 or PC

## Features

- Wireless Bluetooth game controller for PlayStation 4 or PC
- Standard PS4 configuration: 2 analog joysticks, 4-way D-pad and 8 action buttons
- Dual vibration and headset socket
- Colored LED light bar and practical back light for the action buttons

## Specifications

- Interface: Bluetooth 2.1 +EDR
- Buttons: PS, Share, Option, ↑ , ↓ , ←, →, ✕, O,□, △,**L1,L2,L3,** ,R2,R3,RESET
- Battery: Li-Ion, 600 mAh
- Headset socket: 35 mm CTIA 4-pin
- Charging port: micro-USB
- Dimensions: 149 x 34 x 64 mm
- Net weight: 194 g

**1**

**2**

<1sec

>10sec

**On PC** (wired connection)
Connect controller into PC via charging cable in package. All LEDs light on, can play games directly. If not install automatically you can download drivers under support tab.
On PS4 Console (both wired and Bluetooth connection are available).
**Wired Connection**
Plug controller into PS4 console via charging cable and then press PS button (GG logo button) for is to start
**Wireless Bluetooth Connection**

1. First time to connect the controller to PS4 console. Plug controller into PS4 console via charging cable and then press PS button (G logo button) for 1 second to start. And then you can remove the cable and use controller in wireless connection.

2. Reconnection. Press PS button for 1 second to turn on controller and it will connect automatically.

**Turn off controller**
Keep pressing G button for 5 seconds to turn off controller.

Download drivers using this link to product's page.
GEMBIRD EUROPE B.V.
**http://www.gembird.eu**
AN brands and logos are regt-iered trademarks of their reseed we owners



**Declaration of conformity**

Tris product is tested and corrpiles with the easenitlail requirements of The law of member states Connceting RED 12014,/53,EU). RoHS (2011.16.5.EU).The CE deolartion can be found under **www.gembird.eu**

**Waste dispocal**

Waste disposal:
Do not deposit this equipment with the household waste. Improper disposal can harm both the environment and human health. For information about waste collection facilities for used electrical and electronic devices, please contact your city council or an authorized company for the disposal of electrical and electronic equipment.

# WARRANTY CONDITIONS

The receipt must clearly list the date of purchase and the part number, in addition it should be printed. Keep the receipt for the entire warranty period since it is required for all warranty claims. During the warranty period the defective items will be credited, repaired or replaced at the manufacturer's expense. Work carried out under the warranty neither extends the warranty period nor starts a new warranty period. The manufacturer reserves the right to void any warranty claim for damages or defects due to misuse, abuse or external impact (falling down, impact, ingress of water, dust, contamination or break). Wearing parts (e.g. rechargeable batteries) are excluded from the warranty. Upon receipt of the RMA goods, Gembird Europe B.V. reserves the right to choose between replacement of defective goods or issuing a credit note. The credit note amount will always be calculated on the basis of the current market value of the defective products.
Gembird Europe B.V. Wittenrouwen 56, 1356CD Almere, The Netherlands
www.gembird.nl/service support@gmb.nl

## Documents / Resources

| | |
|---|---|
|  | **gembird JPD-PS4BT-01 Wireless Game Controller for Playstation 4 or PC** [pdf] User Manual<br>JPD-PS4BT-01 Wireless Game Controller for Playstation 4 or PC, JPD-PS4BT-01, Wireless Game Controller for Playstation 4 or PC, Wireless Game Controller, Game Controller, Controller |