Manuals+ — User Manuals Simplified.

Horizon URC2069 Pulse Remote User Guide

Using the Horizon URC2069 Pulse Remote

Power:
Powers TV on/off.

Guide:
Display channel listings guide.

OK:
Select a highlighted option.

Info:
Display the Infobar to view description of a program.

Mute:
Turns volume on and off.

Volume +/-:
Adjust volume.

Last:
Return to previous channel or previous page.

Setup:
Used to program your remote.

Cable:
Powers Cable Box on/off.

Menu:
Display main menu.

Direction Buttons:
Navigate and move highlight through guides and menus.

Exit:
Exit guides and menus to return to current program.

Page:
Jump guide page back and forward.

Channel +/-:
Change the channel.

Number Pad:
Enter channel number or pin.

Language:
Used to change language.

Contents [**hide**]

How to Program Your Remote:

1. Turn on your TV.
2. On the remote control, press and hold SETUP until LED blinks twice.
3. Press the "TV POWER" key.
4. Aim the remote control at the device. Press and hold down the DIGIT key for your TV brand: 1. Insignia / Dynex 2. LG / Zenith 3. Mitsubishi 4. Panasonic 5. Philips / Magnavox 6. Samsung 7. Sharp 8. Sony 9. Toshiba 0. Vizio
5. Let go of the key when your TV turns off. The setup is complete.
6. If the power LED blinks twice, the code was successful. If there is one long blink, the setup failed.
   NOTE: To locate a code for a TV brand that is not listed, press and hold SETUP until the LED blinks twice.
   Press and hold down the OK/SELECT key. Let go of the OK/SELECT key when the TV turns off.
   * DVR service functionality is not compatible with this remote.

Documents / Resources

HORIZON Horizon URC2069 Pulse Remote [pdf] User Guide
Horizon, URC2069, Pulse Remote